

FUJIFILM

DIGITAL CAMERA

GFX 50R

Owner's Manual

Introduction

Thank you for your purchase of this product. Be sure that you have read this manual and understood its contents before using the camera. Keep the manual where it will be read by all who use the product.

For the Latest Information

The latest versions of the manuals are available from:

<http://fujifilm-dsc.com/en/manual/>



The site can be accessed not only from your computer but also from smartphones and tablets. It also contains information on the software license.



For information on firmware updates, visit:

http://www.fujifilm.com/support/digital_cameras/software/



Chapter Index

| | |
|--|-----|
| Menu List | iv |
| 1 Before You Begin | 1 |
| 2 First Steps | 25 |
| 3 Basic Photography and Playback | 43 |
| 4 Movie Recording and Playback | 49 |
| 5 Taking Photographs | 55 |
| 6 The Shooting Menus | 87 |
| 7 Playback and the Playback Menu | 129 |
| 8 The Setup Menus | 155 |
| 9 Shortcuts | 191 |
| 10 Peripherals and Optional Accessories | 203 |
| 11 Connections | 217 |
| 12 Technical Notes | 231 |



Menu List







Camera menu options are listed below.

Shooting Menus

Adjust settings when shooting photos or movies.

See page 87 for details.





| Q | IMAGE QUALITY SETTING | | AF/MF | AF/MF SETTING | |
|-----|---------------------------|----|-------|--|-----|
| | IMAGE SIZE | 88 | | FOCUS AREA | 100 |
| | IMAGE QUALITY | 89 | | AF MODE | 101 |
| | RAW RECORDING | 89 | | STORE AF MODE BY ORIENTATION | 102 |
| 1/3 | FILM SIMULATION | 90 | 1/3 | RAPID AF | 102 |
| | GRAIN EFFECT | 91 | | AF POINT DISPLAY   | 102 |
| | COLOR CHROME EFFECT | 91 | | NUMBER OF FOCUS POINTS | 103 |
| | DYNAMIC RANGE | 92 | | PRE-AF | 103 |
| | WHITE BALANCE | 93 | | AF ILLUMINATOR | 103 |
| | HIGHLIGHT TONE | 96 | | FACE/EYE DETECTION SETTING | 104 |
| | SHADOW TONE | 96 | | AF+MF | 105 |
| | COLOR | 96 | | MF ASSIST | 106 |
| 2/3 | SHARPNESS | 96 | 2/3 | FOCUS CHECK | 106 |
| | NOISE REDUCTION | 97 | | INTERLOCK SPOT AE & FOCUS AREA | 107 |
| | LONG EXPOSURE NR | 97 | | INSTANT AF SETTING | 107 |
| | LENS MODULATION OPTIMIZER | 97 | | DEPTH-OF-FIELD SCALE | 108 |
| | COLOR SPACE | 97 | | RELEASE/FOCUS PRIORITY | 108 |
| | PIXEL MAPPING | 98 | 3/3 | TOUCH SCREEN MODE | 109 |
| 3/3 | SELECT CUSTOM SETTING | 98 | | | |
| | EDIT/SAVE CUSTOM SETTING | 99 | | | |

|  SHOOTING SETTING | |  |
|---|--------------------------|---|
| 1 1/2 | SELF-TIMER | 111 |
| | SAVE SELF-TIMER SETTING | 112 |
| | INTERVAL TIMER SHOOTING | 112 |
| | AE BKT SETTING | 114 |
| | FILM SIMULATION BKT | 114 |
| | FOCUS BKT | 115 |
| | PHOTOMETRY | 116 |
| 2 1/2 | SHUTTER TYPE | 117 |
| | FLICKER REDUCTION | 118 |
| | IS MODE | 118 |
| | ISO | 119 |
| | MOUNT ADAPTER SETTING | 121 |
| | 35mm FORMAT MODE | 123 |
| | WIRELESS COMMUNICATION | 123 |
|  FLASH SETTING | |  |
| | FLASH FUNCTION SETTING | 124 |
| | RED EYE REMOVAL | 124 |
| | TTL-LOCK MODE | 125 |
| | LED LIGHT SETTING | 125 |
| | MASTER SETTING | 126 |
| | CH SETTING | 126 |
|  MOVIE SETTING | |  |
| | MOVIE MODE | 127 |
| | MOVIE AF MODE | 127 |
| | HDMI OUTPUT INFO DISPLAY | 127 |
| | HDMI REC CONTROL | 128 |
| | MIC LEVEL ADJUSTMENT | 128 |
| | MIC/REMOTE RELEASE | 128 |

The Playback Menu

Adjust playback settings.








 See page 135 for details.

|  PLAY BACK MENU |  |  PLAY BACK MENU |  |
|--|---|---|---|
| SWITCH SLOT | 135 | RED EYE REMOVAL | 144 |
| RAW CONVERSION | 136 | VOICE MEMO SETTING | 145 |
| ERASE | 138 | COPY | 146 |
| SIMULTANEOUS DELETE (RAW SLOT1/JPG SLOT2) | 140 | IMAGE TRANSFER ORDER | 147 |
| CROP | 140 | WIRELESS COMMUNICATION | 148 |
| RESIZE | 141 | PHOTOBOOK ASSIST | 149 |
| PROTECT | 142 | PRINT ORDER (DPOF) | 151 |
| IMAGE ROTATE | 143 | instax PRINTER PRINT | 152 |
| | | DISP ASPECT | 153 |

Setup Menus

Adjust basic camera settings.

 See page 155 for details.

|  USER SETTING |  |  SCREEN SETTING |  |
|---|---|--|---|
| FORMAT | 156 | EVF BRIGHTNESS | 162 |
| DATE/TIME | 157 | EVF COLOR | 162 |
| TIME DIFFERENCE | 157 | EVF COLOR ADJUSTMENT | 162 |
|  言語/LANG. | 158 | LCD BRIGHTNESS | 163 |
| MY MENU SETTING | 158 | LCD COLOR | 163 |
| SENSOR CLEANING | 159 | LCD COLOR ADJUSTMENT | 163 |
| BATTERY AGE | 159 | IMAGE DISP. | 164 |
| RESET | 159 | AUTOROTATE DISPLAYS | 164 |
|  SOUND SETTING |  | PREVIEW EXP./WB IN MANUAL MODE | 165 |
| AF BEEP VOL. | 160 | NATURAL LIVE VIEW | 165 |
| SELF-TIMER BEEP VOL. | 160 | FRAMING GUIDELINE | 166 |
| OPERATION VOL. | 160 | AUTOROTATE PB | 167 |
| SHUTTER VOLUME | 161 | FOCUS SCALE UNITS | 167 |
| SHUTTER SOUND | 161 | DISP. CUSTOM SETTING | 168 |
| PLAYBACK VOLUME | 161 | LARGE INDICATORS MODE(EVF) | 169 |
| | | LARGE INDICATORS MODE(LCD) | 170 |
| | | $\frac{3}{3}$ LARGE INDICATORS DISP. SETTING | 171 |









| | | | | |
|--|---|---|--|---|
| 1/2 |  BUTTON/DIAL SETTING |  |  SAVE DATA SETTING |  |
| | FOCUS LEVER SETTING | :172 | FRAME NO. | :182 |
| | EDIT/SAVE QUICK MENU | :173 | SAVE ORG IMAGE | :183 |
| | FUNCTION (Fn) SETTING | :174 | EDIT FILE NAME | :183 |
| | COMMAND DIAL SETTING | :176 | CARD SLOT SETTING (STILL IMAGE) | :183 |
| | SHUTTER AF | :177 | SWITCH SLOT (SEQUENTIAL) | :183 |
| | SHUTTER AE | :177 | MOVIE FILE DESTINATION | :184 |
| | SHOOT WITHOUT LENS | :177 | SELECT FOLDER | :184 |
| | SHOOT WITHOUT CARD | :178 | COPYRIGHT INFO | :184 |
| | 2 1/2 | FOCUS RING | :178 |  CONNECTION SETTING |
| AE/AF-LOCK MODE | | :178 | Bluetooth SETTINGS | :185 |
| TOUCH SCREEN SETTING | | :179 | NETWORK SETTING | :186 |
| LOCK | | :179 | instax PRINTER CONNECTION SETTING | :187 |
|  POWER MANAGEMENT |  |  PC CONNECTION MODE | | :187 |
| AUTO POWER OFF | | GENERAL SETTINGS | | :189 |
| SHOOTING STAND BY MODE | | INFORMATION | | :189 |
| AUTO POWER SAVE | | RESET WIRELESS SETTING | | :189 |



Table of Contents

| | |
|-----------------------------------|------------|
| Introduction | ii |
| For the Latest Information | ii |
| Menu List | iv |
| Shooting Menus | iv |
| The Playback Menu | vi |
| Setup Menus | vii |
| Supplied Accessories | xix |
| About This Manual | xx |
| Symbols and Conventions | xx |
| Terminology | xx |

1 Before You Begin 1

| | |
|--|-----------|
| Parts of the Camera | 2 |
| The Serial Number Plate | 5 |
| The Focus Stick (Focus Lever) | 5 |
| The Shutter Speed Dial | 5 |
| The Drive Button | 6 |
| The Exposure Compensation Dial | 6 |
| The Command Dials | 7 |
| The Indicator Lamp | 8 |
| The LCD Monitor | 9 |
| Camera Displays | 10 |
| The Electronic Viewfinder | 10 |
| The LCD Monitor | 12 |
| Display Rotation | 13 |
| Choosing a Display Mode | 14 |
| Adjusting Display Brightness | 15 |
| Focusing the Viewfinder | 15 |
| The DISP/BACK Button | 16 |
| The Dual Display | 17 |
| Customizing the Standard Display | 18 |
| Using the Menus | 20 |

| | |
|-------------------------------|----|
| Touch Screen Mode | 21 |
| Shooting Touch Controls | 21 |
| Playback Touch Controls | 24 |

2 First Steps 25

| | |
|-------------------------------------|----|
| Attaching the Strap | 26 |
| Attaching a Lens | 28 |
| Charging the Battery | 29 |
| Inserting the Battery | 32 |
| Inserting Memory Cards | 34 |
| Using Two Cards | 35 |
| Compatible Memory Cards | 36 |
| Turning the Camera On and Off | 37 |
| Checking the Battery Level | 38 |
| Basic Setup | 39 |
| Choosing a Different Language | 41 |
| Changing the Time and Date | 41 |

3 Basic Photography and Playback 43







| | |
|-----------------------------------|----|
| Taking Photographs (Mode P) | 44 |
| Viewing Pictures | 47 |
| Deleting Pictures | 48 |

4 Movie Recording and Playback 49

| | |
|--------------------------------|----|
| Recording Movies | 50 |
| Adjusting Movie Settings | 52 |
| Viewing Movies | 53 |



5 Taking Photographs 55

| | |
|------------------------------------|----|
| P, S, A, and M Modes | 56 |
| Mode P: Program AE | 56 |
| Mode S: Shutter-Priority AE | 58 |
| Mode A: Aperture-Priority AE | 61 |
| Mode M: Manual Exposure | 62 |

| | |
|---|-----------|
| Autofocus | 64 |
| Focus Mode..... | 65 |
| Autofocus Options (AF Mode)..... | 67 |
| Focus-Point Selection | 69 |
| Manual Focus | 72 |
| Checking Focus..... | 74 |
| Sensitivity | 76 |
| AUTO..... | 77 |
| Metering | 78 |
| Exposure Compensation | 79 |
| C (Custom) | 80 |
| Focus/Exposure Lock | 81 |
| The AF-L and AE-L Buttons | 82 |
| Bracketing | 83 |
|  AE BKT | 83 |
|  ISO BKT..... | 83 |
|  FILM SIMULATION BKT | 83 |
|  WHITE BALANCE BKT..... | 84 |
|  DYNAMIC RANGE BKT | 84 |
|  FOCUS BKT | 84 |
| Continuous Shooting (Burst Mode) | 85 |
| Multiple Exposures | 86 |

6 The Shooting Menus **87**

| | |
|------------------------------------|-----------|
| IMAGE QUALITY SETTING | 88 |
| IMAGE SIZE..... | 88 |
| IMAGE QUALITY | 89 |
| RAW RECORDING..... | 89 |
| FILM SIMULATION..... | 90 |
| GRAIN EFFECT | 91 |
| COLOR CHROME EFFECT | 91 |
| DYNAMIC RANGE..... | 92 |
| WHITE BALANCE..... | 93 |

| | |
|--|------------|
| HIGHLIGHT TONE | 96 |
| SHADOW TONE | 96 |
| COLOR | 96 |
| SHARPNESS | 96 |
| NOISE REDUCTION | 97 |
| LONG EXPOSURE NR | 97 |
| LENS MODULATION OPTIMIZER | 97 |
| COLOR SPACE | 97 |
| PIXEL MAPPING | 98 |
| SELECT CUSTOM SETTING | 98 |
| EDIT/SAVE CUSTOM SETTING | 99 |
| AF/MF SETTING | 100 |
| FOCUS AREA | 100 |
| AF MODE | 101 |
| STORE AF MODE BY ORIENTATION | 102 |
| RAPID AF | 102 |
| AF POINT DISPLAY   | 102 |
| NUMBER OF FOCUS POINTS | 103 |
| PRE-AF | 103 |
| AF ILLUMINATOR | 103 |
| FACE/EYE DETECTION SETTING | 104 |
| AF+MF | 105 |
| MF ASSIST | 106 |
| FOCUS CHECK | 106 |
| INTERLOCK SPOT AE & FOCUS AREA | 107 |
| INSTANT AF SETTING | 107 |
| DEPTH-OF-FIELD SCALE | 108 |
| RELEASE/FOCUS PRIORITY | 108 |
| TOUCH SCREEN MODE | 109 |
| SHOOTING SETTING | 111 |
| SELF-TIMER | 111 |
| SAVE SELF-TIMER SETTING | 112 |
| INTERVAL TIMER SHOOTING | 112 |

| | |
|---|------------|
| AE BKT SETTING | 114 |
| FILM SIMULATION BKT | 114 |
| FOCUS BKT | 115 |
| PHOTOMETRY | 116 |
| SHUTTER TYPE | 117 |
| FLICKER REDUCTION | 118 |
| IS MODE | 118 |
| ISO | 119 |
| MOUNT ADAPTER SETTING | 121 |
| 35mm FORMAT MODE | 123 |
| WIRELESS COMMUNICATION | 123 |
| FLASH SETTING | 124 |
| FLASH FUNCTION SETTING | 124 |
| RED EYE REMOVAL | 124 |
| TTL-LOCK MODE | 125 |
| LED LIGHT SETTING | 125 |
| MASTER SETTING | 126 |
| CH SETTING | 126 |
| MOVIE SETTING | 127 |
| MOVIE MODE | 127 |
| MOVIE AF MODE | 127 |
| HDMI OUTPUT INFO DISPLAY | 127 |
| HDMI REC CONTROL | 128 |
| MIC LEVEL ADJUSTMENT | 128 |
| MIC/REMOTE RELEASE | 128 |
| 7 Playback and the Playback Menu | 129 |
| The Playback Display | 130 |
| The DISP/BACK Button | 131 |
| Viewing Pictures | 133 |
| Playback Zoom | 134 |
| Multi-Frame Playback | 134 |

| | |
|--|------------|
| The Playback Menu..... | 135 |
| SWITCH SLOT | 135 |
| RAW CONVERSION | 136 |
| ERASE | 138 |
| SIMULTANEOUS DELETE(RAW SLOT1/JPG SLOT2) | 140 |
| CROP | 140 |
| RESIZE | 141 |
| PROTECT..... | 142 |
| IMAGE ROTATE | 143 |
| RED EYE REMOVAL | 144 |
| VOICE MEMO SETTING | 145 |
| COPY | 146 |
| IMAGE TRANSFER ORDER..... | 147 |
| WIRELESS COMMUNICATION | 148 |
| PHOTOBOOK ASSIST | 149 |
| PRINT ORDER (DPOF)..... | 151 |
| instax PRINTER PRINT | 152 |
| DISP ASPECT | 153 |

8 The Setup Menus 155

| | |
|---------------------------|------------|
| USER SETTING..... | 156 |
| FORMAT | 156 |
| DATE/TIME..... | 157 |
| TIME DIFFERENCE | 157 |
| 🗣 言語/LANG | 158 |
| MY MENU SETTING..... | 158 |
| SENSOR CLEANING | 159 |
| BATTERY AGE | 159 |
| RESET..... | 159 |
| SOUND SETTING..... | 160 |
| AF BEEP VOL..... | 160 |
| SELF-TIMER BEEP VOL..... | 160 |
| OPERATION VOL..... | 160 |

| | |
|-------------------------------------|------------|
| SHUTTER VOLUME..... | 161 |
| SHUTTER SOUND..... | 161 |
| PLAYBACK VOLUME..... | 161 |
| SCREEN SETTING..... | 162 |
| EVF BRIGHTNESS..... | 162 |
| EVF COLOR..... | 162 |
| EVF COLOR ADJUSTMENT..... | 162 |
| LCD BRIGHTNESS..... | 163 |
| LCD COLOR..... | 163 |
| LCD COLOR ADJUSTMENT..... | 163 |
| IMAGE DISP..... | 164 |
| AUTOROTATE DISPLAYS..... | 164 |
| PREVIEW EXP/WB IN MANUAL MODE..... | 165 |
| NATURAL LIVE VIEW..... | 165 |
| FRAMING GUIDELINE..... | 166 |
| AUTOROTATE PB..... | 167 |
| FOCUS SCALE UNITS..... | 167 |
| DISP. CUSTOM SETTING..... | 168 |
| LARGE INDICATORS MODE(EVF)..... | 169 |
| LARGE INDICATORS MODE(LCD)..... | 170 |
| LARGE INDICATORS DISP. SETTING..... | 171 |
| BUTTON/DIAL SETTING..... | 172 |
| FOCUS LEVER SETTING..... | 172 |
| EDIT/SAVE QUICK MENU..... | 173 |
| FUNCTION (Fn) SETTING..... | 174 |
| COMMAND DIAL SETTING..... | 176 |
| SHUTTER AF..... | 177 |
| SHUTTER AE..... | 177 |
| SHOOT WITHOUT LENS..... | 177 |
| SHOOT WITHOUT CARD..... | 178 |
| FOCUS RING..... | 178 |
| AE/AF-LOCK MODE..... | 178 |
| TOUCH SCREEN SETTING..... | 179 |
| LOCK..... | 179 |

| | |
|---|------------|
| POWER MANAGEMENT | 180 |
| AUTO POWER OFF | 180 |
| SHOOTING STAND BY MODE | 180 |
| AUTO POWER SAVE | 181 |
| SAVE DATA SETTING | 182 |
| FRAME NO. | 182 |
| SAVE ORG IMAGE | 183 |
| EDIT FILE NAME | 183 |
| CARD SLOT SETTING (STILL IMAGE) | 183 |
| SWITCH SLOT (SEQUENTIAL) | 183 |
| MOVIE FILE DESTINATION | 184 |
| SELECT FOLDER | 184 |
| COPYRIGHT INFO | 184 |
| CONNECTION SETTING | 185 |
| Bluetooth SETTINGS | 185 |
| NETWORK SETTING | 186 |
| instax PRINTER CONNECTION SETTING | 187 |
| PC CONNECTION MODE | 187 |
| GENERAL SETTINGS | 189 |
| INFORMATION | 189 |
| RESET WIRELESS SETTING | 189 |

9 Shortcuts 191

| | |
|---|------------|
| Shortcut Options | 192 |
| The Q (Quick Menu) Button | 193 |
| The Quick Menu Display | 193 |
| Viewing and Changing Settings | 194 |
| Editing the Quick Menu | 195 |
| The Fn (Function) Buttons | 196 |
| Assigning Roles to the Function Buttons | 198 |
| MY MENU | 200 |
| MY MENU SETTING | 200 |

| | | |
|-----------|---|------------|
| 10 | Peripherals and Optional Accessories | 203 |
| | Lenses | 204 |
| | Lens Parts | 204 |
| | Lens Care | 205 |
| | Removing Lens Caps | 205 |
| | Attaching Lens Hoods | 205 |
| | Aperture ring | 206 |
| | External Flash Units | 207 |
| | Flash Settings | 208 |
| | SYNC TERMINAL | 209 |
| | SHOE MOUNT FLASH | 210 |
| | MASTER(OPTICAL) | 213 |
| 11 | Connections | 217 |
| | HDMI Output | 218 |
| | Connecting to HDMI Devices | 218 |
| | Shooting | 219 |
| | Playback | 219 |
| | Wireless Connections (Bluetooth®, Wireless LAN/Wi-Fi) | 220 |
| | Smartphones and Tablets: FUJIFILM Camera Remote | 220 |
| | Tethered Shooting: FUJIFILM X Acquire/FUJIFILM Tether Shooting Plug-in/FUJIFILM Tether Shooting Plug-in PRO/ Hyper-Utility Software HS-V5 | 222 |
| | Connecting to Computers via USB | 223 |
| | Tethered Shooting: FUJIFILM X Acquire/FUJIFILM Tether Shooting Plug-in/FUJIFILM Tether Shooting Plug-in PRO/ Hyper-Utility Software HS-V5 | 226 |
| | Copying Pictures to a Computer | 227 |
| | Copying RAW Images in Other Formats: FUJIFILM X RAW STUDIO | 228 |
| | Saving and Loading Camera Settings (FUJIFILM X Acquire) | 228 |
| | instax SHARE Printers | 229 |
| | Establishing a Connection | 229 |
| | Printing Pictures | 230 |

| | |
|--|------------|
| 12 Technical Notes | 231 |
| Accessories from Fujifilm | 232 |
| Software from Fujifilm | 234 |
| FUJIFILM Camera Remote | 234 |
| MyFinePix Studio..... | 234 |
| RAW FILE CONVERTER EX..... | 234 |
| FUJIFILM X RAW STUDIO | 235 |
| FUJIFILM X Acquire | 235 |
| FUJIFILM Tether Shooting Plug-ins for Lightroom..... | 235 |
| Hyper-Utility Software HS-V5 | 235 |
| For Your Safety..... | 236 |
| Product Care..... | 245 |
| Cleaning the Image Sensor..... | 246 |
| Firmware Updates | 247 |
| Checking the Firmware Version..... | 247 |
| Troubleshooting | 248 |
| Warning Messages and Displays..... | 257 |
| Memory Card Capacity..... | 260 |
| Specifications..... | 261 |

Supplied Accessories

The following are included with the camera:

- NP-T125 rechargeable battery
- BC-T125 battery charger
- Plug adapter
- Body cap
- Metal strap clips (× 2)
- Clip attaching tool
- Protective covers (× 2)
- Shoulder strap
- Cable protector
- Hot shoe cover (comes attached to hot shoe)
- Sync terminal cap (comes attached to camera)
- *Owner's Manual* (this manual)



- The plug adapter supplied with the camera varies with the country or region of purchase; be sure to use the adapter appropriate to your country or region as described in the enclosed notice.
- For information on compatible computer software, see “Software from Fujifilm” (📖 234).

About This Manual

This manual contains instructions for your FUJIFILM GFX 50R digital camera. Be sure you have read and understood its contents before proceeding.

Symbols and Conventions

The following symbols are used in this manual:



Information that should be read to prevent damage to the product.



Additional information that may be helpful when using the product.



Pages on which related information may be found.

Menus and other text in the displays are shown in **bold**. Illustrations are for explanatory purposes only; drawings may be simplified, while photographs are not necessarily taken with the model of camera described in this manual.


Terminology

The optional SD, SDHC, and SDXC memory cards the camera uses to store pictures are referred to as “memory cards”. The electronic viewfinder may be referred to as the “EVF” and the LCD monitor as the “LCD”.


Before You Begin




Parts of the Camera



| | | | |
|------------------------------------|-------------------|---------------------------------------|-------------|
| ① ON/OFF switch..... | 37 | ⑪ Diopter adjustment control | 15 |
| ② Shutter button..... | 46 | ⑫ Strap eyelet..... | 26 |
| ③ Exposure compensation dial | 6, 79 | ⑬ Sync terminal | 209 |
| ④ Fn1 button..... | 196 | ⑭ Lens signal contacts | |
| ⑤ Dial lock release..... | 5 | ⑮ Lens release button..... | 28 |
| ⑥ Shutter speed dial | | ⑯ Fn2 button..... | 176 |
| | 5, 56, 58, 61, 62 | ⑰ Drive button..... | 6 |
| ⑦ Hot shoe..... | 23, 210 | ⑱ Front command dial | 7, 176 |
| ⑧ Microphone | 51 | ⑲ Microphone/remote release connector | |
| ⑨ AF-assist illuminator..... | 103 | (ø 2.5 mm)..... | 51, 60, 128 |
| Self-timer lamp | 111 | ⑳ Hot shoe cover..... | 210 |
| ⑩ Remote release connector cover | | ㉑ Body cap | 28 |
| | 51, 60, 128 | | |




- | | |
|--|--|
| 22 Electronic viewfinder (EVF)..... 10, 14, 15 | 36 Connector cover..... 31, 223 |
| 23 Eye sensor 14 | 37 Speaker..... 53, 161 |
| 24 VIEW MODE button..... 14 | 38 Tripod mount |
| 25 (delete) button 48 | 39 Battery-chamber cover 32 |
| 26 Focus mode selector..... 65 | 40 Battery-chamber cover latch..... 32 |
| 27 Fn3 button..... 82, 196 | 41 LCD monitor..... 9, 12, 14, 15 |
| 28 Rear command dial..... 7, 133, 176 | Touch screen..... 21, 109, 179 |
| 29 Fn4 button..... 82, 196 | 42 DISP (display)/ BACK button 16, 131 |
| 30 Fn5 button..... 67, 196 | 43 (playback) button..... 47 |
| 31 Q (quick menu) button 193 | 44 MENU/OK button 20 |
| 32 HDMI connector cover | 45 Focus stick (focus lever)..... 5, 69, 172 |
| 33 Memory card slot cover..... 34 | 46 HDMI Micro connector (Type D)..... 218 |
| 34 Memory card slot cover latch..... 34 | 47 Memory card slot 1..... 34 |
| 35 Indicator lamp 8, 31 | 48 Memory card slot 2..... 34 |



| | | | |
|--------------------------|----|---------------------------------|-----|
| ④⑨ Battery chamber | 32 | ⑤① USB connector (Type-C) | 223 |
| ⑤② Battery latch | 33 | ⑤② 15V DC-IN connector | 31 |


The Cable Protector

- ① The cable protector prevents accidental disconnection of the USB cable or AC adapter. Attach the protector as shown and tighten the lock screw.
- ② Connect the cable and pass it through the protector as shown.



The Serial Number Plate


Do not remove the serial number plate, which provides the FCC ID, KC mark, serial number, and other important information.



Serial number plate


The Focus Stick (Focus Lever)

Tilt or press the focus stick to select the focus area. The focus stick can also be used to navigate the menus.




The Shutter Speed Dial

Press the dial lock release to release the dial before rotating it to the desired setting. Press the release again to lock the dial in place.



The Drive Button


Pressing the drive button displays the following drive mode options.



| Mode | | Mode | |
|--|----|--|----|
| STILL IMAGE (single frame) | 44 | DYNAMIC RANGE BKT (dynamic range bracketing) | 84 |
| CONTINUOUS (burst mode) | 85 | FOCUS BKT (focus bracketing) | 84 |
| AE BKT (exposure bracketing) | 83 | MULTIPLE EXPOSURE | 86 |
| ISO BKT (sensitivity bracketing) | 83 | MOVIE | 50 |
| FILM SIMULATION BKT (film simulation bracketing) | 83 | | |
| WHITE BALANCE BKT (white balance bracketing) | 84 | | |






The Exposure Compensation Dial

Rotate the dial to choose an exposure compensation amount.



The Command Dials

Rotate or press the command dials to:

| | Front command dial | Rear command dial |
|---|--|--|
|  |  | |
|   Rotate | <ul style="list-style-type: none"> • Select menu tabs or page through menus • Choose the desired combination of shutter speed and aperture (program shift) • Adjust aperture^{1,2} • Adjust exposure compensation⁴ • Adjust sensitivity¹ • View other pictures during playback | <ul style="list-style-type: none"> • Highlight menu items • Choose the desired combination of shutter speed and aperture (program shift) • Choose a shutter speed¹ • Adjust settings in the quick menu • Choose the size of the focus frame • Zoom in or out in full frame playback • Zoom in or out in multi-frame playback |
|  Press | <p>—</p> | <ul style="list-style-type: none"> • Zoom in on the active focus point³ • Press and hold to choose the manual focus mode focus display³ • Zoom in on the active focus point during playback |

1 Can be changed using **■ BUTTON/DIAL SETTING > COMMAND DIAL SETTING**.


2 If the lens is equipped with an aperture ring with a "C" position, the camera command dials can be used to adjust aperture when the aperture ring is rotated to C.

3 Available only if **FOCUS CHECK** is assigned to a function button.

4 Exposure compensation dial rotated to C.

The Indicator Lamp

Camera status is shown by the indicator lamp.



| Indicator lamp | Camera status |
|-------------------------|--|
| Glows green | Focus locked. |
| Blinks green | Focus or slow shutter speed warning. Pictures can be taken. |
| Blinks green and orange | <ul style="list-style-type: none"> • Camera on: Recording pictures. Additional pictures can be taken. • Camera off: Uploading pictures to a smartphone or tablet.* |
| Glows orange | Recording pictures. No additional pictures can be taken at this time. |
| Blinks orange | Flash charging; flash will not fire when picture is taken. |
| Blinks red | Lens or memory error. |


* Displayed only if pictures are selected for upload.



- Warnings may also appear in the display.
- The indicator lamp remains off while your eye is to the viewfinder.

The LCD Monitor

The LCD monitor can be tilted for easier viewing, but be careful not to touch the wires or trap fingers or other objects behind the monitor. Touching the wires could cause camera malfunction.




The LCD monitor also functions as a touch screen that can be used for:

- Focus or focus-area selection (📖 21, 22)
- Function selection (📖 23)
- Full-frame playback (📖 24)

This section lists the indicators that may be displayed during shooting.



1 Before You Begin




| | | | |
|---|-------------|--|---------------|
| ① Microphone | 128 | ②④ Histogram..... | 19 |
| ② Remote release..... | 128 | ②⑤ Battery level | 38 |
| ③ Flash (TTL) mode | 210 | ②⑥ Sensitivity..... | 76 |
| ④ Flash compensation..... | 210 | ②⑦ Exposure compensation | 79 |
| ⑤ Self-timer indicator..... | 111 | ②⑧ Aperture..... | 57, 61, 62 |
| ⑥ Continuous mode | 85 | ②⑨ Shutter speed..... | 57, 58, 62 |
| ⑦ Shutter type..... | 117 | ③⑩ TTL lock | 125, 175, 199 |
| ⑧ AF+MF indicator ² | 105 | ③① AE lock..... | 82, 178 |
| ⑨ Bluetooth ON/OFF | 185 | ③② Metering..... | 78 |
| ⑩ White balance..... | 93 | ③③ Shooting mode | 56 |
| ⑪ Film simulation..... | 90 | ③④ Focus mode ² | 65 |
| ⑫ Dynamic range..... | 92 | ③⑤ Focus indicator ² | 66 |
| ⑬ Image transfer status..... | 185, 220 | ③⑥ Manual focus indicator ² | 65, 72 |
| ⑭ Date and time | 39, 41, 157 | ③⑦ AF lock..... | 82, 178 |
| ⑮ Movie mode ³ | 50, 127 | ③⑧ Distance indicator ² | 74 |
| ⑯ Time remaining ³ | 50 | ③⑨ Recording level ^{2,3} | 128 |
| ⑰ Card slot options | 35, 183 | ④⑩ Exposure indicator | 62, 79 |
| ⑱ Number of available frames ¹ | 260 | ④① Virtual horizon..... | 19 |
| ⑲ Image size..... | 88 | ④② Location data download status | 189, 220 |
| ⑳ Image quality | 89 | ④③ 35mm format mode | 123 |
| ㉑ Touch screen mode..... | 21, 109 | ④④ Depth-of-field preview | 61, 74 |
| ㉒ Temperature warning | 259 | ④⑤ Focus check..... | 75, 106 |
| ㉓ Focus frame | 69, 81 | ④⑥ IS mode ² | 118 |

1 Shows "9999" if there is space for over 9999 frames.

2 Not displayed when **ON** is selected for **SCREEN SET-UP > LARGE INDICATORS MODE(EVF)**.

3 Displayed during movie recording only.

The LCD Monitor



| | | | |
|---|-------------|--|---------------|
| ① IS mode ² | 118 | ②4 Sensitivity..... | 76 |
| ② Focus check..... | 75, 106 | ②5 Exposure compensation..... | 79 |
| ③ Depth-of-field preview..... | 61, 74 | ②6 Aperture..... | 57, 61, 62 |
| ④ Location data download status..... | 189, 220 | ②7 Shutter speed..... | 57, 58, 62 |
| ⑤ 35mm format mode..... | 123 | ②8 TTL lock..... | 125, 175, 199 |
| ⑥ Bluetooth ON/OFF..... | 185 | ②9 AE lock..... | 82, 178 |
| ⑦ Image transfer status..... | 185, 220 | ③0 Metering..... | 78 |
| ⑧ Movie mode ³ | 50, 127 | ③1 Shooting mode..... | 56 |
| ⑨ Time remaining ³ | 50 | ③2 Focus mode ² | 65 |
| ⑩ Card slot options..... | 35, 183 | ③3 Focus indicator ² | 66 |
| ⑪ Number of available frames ¹ | 260 | ③4 Manual focus indicator ² | 65, 72 |
| ⑫ Image size..... | 88 | ③5 AF lock..... | 82, 178 |
| ⑬ Image quality..... | 89 | ③6 AF+MF indicator ² | 105 |
| ⑭ Date and time..... | 39, 41, 157 | ③7 Shutter type..... | 117 |
| ⑮ Touch screen mode ⁴ | 21, 109 | ③8 Recording level ^{2,3} | 128 |
| ⑯ White balance..... | 93 | ③9 Continuous mode..... | 85 |
| ⑰ Film simulation..... | 90 | ④0 Exposure indicator..... | 62, 79 |
| ⑱ Dynamic range..... | 92 | ④1 Self-timer indicator..... | 111 |
| ⑲ Temperature warning..... | 259 | ④2 Microphone..... | 128 |
| ⑳ Focus frame..... | 69, 81 | ④3 Remote release..... | 128 |
| ㉑ Histogram..... | 19 | ④4 Flash (TTL) mode..... | 210 |
| ㉒ Distance indicator ² | 74 | ④5 Flash compensation..... | 210 |
| ㉓ Battery level..... | 38 | | |

1 Shows "9999" if there is space for over 9999 frames.

2 Not displayed when **ON** is selected for **SCREEN SET-UP > LARGE INDICATORS MODE(LCD)**.

3 Displayed during movie recording only.


4 Camera functions can also be accessed via touch controls.




Display Rotation

When **ON** is selected for **SCREEN SET-UP > AUTOROTATE DISPLAYS**, the indicators in the viewfinder and LCD monitor automatically rotate to match camera orientation.

Choosing a Display Mode


Press the **VIEW MODE** button to cycle through the following display modes.



| Option | Description |
|--|--|
|  EYE SENSOR | Putting your eye to the viewfinder turns the viewfinder on and the LCD monitor off; taking your eye away turns the viewfinder off and LCD monitor on. |
| EVF ONLY | Viewfinder on, LCD monitor off. |
| LCD ONLY | LCD monitor on, viewfinder off. |
| EVF ONLY +  | Putting your eye to the viewfinder turns the viewfinder on; taking it away turns the viewfinder off. The LCD monitor remains off. |
|  EYE SENSOR + LCD IMAGE DISP. | Putting your eye to the viewfinder during shooting turns the viewfinder on, but the LCD monitor is used for the display of images once you remove your eye from the viewfinder after shooting. |

The Eye Sensor

- The eye sensor may respond to objects other than your eye or to light shining directly on the sensor.
- The eye sensor is disabled while the LCD monitor is tilted.



Eye sensor

Adjusting Display Brightness


The brightness and hue of the viewfinder and LCD monitor can be adjusted using the items in the **SCREEN SET-UP** menu. Choose **EVF BRIGHTNESS** or **EVF COLOR** to adjust viewfinder brightness or hue, **LCD BRIGHTNESS** or **LCD COLOR** to do the same for the LCD monitor.


Focusing the Viewfinder

If the indicators displayed in the viewfinder are blurred, put your eye to the viewfinder and rotate the diopter adjustment control until the display is in sharp focus.

To focus the viewfinder:


- ① Lift the diopter adjustment control.
- ② Rotate the control to adjust viewfinder focus.
- ③ Return the control to its original position and lock it in place.




 Lift the control before use. Failure to observe this precaution could cause product malfunction.

The DISP/BACK Button


The **DISP/BACK** button controls the display of indicators in the viewfinder and LCD monitor.

 Indicators for the EVF and LCD must be selected separately. To choose the EVF display, place your eye to the viewfinder while using the **DISP/BACK** button.



Viewfinder


Full screen



*Full screen
(no indicators)*




Standard indicators



Standard (no indicators)




*Dual display
(manual focus mode only)*




LCD Monitor


Standard indicators



No indicators



*Dual display
(manual focus mode only)*



Info display

The Dual Display

The dual display consists of a large full-frame window and a smaller close-up of the focus area.

Customizing the Standard Display

To choose the items shown in the standard indicator display:

1 Display standard indicators.

Use the **DISP/BACK** button to display standard indicators.

2 Select **DISP. CUSTOM SETTING**.

Select **SCREEN SET-UP > DISP. CUSTOM SETTING** in the setup menu.

3 Choose items.

Highlight items and press **MENU/OK** to select or deselect.

- FRAMING GUIDELINE
- ELECTRONIC LEVEL
- FOCUS FRAME
- AF DISTANCE INDICATOR
- MF DISTANCE INDICATOR
- HISTOGRAM
- LIVE VIEW HIGHLIGHT ALERT
- SHOOTING MODE
- APERTURE/S-SPEED/ISO
- INFORMATION BACKGROUND
- Expo. Comp. (Digit)
- Expo. Comp. (Scale)
- FOCUS MODE
- PHOTOMETRY
- SHUTTER TYPE
- FLASH
- CONTINUOUS MODE
- DUAL IS MODE
- TOUCH SCREEN MODE
- WHITE BALANCE
- FILM SIMULATION
- DYNAMIC RANGE
- FRAMES REMAINING
- IMAGE SIZE/QUALITY
- MOVIE MODE & REC. TIME
- 35mm FORMAT MODE
- IMAGE TRANSFER ORDER
- MIC LEVEL
- BATTERY LEVEL
- FRAMING OUTLINE

4 Save changes.


Press **DISP/BACK** to save changes.

5 Exit the menus.

Press **DISP/BACK** as needed to exit the menus and return to the shooting display.

Virtual Horizon

Selecting **ELECTRONIC LEVEL** displays a virtual horizon. The camera is level when the two lines overlap. Note that the virtual horizon may not be displayed if the camera lens is pointed up or down. For a 3D display (shown), press the function button to which **ELECTRONIC LEVEL** is assigned (📖 174, 198).




Framing Outline


Enable **FRAMING OUTLINE** to make the borders of the frame easier to see against dark backgrounds.

Histograms

Histograms show the distribution of tones in the image. Brightness is shown by the horizontal axis, the number of pixels by the vertical axis.




- **Optimal exposure:** Pixels are distributed in an even curve throughout the tone range.
- **Overexposed:** Pixels are clustered on the right side of the graph.
- **Underexposed:** Pixels are clustered on the left side of the graph.




To view separate RGB histograms and a display showing areas of the frame that will be overexposed at current settings superimposed on the view through the lens, press the function button to which **HISTOGRAM** is assigned (📖 174, 198).

- ① Overexposed areas blink
- ② RGB histograms




Using the Menus

To display the menu, press **MENU/OK**.




To navigate the menus:

- 1 Press **MENU/OK** to display the menus.



- 2 Press the focus stick (focus lever) left to highlight the tab for the current menu.



Tab

- 3 Press the focus stick up or down to highlight the tab (**IQ**, **AF/MF**, **Ⓜ**, **⚡**, **Ⓜ**, **MY**, **Ⓜ** or **Ⓜ**) containing the desired item.
- 4 Press the focus stick right to place the cursor in the menu.




- Use the front command dial to select menu tabs or page through menus and the rear command dial to highlight menu items.
- The focus stick (focus lever) does not tilt diagonally.

Touch Screen Mode

The LCD monitor also functions as a touch screen.

Shooting Touch Controls

To enable touch controls, select **ON** for **■** **BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > TOUCH SCREEN ON/OFF**.








EVF

The LCD monitor can be used to select the focus area while pictures are being framed in the electronic viewfinder (EVF). Use **■** **BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > EVF TOUCH SCREEN AREA SETTINGS** to choose the area of the monitor employed for touch controls.



LCD Monitor

Touch controls can be used to choose the focus area. The operation performed can be selected by tapping the touch screen mode indicator in the display to cycle through the following options.



| Mode | Description |
|--|--|
|  AF  AF OFF | <ul style="list-style-type: none"> In focus mode S (AF-S), the camera focuses when you tap your subject in the display. Focus locks at the current distance until you tap the AF OFF icon. In focus mode C (AF-C), the camera initiates focus when you tap your subject in the display. The camera will continue to adjust focus for changes in the distance to the subject until you tap the AF OFF icon. In manual focus mode (MF), you can tap the display to focus on the selected subject using autofocus. |
|  AREA | Tap to select a point for focus or zoom. The focus frame will move to the selected point. |
|  OFF | Touch focus disabled. |


⚠ Different touch controls are used during focus zoom (110).


- To disable touch controls and hide the touch screen mode indicator, select **OFF** for  **BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > TOUCH SCREEN ON/OFF**.
- Touch control settings can be adjusted using  **AF/MF SETTING > TOUCH SCREEN MODE**.


Touch Function

Functions can be assigned to the following flick gestures in much the same way as function buttons (196):

- Flick up: **T-Fn1**
- Flick left: **T-Fn2**
- Flick right: **T-Fn3**
- Flick down: **T-Fn4**



 In some cases, touch-function flick gestures display a menu; tap to select the desired option.



Playback Touch Controls

When **ON** is selected for **▶ BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > TOUCH SCREEN ON/OFF**, touch controls can be used for the following playback operations:

- **Swipe:** Swipe a finger across the display to view other images.



- **Pinch-out:** Place two fingers on the display and spread them apart to zoom in.



- **Pinch-in:** Place two fingers on the display and slide them together to zoom out.




Pictures can be zoomed out until the entire image is visible but no further.

- **Double-tap:** Tap the display twice to zoom in on the focus point.



- **Drag:** View other areas of the image during playback zoom.



First Steps


2

Attaching the Strap

Attach the strap clips to the camera and then attach the strap.

1 Attach a protective cover.


Place a protective cover over the eye-let as shown, with the black side of the cover toward the camera.



Protective cover


2 Open a strap clip.

Use the clip attaching tool (A) to open a strap clip (B).




3 Slide the clip onto the tool.



Slide the clip onto the tool so that it hooks over the projection.




4 Place the strap clip on an eyelet.

Hook the strap eyelet in the clip opening. Remove the tool, using the other hand to keep the clip in place.


 Keep the tool in a safe place, as you will need it to open the strap clips when removing the strap.


**5 Pass the clip through the eyelet.**

Rotate the clip fully through the eyelet until it clicks closed.


**6 Fasten the strap.**

Insert the strap through a protective cover and strap clip and fasten the buckle as shown.

 To avoid dropping the camera, be sure the strap is correctly secured.



Strap clip




Buckle

Repeat the above steps for the second eyelet.

Attaching a Lens

The camera can be used with lenses for the FUJIFILM G-mount.

Remove the body cap from the camera and the rear cap from the lens. Place the lens on mount, keeping the marks on the lens and camera aligned (①), and then rotate the lens until it clicks into place (②).




- ❗ When attaching lenses, ensure that dust or other foreign matter does not enter the camera.
- Be careful not to touch the camera's internal parts.
- Rotate the lens until it clicks securely into place.
- Do not press the lens release button while attaching the lens.

Removing Lenses

To remove the lens, turn the camera off, then press the lens release button (①) and rotate the lens as shown (②).

- ❗ To prevent dust accumulating on the lens or inside the camera, replace the lens caps and camera body cap when the lens is not attached.



Lenses and Other Optional Accessories

The camera can be used with lenses and accessories for the FUJIFILM G-mount.

- ❗ Observe the following precautions when attaching or removing (exchanging) lenses.
- Check that the lenses are free of dust and other foreign matter.
- Do not change lenses in direct sunlight or under another bright light source. Light focused into the interior of the camera could cause it to malfunction.
- Attach the lens caps before exchanging lenses.
- See the manual provided with the lens for information on use.

Charging the Battery

The battery is not charged at shipment. Before use, charge the battery in the supplied battery charger.


- ! An NP-T125 rechargeable battery is supplied with the camera.
- Charging takes about 140 minutes.

1 Connect the plug adapter.

- ! The plug adapter supplied with the camera varies with the country or region of purchase; use the adapter appropriate to your country or region as described in the enclosed notice.


2 Place the battery in the charger.

Insert the battery in the orientation shown by the arrow.



3 Plug the charger in.

Plug the charger into an indoor power outlet. The charging indicator will light.



4 Charge the battery.

Remove the battery when charging is complete.

The Charging Indicator

The charging indicator shows battery charge status as follows:




| Charging indicator | Battery status | Action |
|--------------------|------------------------|--|
| Off | Battery not inserted. | Insert the battery. |
| | Battery fully charged. | Remove the battery. |
| On | Battery charging. | — |
| Blinks | Battery fault. | Unplug the charger and remove the battery. |






- The supplied charger is compatible with power supplies of 100 to 240 volts (a plug adapter may be needed for overseas use).
- Do not affix labels or other objects to the battery. Failure to observe this precaution could make it impossible to remove the battery from the camera.
- Do not short the battery terminals. The battery could overheat.
- Read the cautions in "The Battery and Power Supply".
- Use only battery chargers designated for use with the battery. Failure to observe this precaution could result in product malfunction.
- Do not remove the labels from the battery or attempt to split or peel the outer casing.
- The battery gradually loses its charge when not in use. Charge the battery one or two days before use.
- If the battery fails to hold a charge, it has reached the end of its charging life and must be replaced.
- Unplug the charger when it is not in use.
- Remove dirt from the battery terminals with a clean, dry cloth. Failure to observe this precaution could prevent the battery from charging.
- Note that charging times increase at low or high temperatures.

Charging via AC Adapter

The battery inserted in the camera will also charge when the camera is powered by an optional AC-15V AC adapter. Charging takes about 120 minutes.



Battery charge status is shown by battery status icons when the camera is on (playback mode) and by the indicator lamp when the camera is off.


| Battery status icon (camera on) | Indicator lamp (camera off) | Battery status |
|--|-----------------------------|-------------------|
|  (yellow) | On | Battery charging |
|  (green) | Off | Charging complete |
|  (red) | Blinks | Battery fault |

Inserting the Battery


After charging the battery, insert the battery in the camera as described below.

1 Open the battery-chamber cover.

Slide the battery-chamber latch as shown and open the battery-chamber cover.




- Do not open the battery-chamber cover when the camera is on. Failure to observe this precaution could damage image files or memory cards.
- Do not use excessive force when handling the battery-chamber cover.



2 Insert the battery as shown.


- Insert the battery in the orientation shown. *Do not use force or attempt to insert the battery upside down or backwards.*
- Confirm that the battery is securely latched.



3 Close the battery-chamber cover.

Close and latch the cover.


❗ If the cover does not close, check that the battery is in the correct orientation. Do not attempt to force the cover shut.



Removing the Battery

Before removing the battery, *turn the camera off* and open the battery-chamber cover.

To remove the battery, press the battery latch to the side, and slide the battery out of the camera as shown.



❗ The battery may become hot when used in high-temperature environments. Observe caution when removing the battery.

Inserting Memory Cards


Pictures are stored on memory cards (sold separately).



The camera can be used with two cards, one in each of its two slots.

1 Open the memory card slot cover.


Unlatch and open the cover.



Do not open the memory card-slot cover when the camera is on. Failure to observe this precaution could damage image files or memory cards.

2 Insert the memory card.

Holding the card in the orientation shown, slide it in until it clicks into place at the back of the slot. Close and latch the memory card slot cover.



Be sure card is in the correct orientation; do not insert at an angle or use force.

3 Format the memory card (📖 156).




Format memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device.

Removing Memory Cards

Before removing memory cards, *turn the camera off* and open the memory card slot cover.

Press and release the card to eject it part way (to prevent the card falling from the slot, press the center of the card and release it slowly, without removing your finger from the card). The card can then be removed by hand.



Using Two Cards

The camera can be used with two cards, one in each of its two slots. At default settings, photos are saved to the card in the second slot only when the card in the first slot is full. This can be changed using **SAVE DATA SET-UP > CARD SLOT SETTING (STILL IMAGE)**.

| Option | Description | Display |
|--------------------------------|---|---------|
| SEQUENTIAL (default) | The card in the second slot is used only when the card in the first slot is full. If the second slot is selected for SAVE DATA SET-UP > SWITCH SLOT (SEQUENTIAL) , recording will start on the card in the second slot and switch to the first slot when the card in the second slot is full. | |
| BACKUP | Each picture is recorded twice, once to each card. | |
| RAW / JPEG | As for SEQUENTIAL , except that the RAW copy of pictures taken with FINE+RAW or NORMAL+RAW selected for IMAGE QUALITY SETTING > IMAGE QUALITY will be saved to the card in the first slot and the JPEG copy to the card in the second slot. | |

The card used to store movies can be selected using **SAVE DATA SET-UP > MOVIE FILE DESTINATION**.

Compatible Memory Cards

- Fujifilm and SanDisk SD, SDHC, and SDXC memory cards have been approved for use in the camera.
- UHS-II cards are recommended for use in this camera.
- Use a UHS Speed Class 1 or better memory card when recording movies.
- A list of supported memory cards is available on the Fujifilm website. For details, visit:

http://www.fujifilm.com/support/digital_cameras/compatibility/.

- ❗ *Do not turn the camera off or remove the memory card while the memory card is being formatted or data are being recorded to or deleted from the card. Failure to observe this precaution could damage the card.*

- Memory cards can be locked, making it impossible to format the card or to record or delete images. Before inserting a memory card, slide the write-protect switch to the unlocked position.





- Memory cards are small and can be swallowed; keep out of reach of children. If a child swallows a memory card, seek medical assistance immediately.
- miniSD or microSD adapters that are larger or smaller than memory cards may not eject normally; if the card does not eject, take the camera to an authorized service representative. Do not forcibly remove the card.
- Do not affix labels or other objects to memory cards. Peeling labels can cause camera malfunction.
- Movie recording may be interrupted with some types of memory card.
- Formatting a memory card in the camera creates a folder in which pictures are stored. Do not rename or delete this folder or use a computer or other device to edit, delete, or rename image files. Always use the camera to delete pictures; before editing or renaming files, copy them to a computer and edit or rename the copies, not the originals. Renaming the files on the camera can cause problems during playback.



Turning the Camera On and Off

Use the **ON/OFF** switch to turn the camera on and off.

Slide the switch to **ON** to turn the camera on, or to **OFF** to turn the camera off.










 Fingerprints and other marks on the lens or viewfinder can affect pictures or the view through the viewfinder. Keep the lens and viewfinder clean.


-  • Press the  button to start playback.
- Press the shutter button halfway to return to shooting mode.
 - The camera will turn off automatically if no operations are performed for the length of time selected for **POWER MANAGEMENT > AUTO POWER OFF**. To reactivate the camera after it has turned off automatically, press the shutter button halfway or turn the **ON/OFF** switch to **OFF** and then back to **ON**.

Checking the Battery Level

After turning the camera on, check the battery level in the display.

Battery level is shown as follows:

| Indicator | Description |
|---|--|
|  | Battery partially discharged. |
|  | Battery about 80% full. |
|  | Battery about 60% full. |
|  | Battery about 40% full. |
|  | Battery about 20% full. |
|  (red) | Low battery. Charge as soon as possible. |
|  (blinks red) | Battery exhausted. Turn camera off and recharge battery. |



Basic Setup


When you turn the camera on for the first time, you can choose a language and set the camera clock. At default settings, you can also pair the camera with a smartphone or tablet so that you can later synchronize the clocks or download pictures. Follow the steps below when turning the camera on for the first time.



If you intend to pair the camera with a smartphone or tablet, install and launch the latest version of the FUJIFILM Camera Remote App on the smart device before proceeding. For more information, visit: http://app.fujifilm-dsc.com/en/camera_remote/


1 Turn the camera on.

A language-selection dialog will be displayed.



2 Choose a language.

Highlight a language and press **MENU/OK**.




3 Pair the camera with the smartphone or tablet.

Press **MENU/OK** to pair the camera with a smartphone or tablet running the FUJIFILM Camera Remote app.





To skip pairing, press **DISP/BACK**.




4 Check the time.

When pairing is complete, you will be prompted to set the camera clock to the time reported by the smartphone or tablet. Check that the time is correct.



 To set the clock manually, press **DISP/BACK** (📖 41).


5 Synchronize the camera settings with the settings configured on your smartphone or tablet.



 The option selected can be changed at any time using **CONNECTION SETTING > Bluetooth SETTINGS**.

6 Set the clock.

Press **MENU/OK** to set the camera clock to the time reported by the smartphone or tablet and exit to shooting mode.



 If the battery is removed for an extended period, the camera clock will be reset and the language-selection dialog will be displayed when the camera is turned on.

Skipping the Current Step

If you skip a step, a confirmation dialog will be displayed; select **NO** to avoid repeating any steps you skipped the next time the camera is turned on.


Choosing a Different Language

To change the language:

- 1 **Display language options.**
Select  **USER SETTING** >  **言語/LANG..**
- 2 **Choose a language.**
Highlight the desired option and press **MENU/OK**.

Changing the Time and Date

To set the camera clock:

- 1 **Display DATE/TIME options.**
Select  **USER SETTING** > **DATE/TIME**.
- 2 **Set the clock.**
Press the focus stick (focus lever) left or right to highlight the year, month, day, hour, or minute and press up or down to change. Press **MENU/OK** to set the clock.

[illegible]


Basic Photography and Playback

3


Taking Photographs (Mode P)

This section describes how to take pictures using program AE (mode P). See pages 56–63 for information on S, A, and M modes.

1 Adjust settings for program AE.




| | Setting | |
|-----------------|---------------|----|
| ① Aperture | A (auto) | 56 |
| ② Shutter speed | A (auto) | 56 |
| ③ Focus mode | S (single AF) | 65 |

 To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.

2 Check the shooting mode.

Confirm that P appears in the display.




3 Ready the camera.

- Hold the camera steady with both hands and brace your elbows against your sides. Shaking or unsteady hands can blur your shots.




- To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the lens and AF-assist illuminator.



4 Frame the picture.


Lenses with Zoom Rings

Use the zoom ring to frame the picture in the display. Rotate the ring left to zoom out, right to zoom in.



5 Focus.

Press the shutter button halfway to focus.



Focus indicator

Focus frame

- **If the camera is able to focus**, it will beep twice and focus frame and focus indicator will glow green.
- **If the camera is unable to focus**, the focus frame will turn red, **!AF** will be displayed, and the focus indicator will blink white.



- If the subject is poorly lit, the AF-assist illuminator may light to assist the focus operation.
- Focus and exposure will lock when the shutter button is pressed halfway. Focus and exposure remain locked while the button is kept in this position (AF/AE lock).
- The camera will focus on subjects at any distance in the macro and standard focus ranges.

6 Shoot.


Smoothly press the shutter button the rest of the way down to take the picture.



Viewing Pictures

Pictures can be viewed in the viewfinder or LCD monitor.

To view pictures full frame, press



Additional pictures can be viewed by pressing the focus stick (focus lever) left or right or rotating the front command dial. Press the focus stick or rotate the dial right to view pictures in the order recorded, left to view pictures in reverse order. Keep the focus stick pressed to scroll rapidly to the desired frame.




Pictures taken using other cameras are marked with a ("gift image") icon to warn that they may not display correctly and that playback zoom may not be available.

Two Memory Cards

If two memory cards are inserted, you can press and hold the button to choose a card for playback. You can also select a card using the **PLAY** **BACK MENU** > **SWITCH SLOT** option.





Deleting Pictures

Use the  button to delete pictures.




Deleted pictures cannot be recovered. Protect important pictures or copy them to a computer or other storage device before proceeding.

- 1 With a picture displayed full frame, press the  button and select **FRAME**.



- 2 Press the focus stick (focus lever) left or right to scroll through pictures and press **MENU/OK** to delete (a confirmation dialog is not displayed). Repeat to delete additional pictures.



- Protected pictures cannot be deleted. Remove protection from any pictures you wish to delete (📖 142).
- Pictures can also be deleted from the menus using the  **PLAY BACK MENU > ERASE** option (📖 138).

Movie Recording and Playback


4



Recording Movies

This section describes how to film movies in auto mode.

- 1 Press the drive button and select **MOVIE**.
- 2 Adjust settings for program AE.




| Setting | | |
|-----------------|---------------|----|
| ① Aperture | A (auto) | 56 |
| ② Shutter speed | A (auto) | 56 |
| ③ Focus mode | S (single AF) | 65 |



To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.

- 3 Press the shutter button to start recording. A recording indicator (●) and the time remaining are displayed while recording is in progress.




4 Press the button again to end recording. Recording ends automatically when the maximum length is reached or the memory card is full.

- ❗ Sound is recorded via the built-in microphone or an optional external microphone. Do not cover the microphone during recording.
- Note that the microphone may pick up lens noise and other sounds made by the camera during recording.
- Vertical or horizontal streaks may appear in movies containing very bright subjects. This is normal and does not indicate a malfunction.

- 📺 The indicator lamp lights while recording is in progress.
- Zoom can be adjusted using the zoom ring on the lens (if available).
- If the lens is equipped with an aperture ring, select the aperture mode before beginning recording. If an option other than **A** is selected, shutter speed and aperture can be adjusted while recording is in progress.
- During recording, you can change exposure compensation by up to ± 2 EV.
- Recording may be unavailable at some settings, while in other cases settings may not apply during recording.

Using an External Microphone

Sound can be recorded with external microphones that connect using jacks 2.5 mm in diameter; microphones that require plug-in power cannot be used. See the microphone manual for details.



- 📺 The dialog shown at right will be displayed when a microphone is connected to the microphone/remote release connector. Press **MENU/OK** and select **MIC/REMOTE RELEASE > 🎤 MIC**.

CHECK MIC/REMOTE RELEASE
SETTING
OK SET **BACK** SKIP

Adjusting Movie Settings


- Frame size and rate can be selected using **MOVIE SETTING > MOVIE MODE**.
- To choose the card used to store movies, use **SAVE DATA SET-UP > MOVIE FILE DESTINATION**.
- Focus mode is selected using the focus mode selector; for continuous focus adjustment, select **C**, or choose **S** and enable Intelligent Face Detection. Intelligent Face Detection is not available in focus mode **M**.

Depth of Field

Choose low f-numbers to soften background details.


Viewing Movies

View movies on the camera.

In full-frame playback, movies are identified by a  icon. Press the focus stick (focus lever) down to start movie playback.





The following operations can be performed while a movie is displayed:




| Focus stick (focus lever) | Full-frame playback | Playback in progress (▶) | Playback paused (⏸) |
|------------------------------|---------------------|-----------------------------|---------------------------------|
| Up | — | End playback | |
| Down | Start playback | Pause playback | Start/resume playback |
| Left/right | View other pictures | Adjust speed | Single frame rewind/ advance |

Progress is shown in the display during playback.


 Do not cover the speaker during playback.



 Press **MENU/OK** to pause playback and display volume controls. Press the focus stick (focus lever) up or down to adjust the volume; press **MENU/OK** again to resume playback. Volume can also be adjusted using **⏮ SOUND SET-UP > PLAYBACK VOLUME**.

Playback Speed

Press the focus stick (focus lever) left or right to adjust playback speed during playback. Speed is shown by the number of arrows (▶ or ◀).



Arrows

5


Taking Photographs

P, S, A, and M Modes

P, S, A, and M modes give you varying degrees of control over shutter speed and aperture.

Mode P: Program AE


Let the camera choose shutter speed and aperture for optimal exposure. Other values that produce the same exposure can be selected with program shift.



Setting

| | |
|-----------------|----------|
| ① Shutter speed | A (auto) |
| ② Aperture | A (auto) |

Confirm that **P** appears in the display.




❗ If the subject is outside the metering range of the camera, the shutter speed and aperture displays will show "— — —".

🔧 To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.

Program Shift

If desired, you can rotate the rear command dial to select other combinations of shutter speed and aperture without altering exposure (program shift).



Program shift is not available in any of the following circumstances:


- With flash units that support TTL auto
- When an auto option is selected for **IMAGE QUALITY SETTING > DYNAMIC RANGE**
- In movie mode



To cancel program shift, turn the camera off.


Mode S: Shutter-Priority AE

Choose a shutter speed and let the camera adjust aperture for optimal exposure.



| Setting | |
|------------------------|---------------|
| ① Shutter speed | User-selected |
| ② Aperture | A (auto) |

Confirm that **S** appears in the display.




- ❗ If the correct exposure cannot be achieved at the selected shutter speed, aperture will be displayed in red.
- If the subject is outside the metering range of the camera, the aperture display will show "— — —".

- 🔧 To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.
- Shutter speed can also be adjusted in increments of $\frac{1}{3}$ EV by rotating the rear command dial.
- Shutter speed can be adjusted while the shutter button is pressed halfway.


Time (T)

Rotate the shutter speed dial to **T** (time) to choose slow shutter speeds for long time-exposures. Use of a tripod is recommended to prevent the camera moving during the exposure.

- 1 Rotate the shutter speed dial to **T**.



- 2 Rotate the rear command dial to choose a shutter speed.



- 3 Press the shutter button all the way down to take a picture at the selected shutter speed. At speeds of 1 s or slower, a count-down timer will be displayed while the exposure is in progress.




To reduce “noise” (mottling) in long time-exposures, select **ON** for **IMAGE QUALITY SETTING > LONG EXPOSURE NR.** Note that this may increase the time needed to record images after shooting.

Bulb (B)

Select a shutter speed of **B** (bulb) for long time-exposures in which you open and close the shutter manually. Use of a tripod is recommended to prevent the camera moving during the exposure.

- 1 Rotate the shutter speed dial to **B**.




- 2 Press the shutter button all the way down. The shutter will remain open for up to 60 minutes while the shutter button is pressed; the display shows the time elapsed since the exposure started.



- Selecting an aperture of **A** fixes shutter speed at 30 s.
- To reduce “noise” (mottling) in long time-exposures, select **ON** for **IMAGE QUALITY SETTING > LONG EXPOSURE NR.** Note that this may increase the time needed to record images after shooting.


Using a Remote Release

A remote release can be used for long time-exposures. When using an optional RR-100 remote release or an electronic release from third-party suppliers, connect it to microphone/remote release connector.




Mode A: Aperture-Priority AE

Choose an aperture and let the camera adjust shutter speed for optimal exposure.



| Setting | |
|-----------------|---------------|
| ① Shutter speed | A (auto) |
| ② Aperture | User-selected |


Confirm that **A** appears in the display.




- If the correct exposure cannot be achieved at the selected aperture, shutter speed will be displayed in red.
- If the subject is outside the metering range of the camera, the shutter speed display will show “— —”.

- To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.
- Rotate the lens aperture ring to adjust aperture.
- Aperture can be adjusted even while the shutter button is pressed halfway.


Previewing Depth of Field

When **PREVIEW DEPTH OF FIELD** is assigned to a function button, pressing the button displays a  icon and stops aperture down to the selected setting, allowing depth of field to be previewed in the display.




Mode M: Manual Exposure

In manual mode, the user controls both shutter speed and aperture. Shots can be deliberately overexposed (brighter) or underexposed (darker), opening the door for a variety of individual creative expression. The amount the picture would be under- or over-exposed at current settings is shown by the exposure indicator; adjust shutter speed and aperture until the desired exposure is reached.



| Setting | |
|-----------------|---------------|
| ① Shutter speed | User-selected |
| ② Aperture | User-selected |

Confirm that M appears in the display.



- To use the shutter speed dial, press the dial lock release and rotate the dial to the desired setting.
- Rotate the lens aperture ring to adjust aperture.
- Shutter speed can be adjusted in increments of $\frac{1}{3}$ EV by rotating the rear command dial.

Exposure Preview

To preview exposure in the LCD monitor, select an option other than **OFF** for  **SCREEN SET-UP > PREVIEW EXP./WB IN MANUAL MODE.**




Select **OFF** when using the flash or on other occasions on which exposure may change when the picture is taken.

Autofocus


Take pictures using autofocus.

- 1 Rotate the focus mode selector to **S** or **C** (📖 65).



- 2 Choose an AF mode (📖 67).

- 3 Choose the position and size of the focus frame (📖 69).




- 4 Take pictures.



For information on the autofocus system, visit:
<http://fujifilm-x.com/af/en/index.html>

Focus Mode

Use the focus mode selector to choose how the camera focuses.



Choose from the following options:

| Mode | Description |
|----------------------|--|
| S (AF-S) | Single AF: Focus locks while the shutter button is pressed halfway. Choose for stationary subjects. |
| C (AF-C) | Continuous AF: Focus is continually adjusted to reflect changes in the distance to the subject while the shutter button is pressed halfway. Use for subjects that are in motion. Eye-detection AF is not available. |
| M (manual) | Manual: Focus manually using the lens focus ring. Choose for manual control of focus or in situations in which the camera is unable to focus using autofocus (📖 72). |




- Regardless of the option selected, manual focus will be used when the lens is in manual focus mode.
- If **ON** is selected for **AF/MF SETTING > PRE-AF**, focus will be adjusted continuously in modes **S** and **C** even when the shutter button is not pressed.

The Focus Indicator

Focus status is shown by the focus indicator.

| Focus indicator | Focus status |
|--------------------|---|
| () | Camera focusing. |
| ● (lights green) | Subject in focus; focus locked (focus mode S). |
| ● (lights green) | Subject in focus (focus mode C). |
| (●) (lights green) | Focus is automatically adjusted for changes in distance to subject. |
| ○ (blinks white) | Camera unable to focus. |
| MF | Manual focus (focus mode M). |




Focus indicator

Autofocus Options (AF Mode)

Choose how the camera focuses in modes **S** and **C**.

- 1 Press a function button (by default, **Fn5**) to display AF mode options.









- 2 Choose an AF mode.

- The **Fn5** button can be assigned other roles using **■ BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING**. The role described above can also be assigned to other function buttons (198).
- AF mode can also be selected using **AF/MF SETTING > AF MODE**.







How the camera focuses depends on the focus mode.

Focus Mode **S** (AF-S)

| Option | Description | Sample image |
|--|---|---|
|  SINGLE POINT | Camera focuses on subject in selected focus point. Use for pin-point focus on selected subject. |  |
|  ZONE | Camera focuses on subject in selected focus zone. Focus zones include multiple focus points, making it easier to focus on subjects in motion. |  |

| Option | Description | Sample image |
|---|---|---|
|  WIDE/TRACKING | Camera focuses automatically on high-contrast subjects; display shows areas in focus. |  |

Focus Mode C (AF-C)


| Option | Description | Sample image |
|--|---|--|
|  SINGLE POINT | Focus tracks subject at selected focus point. Use for subjects moving toward or away from camera. |  |
|  ZONE | Focus tracks subject in selected focus zone. Use for subjects that are moving fairly predictably. |  |
|  WIDE/TRACKING | Focus tracks subjects moving through wide area of frame. |  |

Focus-Point Selection

Choose a focus point for autofocus.


Viewing the Focus-Point Display








- 1 Press **MENU/OK** and go to the shooting menu.
- 2 Select **AF/MF SETTING > FOCUS AREA** to view the focus-point display.
- 3 Use the focus stick (focus lever) and rear command dial to choose a focus area.


 The focus point can also be selected using touch controls (21).

Selecting a Focus Point

Use the focus stick (focus lever) to choose the focus point and the rear command dial to choose the size of the focus frame. The procedure varies with the option selected for AF mode.










| AF mode | Focus stick | | Rear command dial | |
|---|---|--|---|--|
| |  Tilt |  Press |  Rotate |  Press |
|  | Select focus point | Select center focus point | Choose from 6 frame sizes | Restore original size |
|  | | | Choose from 3 frame sizes | |
|  | | | — | |

 Manual focus-point selection is not available when **WIDE/TRACKING** is selected in focus mode **S**.

The Focus-Point Display

The focus-point display varies with the option selected for AF mode.

 Focus frames are shown by small squares (□), focus zones by the large squares.

| AF mode | | |
|--|--|---|
|  SINGLE POINT |  ZONE |  WIDE/TRACKING |
|  |  |  |
| Number of points available can be selected using AF/MF SETTING > NUMBER OF FOCUS POINTS. | Choose from zones with 7×7 , 5×5 , or 3×3 focus points. | Position focus frame over subject you want to track. |


Autofocus

Although the camera boasts a high-precision autofocus system, it may be unable to focus on the subjects listed below.

- Very shiny subjects such as mirrors or car bodies.
- Subjects photographed through a window or other reflective object.
- Dark subjects and subjects that absorb rather than reflect light, such as hair or fur.
- Insubstantial subjects, such as smoke or flame.
- Subjects that show little contrast with the background.
- Subjects positioned in front of or behind a high-contrast object that is also in the focus frame (for example, a subject photographed against a backdrop of highly contrasting elements).

Checking Focus

To zoom in on the current focus area for precise focus, press the center of the rear command dial. Use the focus stick (focus lever) to choose another focus area. Press the center of the rear command dial again to cancel zoom.






Normal display



Focus zoom




- In focus mode **S**, zoom can be adjusted by rotating the rear command dial.
- The focus stick can be used to select the focus area while zoom is in effect.
- In focus mode **S**, select  **SINGLE POINT** for **AF MODE**.
- Focus zoom is not available in focus mode **C** or when  **AF/MF SETTING > PRE-AF** is on.
- Use  **BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING** to change the function performed by the center of the rear command dial. You can also assign its default function to other controls (📖 198).

Manual Focus

Adjust focus manually.


- 1 Rotate the focus mode selector to M.



MF will appear in the display.



- 2 Focus manually using the lens focus ring. Rotate the ring left to reduce the focus distance, right to increase.




- 3 Take pictures.



- Use **FUNCTION/DIAL SETTING > FOCUS RING** to reverse the direction of rotation of the focus ring.
- Regardless of the option selected, manual focus will be used when the lens is in manual focus mode.

Quick Focus

- To use autofocus to focus on the subject in the selected focus area, press the button to which focus lock or **AF-ON** has been assigned (the size of the focus area can be chosen with the rear command dial).
- In manual focus mode, you can use this feature to quickly focus on a chosen subject using either single or continuous AF according to the option chosen for  **AF/MF SETTING > INSTANT AF SETTING**.

Checking Focus

A variety of options are available for checking focus in manual focus mode.

The Manual Focus Indicator

The manual focus indicator indicates how closely the focus distance matches the distance to the subject in the focus brackets. The white line indicates the distance to the subject in the focus area (in meters or feet according to the option selected for **SCREEN SET-UP > FOCUS SCALE UNITS** in the setup menu), the blue bar the depth of field, or in other words the distance in front of and behind the subject that appears to be in focus.



Focus distance
(white line)



Depth of field

- If both **AF DISTANCE INDICATOR** and **MF DISTANCE INDICATOR** are selected in the **SCREEN SET-UP > DISP. CUSTOM SETTING** list, the manual focus indicator can also be viewed using the depth-of-field indicator in the standard display. Use the **DISP/BACK** button to display standard indicators.
- Use the **AF/MF SETTING > DEPTH-OF-FIELD SCALE** option to choose how depth of field is displayed. Choose **FILM FORMAT BASIS** to help you make practical assessments of depth of field for pictures that will be viewed as prints and the like, **PIXEL BASIS** to help you assess depth of field for pictures that will be viewed at high resolutions on computers or other electronic displays.

Focus Zoom

If **ON** is selected for **AF/MF SETTING > FOCUS CHECK**, the camera will automatically zoom in on the selected focus area when the focus ring is rotated. Press the center of the rear command dial to exit zoom.



- Use the focus stick (focus lever) to choose another focus area.
- Zoom can be adjusted by rotating the rear command dial.

Focus Peaking


Select **FOCUS PEAK HIGHLIGHT** for **AF/MF SETTING > MF ASSIST** to highlight high-contrast outlines. When focusing, rotate the focus ring until the subject is highlighted.



- The **MF ASSIST** menu can be displayed by pressing and holding the center of the rear command dial.

Adjust the camera's sensitivity to light.

Adjust ISO sensitivity using a function button (by default, **Fn1**).



| Option | Description |
|---|--|
| AUTO1 AUTO2 AUTO3 | Sensitivity is automatically adjusted in response to shooting conditions according to combination of standard and maximum sensitivity and minimum shutter speed chosen for SHOOTING SETTING > ISO . Choose from AUTO1 , AUTO2 , and AUTO3 (77). |
| 12800–100 | Adjust sensitivity manually. Selected value is shown in display. |
| H (102400/51200/25600), L (50) | Choose for special situations. Note that mottling may appear in pictures taken at H , while L reduces dynamic range. |

- The **Fn1** button can be assigned other roles using **BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING**. The role described above can also be assigned to other function buttons (198).
- ISO sensitivity can also be adjusted using **SHOOTING SETTING > ISO**.
- Sensitivity is not reset when the camera is turned off.
- If desired, you can use **BUTTON/DIAL SETTING > COMMAND DIAL SETTING** to configure the camera so that ISO sensitivity can be adjusted using the front or rear command dial.

Adjusting Sensitivity

High values can be used to reduce blur when lighting is poor, while lower values allow slower shutter speeds or wider apertures in bright light; note, however, that mottling may appear in pictures taken at high sensitivities.

AUTO

Choose the base sensitivity, maximum sensitivity, and minimum shutter speed for **AUTO1**, **AUTO2**, and **AUTO3**.

| Item | Options | Default | | |
|----------------------------|-------------------------------------|--------------------|-------|-------|
| | | AUTO1 | AUTO2 | AUTO3 |
| DEFAULT SENSITIVITY | 12800–100 | 100 | | |
| MAX. SENSITIVITY | 12800–200 | 800 | 1600 | 3200 |
| MIN. SHUTTER SPEED | $\frac{1}{500}$ – $\frac{1}{4}$ SEC | $\frac{1}{60}$ SEC | | |

The camera automatically chooses a sensitivity between the default and maximum values; sensitivity is only raised above the default value if the shutter speed required for optimal exposure would be slower than the value selected for **MIN. SHUTTER SPEED**.



- If the value selected for **DEFAULT SENSITIVITY** is higher than that selected for **MAX. SENSITIVITY**, **DEFAULT SENSITIVITY** will be set to the value selected for **MAX. SENSITIVITY**.
- The camera may select shutter speeds slower than **MIN. SHUTTER SPEED** if pictures would still be underexposed at the value selected for **MAX. SENSITIVITY**.







Metering

Choose how the camera meters exposure.

SHOOTING SETTING > PHOTOMETRY offers a choice of the following metering options:

! The selected option will only take effect when **AF/MF SETTING > FACE/EYE DETECTION SETTING** is **FACE OFF/EYE OFF**.


| Mode | Description |
|--|---|
|  (multi) | The camera instantly determines exposure based on an analysis of composition, color, and brightness distribution. Recommended in most situations. |
|  (center-weighted) | The camera meters the entire frame but assigns the greatest weight to the area at the center. |
|  (spot) | The camera meters lighting conditions in an area at the center of the frame equivalent to 2% of the total. Recommended with backlit subjects and in other cases in which the background is much brighter or darker than the main subject. |
|  (average) | Exposure is set to the average for the entire frame. Provides consistent exposure across multiple shots with the same lighting, and is particularly effective for landscapes and portraits of subjects dressed in black or white. |



Exposure Compensation

Adjust exposure.



Rotate the exposure compensation dial.



The amount of compensation available varies with the shooting mode.

C (Custom)

When the exposure compensation dial is rotated to **C**, you can adjust exposure compensation after pressing a function button (by default, **Fn2**). Rotate the front command dial to choose a value.




- The **Fn2** button can be assigned other roles using **■ BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING**. The role described above can also be assigned to other function buttons (198).
- The command dials can be used to set exposure compensation to values between -5 and $+5$ EV.
- Press the **Fn2** to toggle between aperture and exposure compensation.

Focus/Exposure Lock

Focus and exposure lock when the shutter button is pressed halfway.

- 1 Position the subject in the focus frame and press the shutter button halfway to lock focus and exposure. Focus and exposure will remain locked while the shutter button is pressed halfway (AF/AE lock).



- 2 Press the button all the way down.




Focus lock using the shutter button is only available when **ON** is selected for **■ BUTTON/DIAL SETTING > SHUTTER AF, SHUTTER AE**.


The AF-L and AE-L Buttons

Focus and exposure can also be locked using function buttons. At default settings, the **Fn3** button locks exposure, the **Fn4** button focus.



- While the assigned control is pressed, pressing the shutter button halfway will not end the lock.
- If **AE&AF ON/OFF SWITCH** is selected for **■ BUTTON/DIAL SETTING > AE/AF-LOCK MODE**, the lock can only be ended by pressing the control a second time.



Fn3 button
(exposure lock)



Fn4 button
(focus lock)


 The **Fn3** and **Fn4** buttons can be assigned other roles using **■ BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING**. Exposure and focus lock can also be assigned to other function buttons ( 198).


BKT Bracketing

Automatically vary settings over a series of pictures.

Press the drive button and choose from the options below.

AE BKT


Use  **SHOOTING SETTING** > **AE BKT SETTING** to choose the bracketing amount, bracketing order, and number of shots. Each time the shutter button is pressed, the camera will take the specified number of shots: one using the metered value for exposure and the others over- or under-exposed by multiples of the selected bracketing amount.

 Regardless of the bracketing amount, exposure will not exceed the limits of the exposure metering system.

ISO BKT

Select a bracketing amount ($\pm\frac{1}{3}$, $\pm\frac{2}{3}$, or ± 1) in the drive mode display. Each time the shutter is released, the camera will take a picture at the current sensitivity and process it to create two additional copies, one with sensitivity raised and the other with sensitivity lowered by the selected amount.

FILM SIMULATION BKT

Each time the shutter is released, the camera takes one shot and processes it to create copies with different film simulation settings, chosen using  **SHOOTING SETTING** > **FILM SIMULATION BKT**.

WB WHITE BALANCE BKT

Select a bracketing amount (± 1 , ± 2 , or ± 3) in the drive mode display. Each time the shutter is released, the camera takes one shot and processes it to create three copies: one at the current white balanced setting, one with fine-tuning increased by the selected amount, and another with fine-tuning decreased by the selected amount.

DR DYNAMIC RANGE BKT

Each time the shutter button is pressed, the camera takes three shots with different dynamic ranges: 100% for the first, 200% for the second, and 400% for the third.



While dynamic range bracketing is in effect, sensitivity will be restricted to a minimum of ISO 640; the sensitivity previously in effect is restored when bracketing ends.


FOCUS FOCUS BKT

Each time the shutter button is pressed, the camera takes a series of photos, varying focus with each shot. The number of shots, the amount focus changes with each shot, and the interval between shots can be selected using **SHOOTING SETTING > FOCUS BKT**.



Continuous Shooting (Burst Mode)


Capture motion in a series of pictures.

Press the drive button and select  **CONTINUOUS**. The camera will take pictures while the shutter button is pressed; shooting ends when the shutter button is released or the memory card is full.



- If file numbering reaches 999 before shooting is complete, the remaining pictures will be recorded to a new folder.
- Shooting ends when the memory card is full; the camera will record all photos shot to that point. Burst shooting may not begin if the space available on the memory card is insufficient.
- Frame rates may slow as more shots are taken.
- Frame rate varies with the scene, shutter speed, sensitivity, and focus mode.
- Depending on shooting conditions, frame rates may slow or the flash may not fire.
- Recording times may increase during burst shooting.

Exposure

To vary exposure with each shot, select **OFF** for  **BUTTON/DIAL SETTING > SHUTTER AE**.




- Depending on such factors as aperture, sensitivity, and exposure compensation, exposure may not be adjusted automatically.



Multiple Exposures

Create a photograph that combines two exposures.



1 Press the drive button and select  **MULTIPLE EXPOSURE**.

2 Take the first shot.

3 Press **MENU/OK**. The first shot will be shown superimposed on the view through the lens and you will be prompted to take the second shot.




- To return to Step 2 and retake the first shot, press the focus stick (focus lever) left.

- To save the first shot and exit without creating a multiple exposure, press **DISP/BACK**.



4 Take the second shot, using the first frame as a guide.



5 Press **MENU/OK** to create the multiple exposure, or press the focus stick left to return to Step 4 and retake the second shot.



Multiple exposures cannot be recorded via tethered shooting (187).

6


The Shooting Menus



IMAGE QUALITY SETTING

Adjust image quality settings.

To display image quality settings, press **MENU/OK** in the shooting display and select the **IQ** (IMAGE QUALITY SETTING) tab.



The options available vary with the shooting mode selected.

IMAGE SIZE

Choose the size and aspect ratio at which still pictures are recorded.

| Option | Image size | Option | Image size |
|----------------|-------------|----------------|-------------|
| L 4:3 | 8256 × 6192 | S 4:3 | 4000 × 3000 |
| L 3:2 | 8256 × 5504 | S 3:2 | 4000 × 2664 |
| L 16:9 | 8256 × 4640 | S 16:9 | 4000 × 2248 |
| L 1:1 | 6192 × 6192 | S 1:1 | 2992 × 2992 |
| L 65:24 | 8256 × 3048 | S 65:24 | 4000 × 1480 |
| L 5:4 | 7744 × 6192 | S 5:4 | 3744 × 3000 |
| L 7:6 | 7232 × 6192 | S 7:6 | 3504 × 3000 |



IMAGE SIZE is not reset when the camera is turned off or another shooting mode is selected.

IMAGE QUALITY

Choose a file format and compression ratio.

| Option | Description |
|-------------------------|---|
| SUPER FINE | Very low compression ratios are used for maximum image quality. |
| FINE | Low compression ratios are used for higher-quality images. |
| NORMAL | Higher compression ratios are used to increase the number of images that can be stored. |
| SUPER FINE + RAW | Record both RAW and super-fine quality JPEG pictures. |
| FINE + RAW | Record both RAW and fine-quality JPEG images. |
| NORMAL + RAW | Record both RAW and normal-quality JPEG images. |
| RAW | Record RAW images only. |

The Function Buttons

To toggle RAW image quality on or off for a single shot, assign **RAW** to a function button (📖 198). Press the button once to select the option in the right column, again to return to the original setting (left column).

| Option currently selected for IMAGE QUALITY | Option selected by pressing function button to which RAW is assigned |
|--|---|
| SUPER FINE | SUPER FINE + RAW |
| FINE | FINE + RAW |
| NORMAL | NORMAL + RAW |
| SUPER FINE + RAW | SUPER FINE |
| FINE + RAW | FINE |
| NORMAL + RAW | NORMAL |
| RAW | FINE |











RAW RECORDING

Choose whether to compress RAW images.


| Option | Description |
|--------------------------------|---|
| UNCOMPRESSED | RAW images are not compressed. |
| LOSSLESS COMPRESSED | RAW images are compressed using a reversible algorithm that reduces file size with no loss of image data. The images can be viewed in RAW FILE CONVERTER EX (📖 234), FUJIFILM X RAW STUDIO (📖 235), or other software that supports “lossless” RAW compression. |

FILM SIMULATION

Simulate the effects of different kinds of film, including black-and-white (with or without color filters). Choose a palette according to your subject and creative intent.

| Option | Description |
|---|---|
|  PROVIA/STANDARD | Standard color reproduction. Suited to a wide range of subjects, from portraits to landscapes. |
|  Velvia/VIVID | A high-contrast palette of saturated colors, suited to nature photos. |
|  ASTIA/SOFT | Enhances the range of hues available for skin tones in portraits while preserving the bright blues of daylight skies. Recommended for outdoor portrait photography. |
|  CLASSIC CHROME | Soft color and enhanced shadow contrast for a calm look. |
|  PRO Neg. Hi | Offers slightly more contrast than  PRO Neg. Std. Recommended for outdoor portrait photography. |
|  PRO Neg. Std | A soft-toned palette. The range of hues available for skin tones is enhanced, making this a good choice for studio portrait photography. |
|  ACROS* | Take black-and-white photos with rich gradation and outstanding sharpness. |
|  MONOCHROME* | Take pictures in standard black and white. |
|  SEPIA | Take pictures in sepia. |

* Available with yellow (**Ye**), red (**R**), and green (**G**) filters, which deepen shades of gray corresponding to hues complementary to the selected color. The yellow (**Ye**) filter deepens purples and blues and the red (**R**) filter blues and greens. The green (**G**) filter deepens reds and browns, including skin tones, making it a good choice for portraits.

-  Film simulation options can be combined with tone and sharpness settings.
- Film simulation settings can also be accessed via shortcuts (📖 192).
- For more information, visit: <http://fujifilm-x.com/en/x-stories/the-world-of-film-simulation-episode-1/>

GRAIN EFFECT


Add a film grain effect. Select an amount (**STRONG** or **WEAK**) or choose **OFF** to turn film grain off.

| Options | | |
|---------------|-------------|------------|
| STRONG | WEAK | OFF |

COLOR CHROME EFFECT

Deepen colors in shadows. Select an amount (**STRONG** or **WEAK**) or choose **OFF** to turn the effect off.

| Options | | |
|---------------|-------------|------------|
| STRONG | WEAK | OFF |

 **COLOR CHROME EFFECT** is not available during bracketing or burst photography.

DYNAMIC RANGE





Control contrast. Choose lower values to increase contrast when shooting indoors or under overcast skies, higher values to reduce loss of detail in highlights when photographing high-contrast scenes. Higher values are recommended for scenes that include both sunlight and deep shade, for such high-contrast subjects as sunlight on water, brightly-lit autumn leaves, and portraits taken against a blue sky, and for white objects or people wearing white.

| Options | | | |
|---------|--|--|--|
| AUTO |  100% |  200% |  400% |



Mottling may appear in pictures taken at higher values. Choose a value according to the scene.



- If **AUTO** is selected, the camera will automatically choose either  100% or  200% according to the subject and shooting conditions. Shutter speed and aperture will be displayed when the shutter button is pressed halfway.
-  200% is available at sensitivities of from ISO 200 to ISO 12800,  400% at sensitivities of from ISO 400 to 12800.

WHITE BALANCE


For natural colors, choose a white balance option that matches the light source.

| Option | Description |
|-------------|--|
| AUTO | White balance is adjusted automatically. |
| | Measure a value for white balance. |
| | Choose a color temperature. |
| | For subjects in direct sunlight. |
| | For subjects in the shade. |
| | Use under “daylight” fluorescent lights. |
| | Use under “warm white” fluorescent lights. |
| | Use under “cool white” fluorescent lights. |
| | Use under incandescent lighting. |
| | Reduces the blue cast typically associated with underwater lighting. |

- In conditions in which **AUTO** fails to produce the desired results—for example, under certain types of lighting or in close-ups of portrait subjects—use custom white balance or choose a white balance option suited to the light source.
- White balance is adjusted for flash lighting only in **AUTO** and modes. Turn the flash off using other white balance options.
- White balance options can also be accessed via shortcuts (192).

Fine-Tuning White Balance

Pressing **MENU/OK** after selecting a white balance option displays a fine-tuning dialog; use the focus stick (focus lever) to fine-tune white balance.




- To exit without fine-tuning white balance, press **DISP/BACK** after selecting a white balance option.
- The focus stick (focus lever) does not tilt diagonally.

Custom White Balance

Choose \square_1 , \square_2 , or \square_3 to adjust white balance for unusual lighting conditions. White balance measurement options will be displayed; frame a white object so that it fills the display and press the shutter button all the way down to measure white balance (to select the most recent custom value and exit without measuring white balance, press **DISP/BACK**, or press **MENU/OK** to select the most recent value and display the fine-tuning dialog).


- If **"COMPLETED!"** is displayed, press **MENU/OK** to set white balance to the measured value.



- If **"UNDER"** is displayed, raise exposure compensation and try again.
- If **"OVER"** is displayed, lower exposure compensation and try again.

K: Color Temperature

Selecting **K** in the white balance menu displays a list of color temperatures; highlight a color temperature and press **MENU/OK** to select the highlighted option and display the fine-tuning dialog.



Color Temperature

Color temperature is an objective measure of the color of a light source, expressed in Kelvin (K). Light sources with a color temperature close to that of direct sunlight appear white; light sources with a lower color temperature have a yellow or red cast, while those with a higher color temperature are tinged with blue. You can match color temperature to the light source, or choose options that differ sharply from the color of the light source to make pictures “warmer” or “colder.”

HIGHLIGHT TONE

Adjust the appearance of highlights.

| Options | | | | | | |
|---------|----|----|----|---|----|----|
| +4 | +3 | +2 | +1 | 0 | -1 | -2 |

SHADOW TONE

Adjust the appearance of shadows.

| Options | | | | | | |
|---------|----|----|----|---|----|----|
| +4 | +3 | +2 | +1 | 0 | -1 | -2 |

COLOR

Adjust color density.

| Options | | | | | | | | |
|---------|----|----|----|---|----|----|----|----|
| +4 | +3 | +2 | +1 | 0 | -1 | -2 | -3 | -4 |

SHARPNESS

Sharpen or soften outlines.

| Options | | | | | | | | |
|---------|----|----|----|---|----|----|----|----|
| +4 | +3 | +2 | +1 | 0 | -1 | -2 | -3 | -4 |

NOISE REDUCTION

Reduce noise in pictures taken at high sensitivities.

| Options | | | | | | | | |
|---------|----|----|----|---|----|----|----|----|
| +4 | +3 | +2 | +1 | 0 | -1 | -2 | -3 | -4 |

LONG EXPOSURE NR

Select **ON** to reduce mottling in long time-exposures.

| Options | |
|---------|-----|
| ON | OFF |

LENS MODULATION OPTIMIZER

Select **ON** to improve definition by adjusting for diffraction and the slight loss of focus at the periphery of the lens.

| Options | |
|---------|-----|
| ON | OFF |


COLOR SPACE

Choose the gamut of colors available for color reproduction.

| Option | Description |
|-----------|---------------------------------|
| sRGB | Recommended in most situations. |
| Adobe RGB | For commercial printing. |

PIXEL MAPPING

Use this option if you notice bright spots in your pictures.

- 1 Press **MENU/OK** in the shooting display and select the  **IMAGE QUALITY SETTING** tab.
- 2 Highlight **PIXEL MAPPING** and press **MENU/OK** to perform pixel mapping.



- Results are not guaranteed.
- Be sure the battery is fully charged before beginning pixel mapping.
- Pixel mapping is not available when the camera temperature is elevated.
- Processing may take a few seconds.

SELECT CUSTOM SETTING


Recall settings saved with **EDIT/SAVE CUSTOM SETTING**. Settings can be recalled from any of the seven custom settings banks.

| Banks | | | |
|----------|----------|----------|----------|
| CUSTOM 1 | CUSTOM 2 | CUSTOM 3 | CUSTOM 4 |
| CUSTOM 5 | CUSTOM 6 | CUSTOM 7 | |


EDIT/SAVE CUSTOM SETTING

Save up to 7 sets of custom camera settings for commonly-encountered situations. Saved settings can be recalled using **IMAGE QUALITY SETTING > SELECT CUSTOM SETTING**.


- 1 Press **MENU/OK** in shooting mode to display the shooting menu. Select the **IMAGE QUALITY SETTING** tab, then highlight **EDIT/SAVE CUSTOM SETTING** and press **MENU/OK**.
- 2 Highlight a custom settings bank and press **MENU/OK** to select.



- 3 Adjust the following as desired:
 - ISO
 - DYNAMIC RANGE
 - FILM SIMULATION
 - GRAIN EFFECT
 - COLOR CHROME EFFECT
 - WHITE BALANCE
 - HIGHLIGHT TONE
 - SHADOW TONE
 - COLOR
 - SHARPNESS
 - NOISE REDUCTION



- 4 Press **DISP/BACK**. A confirmation dialog will be displayed; highlight **OK** and press **MENU/OK**.




- To store current camera settings in the selected bank, highlight **SAVE CURRENT SETTINGS** in Step 3 and press **MENU/OK**.
- To restore default settings for the current bank, select **RESET**.
- Banks can be renamed using **EDIT CUSTOM NAME**.



AF/MF SETTING

Adjust focus settings.

To display focus settings, press **MENU/OK** in the shooting display and select the **AF/MF** (AF/MF SETTING) tab.







The options available vary with the shooting mode selected.

FOCUS AREA

Choose the focus area for autofocus, manual focus, and focus zoom.

AF MODE

Choose the AF mode for focus modes **S** and **C**.

| Option | Description |
|---|--|
|  SINGLE POINT | <p>The camera focuses on the subject in the selected focus point. The number of focus points available can be selected using  AF/MF SETTING > NUMBER OF FOCUS POINTS. Use for pin-point focus on a selected subject.</p> |
|  ZONE | <p>The camera focuses on the subject in the selected focus zone. Focus zones include multiple focus points, making it easier to focus on subjects that are in motion.</p> |
|  WIDE/TRACKING | <ul style="list-style-type: none"> • In focus mode S, the camera automatically focuses on high-contrast subjects; the areas in focus are shown in the display. • In focus mode C, the camera tracks focus on the subject in the selected focus point while the shutter button is pressed halfway. <p>The camera may be unable to focus on small objects or subjects that are moving rapidly.</p> |

STORE AF MODE BY ORIENTATION

Choose whether the focus mode and focus area used when the camera is in portrait orientation are stored separately from those used when the camera is in landscape orientation.


| Option | Description |
|-----------------|---|
| OFF | The same settings are used in both orientations. |
| FOCUS AREA ONLY | The focus area for each orientation can be selected separately. |
| ON | The focus mode and focus area can be selected separately. |

RAPID AF

Select **ON** for faster focus times. Display quality will drop while the camera focuses.

| Options | |
|---------|-----|
| ON | OFF |

AF POINT DISPLAY

Choose whether individual focus frames are displayed when **ZONE** or **WIDE/TRACKING** is selected for  **AF/MF SETTING** > **AF MODE**.

| Options | |
|---------|-----|
| ON | OFF |

NUMBER OF FOCUS POINTS


Choose the number of focus points available for focus-point selection in manual focus mode or when **SINGLE POINT** is selected for **AF MODE**.

| Option | Description |
|--------------------------------|--|
| 117 POINTS (9 × 13) | Choose from 117 focus points arranged in a 9- by 13-point grid. |
| 425 POINTS (17 × 25) | Choose from 425 focus points arranged in a 17- by 25-point grid. |

PRE-AF

If **ON** is selected, the camera will continue to adjust focus even when the shutter button is not pressed halfway. The camera adjusts focus continuously, allowing it to focus faster when the shutter button is pressed halfway. Choosing this option helps prevent missed shots.


| Options | |
|-----------|------------|
| ON | OFF |

 Choosing **ON** increases the drain on the battery.

AF ILLUMINATOR


If **ON** is selected, the AF-assist illuminator will light to assist autofocus.

| Options | |
|-----------|------------|
| ON | OFF |

-  • The camera may be unable to focus using the AF-assist illuminator in some cases.
- If the camera is unable to focus, try increasing the distance to the subject.
 - Avoid shining the AF-assist illuminator directly into your subject's eyes.

FACE/EYE DETECTION SETTING

Intelligent Face Detection sets focus and exposure for human faces anywhere in the frame, preventing the camera from focusing on the background in group portraits. Choose for shots that emphasize portrait subjects. You can also choose whether the camera detects and focuses on eyes when Intelligent Face Detection is on. Choose from the following options:





| Option | Description |
|-----------------------------------|--|
| FACE ON/EYE OFF | Intelligent Face Detection only. |
| FACE ON/EYE AUTO | The camera automatically chooses which eye to focus on when a face is detected. |
| FACE ON/RIGHT EYE PRIORITY | The camera focuses on the right eye of subjects detected using Intelligent Face Detection. |
| FACE ON/LEFT EYE PRIORITY | The camera focuses on the left eye of subjects detected using Intelligent Face Detection. |
| FACE OFF/EYE OFF | Intelligent Face Detection and eye priority off. |

- ❗ If the subject moves as the shutter button is pressed, the face may not be in the area indicated by the green border when the picture is taken.
- In some modes, the camera may set exposure for the frame as a whole rather than the portrait subject.


- 📁 The face selected by the camera is indicated by a green border.
- If there is more than one face in the frame, the camera will select the face closest to the center; other faces are indicated by white borders.
- Faces can be detected with the camera in vertical or horizontal orientation.
- If the camera is unable to detect the subject's eyes because they are hidden by hair, glasses, or other objects, the camera will instead focus on faces.
- Face/eye detection options can also be accessed via shortcuts (📖 192).

AF+MF

If **ON** is selected in focus mode **S** and focus has been locked (whether by pressing the shutter button halfway or by other means), focus lock can be ended and focus adjusted manually by rotating the focus ring.

| Options | |
|--|-----|
| ON | OFF |
| <p> • Lenses with a focus distance indicator must be set to manual focus mode (MF) before this option can be used. Selecting MF disables the focus distance indicator.</p> <p>• If the lens is equipped with a focus distance indicator, set the focus ring to the center, as the camera may fail to focus if the ring is set to infinity or the minimum focus distance.</p> <p> Focus peaking can be used to check focus. To enable focus peaking, select FOCUS PEAK HIGHLIGHT for MF ASSIST.</p> | |

AF + MF Focus Zoom

When **ON** is selected for  **AF/MF SETTING** > **FOCUS CHECK** and **SINGLE POINT** selected for **AF MODE**, focus zoom can be used to zoom in on the selected focus area. The zoom ratio can be selected using the rear command dial.

MF ASSIST

Choose how focus is displayed in manual focus mode.

| Option | Description |
|-----------------------------|--|
| STANDARD | Focus is displayed normally. |
| FOCUS PEAK HIGHLIGHT | The camera heightens high-contrast outlines. Choose a color and peaking level. |



You can also choose MF assist options by holding the center of the rear command dial.

FOCUS CHECK

If **ON** is selected, the display will automatically zoom in on the selected focus area when the focus ring is rotated in manual focus mode.

| Options | |
|---------|-----|
| ON | OFF |



- Pressing the center of the rear command dial cancels focus zoom.
- The zoom position is centered on the current focus area and changes when the focus area is changed.

INTERLOCK SPOT AE & FOCUS AREA

Select **ON** to meter the current focus frame when **SINGLE POINT** is selected for **AF MODE** and **SPOT** is selected for **PHOTOMETRY**.

| Options | |
|---------|-----|
| ON | OFF |

INSTANT AF SETTING

Choose whether the camera focuses using single AF (**AF-S**) or continuous AF (**AF-C**) when a button to which focus lock or **AF-ON** is assigned is pressed in manual focus mode.

| Options | |
|---------|------|
| AF-S | AF-C |

DEPTH-OF-FIELD SCALE

Choose **FILM FORMAT BASIS** to help you make practical assessments of depth of field for pictures that will be viewed as prints and the like, **PIXEL BASIS** to help you assess depth of field for pictures that will be viewed at high resolutions on computers or other electronic displays.

| Options | |
|--------------------|--------------------------|
| PIXEL BASIS | FILM FORMAT BASIS |

RELEASE/FOCUS PRIORITY





Choose how the camera focuses in focus mode **AF-S** or **AF-C**.

| Option | Description |
|----------------|---|
| RELEASE | Shutter response is prioritized over focus. Pictures can be taken when the camera is not in focus. |
| FOCUS | Focus is prioritized over shutter response. Pictures can be only taken when the camera is in focus. |


TOUCH SCREEN MODE

Choose the focus operations performed using touch controls.

Still Photography

| Mode | Description |
|--|--|
|  AF  AF OFF | <ul style="list-style-type: none"> In focus mode S (AF-S), the camera focuses when you tap your subject in the display. Focus locks at the current distance until you tap the AF OFF icon. In focus mode C (AF-C), the camera initiates focus when you tap your subject in the display. The camera will continue to adjust focus for changes in the distance to the subject until you tap the AF OFF icon. In manual focus mode (MF), you can tap the display to focus on the selected subject using autofocus. |
|  AREA | Tap to select a point for focus or zoom. The focus frame will move to the selected point. |
|  OFF | Touch focus disabled. |

Movie Recording

| Mode | Description |
|---|--------------------------|
|  OFF | Touch controls disabled. |



To disable touch controls and hide the touch screen mode indicator, select **OFF** for **■ BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > TOUCH SCREEN ON/OFF**.


Touch Controls for Focus Zoom

Different touch controls are used during focus zoom (focus check enabled).


Central Area

Tapping the center of the display performs the operations below.

| Mode | AF-S | MF |
|------|------|------------|
| AF | AF | Instant AF |
| AREA | OFF | |
| OFF | | |

**Other Areas**


Tapping other areas simply scrolls the display.






SHOOTING SETTING

Adjust shooting options.



To display shooting options, press **MENU/OK** in the shooting display and select the  (**SHOOTING SETTING**) tab.



The options available vary with the shooting mode selected.

SELF-TIMER

Choose a shutter release delay.

| Option | Description |
|---|--|
|  2 SEC | The shutter is released two seconds after the shutter button is pressed. Use to reduce blur caused by the camera moving when the shutter button is pressed. The self-timer lamp blinks as the timer counts down. |
|  10 SEC | The shutter is released ten seconds after the shutter button is pressed. Use for photographs in which you wish to appear yourself. The self-timer lamp blinks immediately before the picture is taken. |
| OFF | Self-timer off. |

If an option other than **OFF** is selected, the timer will start when the shutter button is pressed all the way down. The display shows the number of seconds remaining until the shutter is released. To stop the timer before the picture is taken, press **DISP/BACK**.



Stand behind the camera when using the shutter button. Standing in front of the lens can interfere with focus and exposure.


SAVE SELF-TIMER SETTING


If **ON** is selected, the chosen self-timer setting will remain in effect after a picture is taken or the camera is turned off.

| Options | |
|---------|-----|
| ON | OFF |


INTERVAL TIMER SHOOTING

Configure the camera to take photos automatically at a preset interval.


- 1 Highlight **INTERVAL TIMER SHOOTING** in the  (**SHOOTING SETTING**) tab and press **MENU/OK**.



- 2 Use the focus stick (focus lever) to choose the interval and number of shots. Press **MENU/OK** to proceed.



- 3 Use the focus stick to choose the starting time and then press **MENU/OK**. Shooting will start automatically.





Interval timer photography cannot be used with multiple exposure photography. In burst mode, only one picture will be taken each time the shutter is released.



- Use of a tripod is recommended.
- Check the battery level before starting. We recommend using an optional AC-15V AC power adapter.
- The display turns off between shots and lights a few seconds before the next shot is taken.
- The display can be activated at any time by pressing the shutter button.
- To continue shooting until the memory card is full, set the number of shots to ∞ .






AE BKT SETTING

Adjust exposure bracketing settings.

| Option | Description |
|----------------------------|--|
| FRAMES/STEP SETTING | Choose the number of shots in the bracketing sequence and the amount exposure is varied with each shot. <ul style="list-style-type: none"> • FRAMES: Choose the number of shots in the bracketing sequence. • STEP: Choose the amount exposure is varied with each shot. |
| 1 FRAME/CONTINUOUS | <ul style="list-style-type: none"> • 1 FRAME: The shots in the bracketing sequence are taken one at a time. • CONTINUOUS: The shots in the bracketing sequence are taken in a single burst. |
| SEQUENCE SETTING | Choose the order in which the shots are taken. |

FILM SIMULATION BKT

Choose the three film simulation types used for film simulation bracketing (📖 90).


| Options | | |
|--|---|---|
|  PROVIA/STANDARD |  Velvia/VIVID |  ASTIA/SOFT |
|  CLASSIC CHROME |  PRO Neg. Hi |  PRO Neg. Std |
|  ACROS* |  MONOCHROME* |  SEPIA |

* Available with yellow (**Ye**), red (**R**), and green (**G**) filters.

FOCUS BKT


Adjust focus bracketing settings.

| Option | Description |
|-----------------|---|
| FRAMES | Choose the number of shots. |
| STEP | Choose the amount focus changes with each shot. |
| INTERVAL | Choose the interval between shots. |

 Do not adjust zoom during shooting.

Focus and FRAMES/STEP

The relation between focus and the options chosen for **FRAMES** and **STEP** is shown in the illustration.







- Focus proceeds from the starting position toward infinity.
- Small **STEP** values translate to small changes in focus, larger values to larger changes.
- Regardless of the option chosen for **FRAMES**, shooting ends when focus reaches infinity.

PHOTOMETRY

Choose how the camera meters exposure.

 The selected option will only take effect when  **AF/MF SETTING** > **FACE/EYE DETECTION SETTING** is **FACE OFF/EYE OFF**.

| Mode | Description |
|---|---|
|  MULTI | The camera instantly determines exposure based on an analysis of composition, color, and brightness distribution. Recommended in most situations. |
|  CENTER WEIGHTED | The camera meters the entire frame but assigns the greatest weight to the area at the center. |
|  SPOT | The camera meters lighting conditions in an area at the center of the frame equivalent to 2% of the total. Recommended with backlit subjects and in other cases in which the background is much brighter or darker than the main subject. |
|  AVERAGE | Exposure is set to the average for the entire frame. Provides consistent exposure across multiple shots with the same lighting, and is particularly effective for landscapes and portraits of subjects dressed in black or white. |

SHUTTER TYPE

Choose the shutter type. Choose the electronic shutter to mute the shutter sound.

| Option | Description |
|--|--|
| MS MECHANICAL SHUTTER | Take pictures with the mechanical shutter. |
| ES ELECTRONIC SHUTTER | Take pictures with the electronic shutter. |
| EF E-FRONT CURTAIN SHUTTER | The camera chooses the mechanical or electronic front curtain shutter according to shooting conditions. |
| M_E MECHANICAL + ELECTRONIC | The camera chooses the mechanical or electronic shutter according to shooting conditions. |
| E_F E-FRONT + ELECTRONIC | The camera chooses the mechanical, electronic, or electronic front curtain shutter according to shooting conditions. |

If **ES ELECTRONIC SHUTTER**, **M_E MECHANICAL + ELECTRONIC**, or **E_F E-FRONT + ELECTRONIC** is selected, shutter speeds faster than $\frac{1}{4000}$ s can be chosen by rotating the shutter speed dial to **4000** and then rotating the rear command dial. The mechanical shutter will still be used at high shutter speeds when **EF E-FRONT CURTAIN SHUTTER** is selected.



- When using the electronic shutter, note the following:
 - Distortion may be visible in shots of moving subjects.
 - Distortion may also be visible in hand-held shots taken at high shutter speeds; use of a tripod is recommended.
 - Banding and fog may occur in shots taken under fluorescent lights or other flickering or erratic illumination.
 - When taking pictures with the shutter muted (161), respect your subjects' image rights and right to privacy.
- When using the electronic front-curtain shutter, note the following:
 - Faster shutter speeds are more likely to result in uneven exposure and loss of resolution in out-of-focus areas of the frame.



The following restrictions apply when the electronic shutter is used:

- Sensitivity is restricted to values of ISO 12800–100.
- Long exposure noise reduction has no effect.
- The flash can not be used.

FLICKER REDUCTION




Select **ON** to reduce flicker in pictures and the display when shooting under fluorescent lighting and other similar light sources.

| Options | |
|---------|-----|
| ON | OFF |

- Enabling flicker reduction disables the electronic shutter and increases the time needed to record pictures.
- Flicker reduction is not available during movie recording.

IS MODE



Reduce blur.

| Option | Description |
|--|--|
|  CONTINUOUS | Image stabilization on. |
|  SHOOTING ONLY | Image stabilization enabled only when the shutter button is pressed halfway (focus mode C) or the shutter is released. |
| OFF | Image stabilization off;  appears in the display. Recommended when the camera is on a tripod. |




- This option is available only with lenses that support image stabilization.

ISO

Adjust the camera's sensitivity to light.

| Option | Description |
|---|--|
| AUTO1 AUTO2 AUTO3 | Sensitivity is automatically adjusted in response to shooting conditions according to combination of standard and maximum sensitivity and minimum shutter speed chosen for  SHOOTING SETTING > ISO . Choose from AUTO1 , AUTO2 , and AUTO3 ( 120). |
| 12800–100 | Adjust sensitivity manually. Selected value is shown in display. |
| H (102400/51200/25600), L (50) | Choose for special situations. Note that mottling may appear in pictures taken at H , while L reduces dynamic range. |



- The **Fn1** button can be assigned other roles using  **BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING**. The role described above can also be assigned to other function buttons ( 198).
- Sensitivity is not reset when the camera is turned off.
- If desired, you can use  **BUTTON/DIAL SETTING > COMMAND DIAL SETTING** to configure the camera so that ISO sensitivity can be adjusted using the front or rear command dial.

Adjusting Sensitivity

High values can be used to reduce blur when lighting is poor, while lower values allow slower shutter speeds or wider apertures in bright light; note, however, that mottling may appear in pictures taken at high sensitivities.

AUTO

Choose the base sensitivity, maximum sensitivity, and minimum shutter speed for **AUTO1**, **AUTO2**, and **AUTO3**.

| Item | Options | Default | | |
|----------------------------|-------------------------------------|--------------------|-------|-------|
| | | AUTO1 | AUTO2 | AUTO3 |
| DEFAULT SENSITIVITY | 12800–100 | 100 | | |
| MAX. SENSITIVITY | 12800–200 | 800 | 1600 | 3200 |
| MIN. SHUTTER SPEED | $\frac{1}{500}$ – $\frac{1}{4}$ SEC | $\frac{1}{60}$ SEC | | |

The camera automatically chooses a sensitivity between the default and maximum values; sensitivity is only raised above the default value if the shutter speed required for optimal exposure would be slower than the value selected for **MIN. SHUTTER SPEED**.




- If the value selected for **DEFAULT SENSITIVITY** is higher than that selected for **MAX. SENSITIVITY**, **DEFAULT SENSITIVITY** will be set to the value selected for **MAX. SENSITIVITY**.
- The camera may select shutter speeds slower than **MIN. SHUTTER SPEED** if pictures would still be underexposed at the value selected for **MAX. SENSITIVITY**.

MOUNT ADAPTER SETTING

Adjust settings for lenses attached via a mount adapter.

Shutter Select

When using lenses with an internal shutter, choose whether to use the shutter on the camera (**BODY**) or the lens (**LENS**).


 This option may have no effect with some lenses.

Saved Settings

Store settings for up to 6 lenses, or choose **OFF** to disable corrections for focal length, distortion, color shading, and peripheral illumination.


Choosing a Focal Length

Use the focus stick (focus lever) to enter the focal length.



Distortion Correction


Choose from **STRONG**, **MEDIUM**, or **WEAK** options to correct **BARREL** or **PINCUSHION** distortion.




Color Shading Correction

Color (shading) variations between the center and edges of the frame can be adjusted separately for each corner.

To use color shading correction, follow the steps below.





- 1 Rotate the rear command dial to choose a corner. The selected corner is indicated by a triangle.
- 2 Use the focus stick (focus lever) to adjust shading until there is no visible difference in color between the selected corner and the center of the image.
 - Press the focus stick left or right to adjust colors on the cyan–red axis.
 - Press the focus stick up or down to adjust colors on the blue–yellow axis.

 To determine the amount required, adjust color shading correction while taking photos of blue sky or a sheet of gray paper.


Peripheral Illumination Correction


Choose from values between –5 and +5. Choosing positive values increases peripheral illumination, while choosing negative values reduces peripheral illumination. Positive values are recommended for vintage lenses, negative values to create the effect of images taken with an antique lens or a pinhole camera.






 To determine the amount required, adjust peripheral illumination correction while taking photos of blue sky or a sheet of gray paper.

35mm FORMAT MODE

Enabling  **SHOOTING SETTING > 35mm FORMAT MODE** in the shooting menu sets the picture angle to 35 mm; the change is reflected in the display.



| Option | Description |
|-------------|--|
| ON | The picture angle is set to 35 mm; the change is reflected in the display. |
| OFF | 35 mm format mode disabled. |
| AUTO | 35 mm format mode is enabled automatically when a mount adapter that supports automatic detection is attached. |

- The  **SCREEN SET-UP > DISP. CUSTOM SETTING** item in the setup menu (18, 168) includes an option (enabled by default) for displaying a **35mm FORMAT MODE** icon.
- The  **IMAGE QUALITY SETTING > IMAGE SIZE** item in the shooting menu is fixed at  **3:2**.

WIRELESS COMMUNICATION


Connect to smartphones running the latest version of the FUJIFILM Camera Remote app. The smartphone can then be used to:


- Control the camera and take pictures remotely
- Receive pictures uploaded from the camera
- Browse the pictures on the camera and download selected pictures
- Upload location data to the camera


 For downloads and other information, visit:
http://app.fujifilm-dsc.com/en/camera_remote/

FLASH SETTING

Adjust flash-related settings.


To display flash-related settings, press **MENU/OK** in the shooting display and select the  (**FLASH SETTING**) tab.


 The options available vary with the shooting mode selected.



FLASH FUNCTION SETTING

Choose a flash control mode, flash mode, or sync mode or adjust the flash level. The options available vary with the flash.


 For more information on flash settings, see “External Flash Units” (207) in “Peripherals and Optional Accessories”.



RED EYE REMOVAL

Remove red-eye effects caused by the flash.

| Option | Description |
|----------------------|---|
| FLASH+REMOVAL | A red-eye reduction pre-flash is combined with digital red-eye removal. |
| FLASH | Flash red-eye reduction only. |
| REMOVAL | Digital red-eye removal only. |
| OFF | Flash red-eye reduction and digital red-eye removal off. |

-  Flash red-eye reduction can be used in TTL flash control mode.
- Digital red-eye removal is performed only when a face is detected.
- Digital red-eye removal is not available with RAW images.

TTL-LOCK MODE

Instead of adjusting flash level with each shot, TTL flash control can be locked for consistent results across a series of photographs.

| Option | Description |
|---------------------------------|---|
| LOCK WITH LAST FLASH | Flash output is locked at the value metered for the most recent photo. |
| LOCK WITH METERING FLASH | The camera emits a series of pre-flashes and locks flash output at the metered value. |



- To use TTL lock, assign **TTL-LOCK** to a camera control and then use the control to enable or disable TTL lock (📖 198).
- Flash compensation can be adjusted while TTL lock is in effect.
- Selecting **LOCK WITH LAST FLASH** displays an error message if no previously metered value exists.

LED LIGHT SETTING

Choose whether to use the flash unit's LED video light (if available) as a catchlight or AF-assist illuminator when taking photos.

| Option | Role of LED video light in still photography |
|-----------------------------|--|
| CATCHLIGHT | Catchlight |
| AF ASSIST | AF-assist illuminator |
| AF ASSIST+CATCHLIGHT | AF-assist illuminator and catchlight |
| OFF | None |



In some cases, this option can also be accessed via the **FLASH FUNCTION SETTING** menu.

MASTER SETTING

Choose a flash group (A, B, or C) for the flash mounted on the camera hot shoe when it functions as a master flash controlling remote flash units via Fujifilm wireless optical flash control, or choose **OFF** to limit master flash output to a level that does not affect the final picture.

| Options | | | |
|---------|------|------|-----|
| Gr A | Gr B | Gr C | OFF |



In some cases, this option can also be accessed via the **FLASH FUNCTION SETTING** menu.

CH SETTING

Choose the channel used for communication between the master flash and remote flash units when using Fujifilm optical wireless flash control. Separate channels can be used for different flash systems or to prevent interference when multiple systems are operating in close proximity.

| Options | | | |
|---------|-----|-----|-----|
| CH1 | CH2 | CH3 | CH4 |




MOVIE SETTING

Adjust movie-recording options.

To display options for movie recording, press **MENU/OK** in the shooting display and select the **MOVIE SETTING** tab.

The options available vary with the shooting mode selected.



MOVIE MODE

Choose a frame size and rate for movie recording.

| Option | Frame size | Rate |
|----------------------------|-----------------------|-----------|
| FULL HD 1080/29.97P | 1920 × 1080 (Full HD) | 29.97 fps |
| FULL HD 1080/25P | | 25 fps |
| FULL HD 1080/24P | | 24 fps |
| FULL HD 1080/23.98P | | 23.98 fps |
| HD 720/29.97P | 1280 × 720 (HD) | 29.97 fps |
| HD 720/25P | | 25 fps |
| HD 720/24P | | 24 fps |
| HD 720/23.98P | | 23.98 fps |

MOVIE AF MODE

Choose how the camera selects the focus point for movie recording.

| Option | Description |
|--------------|---|
| MULTI | Automatic focus-point selection. |
| AREA | The camera focuses on the subject in the selected focus area. |

HDMI OUTPUT INFO DISPLAY

If **ON** is selected, HDMI devices to which the camera is connected will mirror the information in the camera display.

| Options | |
|-----------|------------|
| ON | OFF |


HDMI REC CONTROL

Choose whether the camera sends movie start and stop signals to the HDMI device when the shutter button is pressed to start and stop movie recording.

| Options | |
|---------|-----|
| ON | OFF |

MIC LEVEL ADJUSTMENT

Adjust the recording level for the built-in and external microphones.





| Option | Description |
|--------|---------------------------|
| 20—1 | Choose a recording level. |
| OFF | Disable the microphone. |

- The display shows the peak recording level detected in a given period.
- You can assign **MIC LEVEL ADJUSTMENT** to a camera control and then using the control to adjust the microphone level during recording.

MIC/REMOTE RELEASE

Specify whether the device connected to the microphone/remote release connector is a microphone or a remote release.

| Options | |
|---|--|
|  MIC |  REMOTE |


Playback and the Playback Menu

7

The Playback Display

This section lists the indicators that may be displayed during playback.



For illustrative purposes, displays are shown with all indicators lit.



| | | | |
|--|-------------|-----------------------------------|------------|
| ① Date and time..... | 39, 41, 157 | ⑮ Film simulation..... | 90 |
| ② Bluetooth ON/OFF..... | 185 | ⑯ Dynamic range..... | 92 |
| ③ Image transfer order..... | 147 | ⑰ White balance..... | 93 |
| ④ Image transfer status..... | 185, 220 | ⑱ Sensitivity..... | 76 |
| ⑤ Number of frames selected for upload...147 | | ⑲ Exposure compensation | 79 |
| ⑥ Card slot..... | 135 | ⑳ Aperture..... | 57, 61, 62 |
| ⑦ Frame number | 182 | ㉑ Shutter speed..... | 57, 58, 62 |
| ⑧ Protected image..... | 142 | ㉒ Playback mode indicator..... | 47 |
| ⑨ Location data..... | 220 | ㉓ Movie icon..... | 53 |
| ⑩ Red-eye removal indicator..... | 124, 144 | ㉔ Gift image..... | 47 |
| ⑪ Face detection indicator..... | 104 | ㉕ Photobook assist indicator..... | 149 |
| ⑫ Battery level..... | 38 | ㉖ DPOF print indicator | 151 |
| ⑬ Image quality..... | 89 | ㉗ Voice memo..... | 145 |
| ⑭ Image size..... | 88 | ㉘ Rating..... | 131 |

The DISP/BACK Button

The **DISP/BACK** button controls the display of indicators during playback.



The Info Display


In the info display, you can press the focus stick (focus lever) up to cycle through a series of information and histogram displays.

Favorites: Rating Pictures


To rate the current picture, press **DISP/BACK** and press the focus stick (focus lever) up and down to select from zero to five stars.

Viewing Photo Information



The photo information display changes each time the focus stick (focus lever) is pressed up.




Basic data



Histogram




Info display 2



Info display 1

Zooming in on the Focus Point

Press the center of the rear command dial to zoom in on the focus point. Press again to return to full-frame playback.



Playback Zoom

Rotate the rear command dial right to zoom in on the current picture, left to zoom out. To exit zoom, press **DISP/BACK**, **MENU/OK**, or the center of the rear command dial.

- The maximum zoom ratio varies with the option selected for **IMAGE QUALITY SETTING > IMAGE SIZE**.
 - Playback zoom is not available with cropped or resized copies saved at a size of **640**.

Scroll

When the picture is zoomed in, the focus stick (focus lever) can be used to view areas of the image not currently visible in the display.



Navigation window

Multi-Frame Playback

To change the number of images displayed, rotate the rear command dial left when a picture is displayed full frame.


- Use the focus stick (focus lever) to highlight images and press **MENU/OK** to view the highlighted image full frame. In the nine- and hundred-frame displays, press the focus stick up or down to view more pictures.



The Playback Menu

Adjust playback settings.


The playback menu is displayed when you press **MENU/OK** in playback mode.



SWITCH SLOT

Choose the card from which images will be played back.




If two memory cards are inserted, you can press and hold the  button to choose a card for playback.

RAW CONVERSION


Even if you don't have a computer, you can use the camera to modify RAW pictures and save them in JPEG or TIFF format.

Saving RAW Pictures in Another Format

- 1 Display a RAW picture.
- 2 Highlight **RAW CONVERSION** in the playback menu.
- 3 Press **MENU/OK**.
A list of settings will be displayed.



- 4 Press the focus stick (focus lever) up or down to highlight a setting.
- 5 Press the focus stick right to display options.



- 6 Press the focus stick up or down to highlight the desired option.
- 7 Press **MENU/OK** to select the highlighted option. The settings list shown in Step 3 will be displayed. Repeat Steps 4 to 7 to adjust additional settings.
- 8 Press the **Q** button.
A preview of the JPEG or TIFF copy will be displayed.
- 9 Press **MENU/OK**.
The JPEG or TIFF copy will be saved.




RAW conversion options can also be displayed by pressing the **Q** button when a RAW picture is displayed during playback.

The settings that can be adjusted when converting pictures from RAW to another format are:

| Setting | Description |
|----------------------------------|--|
| REFLECT SHOOTING COND. | Create a copy using the settings in effect at the time the photo was taken. |
| FILE TYPE | Choose a file format. |
| IMAGE SIZE | Choose an image size. |
| IMAGE QUALITY | Adjust image quality. |
| PUSH/PULL PROCESSING | Adjust exposure. |
| DYNAMIC RANGE | Enhance details in highlights for natural contrast. |
| FILM SIMULATION | Simulate the effects of different types of film. |
| GRAIN EFFECT | Add a film grain effect. |
| COLOR CHROME EFFECT | Deepen colors in shadows. |
| WHITE BALANCE | Adjust white balance. |
| WB SHIFT | Fine-tune white balance. |
| HIGHLIGHT TONE | Adjust highlights. |
| SHADOW TONE | Adjust shadows. |
| COLOR | Adjust color density. |
| SHARPNESS | Sharpen or soften outlines. |
| NOISE REDUCTION | Process the copy to reduce mottling. |
| LENS MODULATION OPTIMIZER | Improve definition by adjusting for diffraction and the slight loss of focus at the periphery of the lens. |
| COLOR SPACE | Choose the color space used for color reproduction. |

ERASE


Delete individual pictures, multiple selected pictures, or all pictures.

 Deleted pictures cannot be recovered. Protect important pictures or copy them to a computer or other storage device before proceeding.

| Option | Description |
|------------------------|------------------------------------|
| FRAME | Delete pictures one at a time. |
| SELECTED FRAMES | Delete multiple selected pictures. |
| ALL FRAMES | Delete all unprotected pictures. |

FRAME

- 1 Select **FRAME** for **ERASE** in the playback menu.
- 2 Press the focus stick (focus lever) left or right to scroll through pictures and press **MENU/OK** to delete.

-  • A confirmation dialog is not displayed before pictures are deleted; be sure the correct picture is selected before pressing **MENU/OK**.
- Additional pictures can be deleted by pressing **MENU/OK**. Press the focus stick left or right to scroll through pictures and press **MENU/OK** to delete.

SELECTED FRAMES

- 1 Select **SELECTED FRAMES** for **ERASE** in the playback menu.
- 2 Highlight pictures and press **MENU/OK** to select.
 - Selected pictures are indicated by check marks (✓).
 - To deselect a highlighted picture, press **MENU/OK** again.
- 3 When the operation is complete, press **DISP/BACK** to display a confirmation dialog.
- 4 Highlight **OK** and press **MENU/OK** to delete the selected pictures.



Pictures in photobooks or printer orders are shown by **!**.

ALL FRAMES

- 1 Select **ALL FRAMES** for **ERASE** in the playback menu.
- 2 A confirmation dialog will be displayed; highlight **OK** and press **MENU/OK** to delete all unprotected pictures.



- Pressing **DISP/BACK** cancels deletion; note that any pictures deleted before the button was pressed cannot be recovered.
- If a message appears stating that the selected images are part of a DPOF print order, press **MENU/OK** to delete the pictures.

SIMULTANEOUS DELETE(RAW SLOT1/JPG SLOT2)

Taking photos with **RAW/JPEG** selected for **SAVE DATA SET-UP > CARD SLOT SETTING (STILL IMAGE)** creates two copies. Choose whether deleting the RAW image will also delete the JPEG copy.

| Option | Description |
|------------|---|
| ON | Deleting the RAW image from the card in Slot 1 also deletes the JPEG copy from the card in Slot 2. |
| OFF | Deleting the RAW image from the card in Slot 1 does not delete the JPEG copy from the card in Slot 2. |

CROP

Create a cropped copy of the current picture.

- 1 Display the desired picture.
- 2 Select **CROP** in the playback menu.
- 3 Use the rear command dial to zoom in and out and press the focus stick (focus lever) up, down, left, or right to scroll the picture until the desired portion is displayed.
- 4 Press **MENU/OK** to display a confirmation dialog.
- 5 Press **MENU/OK** again to save the cropped copy to a separate file.



- The higher the zoom ratio, the smaller the number of pixels in the cropped copy.
- If the size of the final copy will be **640**, **YES** will be displayed in yellow.
- All copies have an aspect ratio of 3:2.

RESIZE

Create a small copy of the current picture.

- 1 Display the desired picture.
- 2 Select **RESIZE** in the playback menu.
- 3 Highlight a size and press **MENU/OK** to display a confirmation dialog.
- 4 Press **MENU/OK** again to save the resized copy to a separate file.



The sizes available vary with the size of the original image.

PROTECT

Protect pictures from accidental deletion. Highlight one of the following options and press **MENU/OK**.

| Option | Description |
|------------------|--|
| FRAME | Protect selected pictures. Press the focus stick (focus lever) left or right to view pictures and press MENU/OK to select or deselect. Press DISP/BACK when the operation is complete. |
| SET ALL | Protect all pictures. |
| RESET ALL | Remove protection from all pictures. |

 Protected pictures will be deleted when the memory card is formatted.


 Protecting images currently selected for upload to paired smartphones or tablets removes upload marking.

IMAGE ROTATE

Rotate pictures.

- 1 Display the desired picture.
- 2 Select **IMAGE ROTATE** in the playback menu.
- 3 Press the focus stick (focus lever) down to rotate the picture 90° clockwise, up to rotate it 90° counterclockwise.
- 4 Press **MENU/OK**. The picture will automatically be displayed in the selected orientation whenever it is played back on the camera.



- Protected pictures cannot be rotated. Remove protection before rotating pictures.
- The camera may not be able to rotate pictures created with other devices. Pictures rotated on the camera will not be rotated when viewed on a computer or on other cameras.
- Pictures taken with **SCREEN SET-UP > AUTOROTATE PB** are automatically displayed in the correct orientation during playback.

RED EYE REMOVAL

Remove red-eye from portraits. The camera will analyze the image; if red-eye is detected, the image will be processed to create a copy with reduced red-eye.

- 1 Display the desired picture.
- 2 Select **RED EYE REMOVAL** in the playback menu.
- 3 Press **MENU/OK**.



- Results vary depending on the scene and the camera's success in detecting faces.
- The amount of time needed to process the image varies with the number of faces detected.
- Red eye cannot be removed from pictures that have already been processed using red-eye removal, which are indicated by a icon during playback.
- Red eye removal cannot be performed on RAW images.

VOICE MEMO SETTING

Add a voice memo to the current photograph.

- 1 Select **ON** for **VOICE MEMO SETTING** in the playback menu.
- 2 Display a photo to which you wish to add a voice memo.
- 3 Press and hold the **Fn2** button to record the memo. Recording ends after 30 s or when you release the button.



- The new memo will be recorded over any existing memos.
- Voice memos cannot be added to protected pictures.
- Deleting the picture also deletes the memo.

Playing Voice Memos

Pictures with voice memos are indicated by icons during playback.

- To play a memo, select the picture and press the **Fn2** button.
- A progress bar will be displayed while the memo plays back.
- Volume can be adjusted by pressing **MENU/OK** to pause playback and then pressing the focus stick (focus lever) up or down to adjust the volume. Press **MENU/OK** again to resume playback. Volume can also be adjusted using **SOUND SET-UP > PLAYBACK VOLUME**.

COPY

Copy pictures between the cards in the first and second slots.

- 1 Select **COPY** in the playback menu.
- 2 Highlight one of the following options.

| Option | Description |
|----------------------|---|
| SLOT1 → SLOT2 | Copy pictures from the card in the first slot to the card in the second slot. |
| SLOT2 → SLOT1 | Copy pictures from the card in the second slot to the card in the first slot. |

- 3 Press the focus stick (focus lever) right.
- 4 Highlight one of the following options and press **MENU/OK**.

| Option | Description |
|-------------------|--|
| FRAME | Copy selected pictures. Press the focus stick left or right to view pictures and press MENU/OK to copy the current picture. |
| ALL FRAMES | Copy all pictures. |



 Copying ends when the destination is full.

IMAGE TRANSFER ORDER

Select photos for upload to a paired smartphone or tablet.

- 1 Select **IMAGE TRANSFER ORDER > SELECT FRAMES** in the playback menu.
- 2 Highlight photos and press **MENU/OK** to select or deselect. Repeat until all the desired photos have been selected.
- 3 Press **DISP/BACK** to exit to playback.

 If **ON** is selected for both **CONNECTION SETTING > Bluetooth SETTINGS > Bluetooth ON/OFF** and **AUTO IMAGE TRANSFER**, upload will begin shortly after you exit to playback or turn the camera off.

-  • Image transfer orders can contain a maximum of 999 pictures.
- The following cannot be selected for upload:
 - Protected pictures
 - Movies
 - RAW images
 - “Gift” pictures (pictures taken with other cameras)
- If **PAIRING/TRANSFER ORDER** is selected for **CONNECTION SETTING > GENERAL SETTINGS > Wi-Fi BUTTON SETTING**, photos can also be marked for upload using the **Fn1** button.
- To remove upload marking from all pictures in the current order, select **IMAGE TRANSFER ORDER > RESET ORDER**.
- If **ON** is selected for **CONNECTION SETTING > Bluetooth SETTINGS > AUTO IMAGE TRANSFER**, photos will automatically be marked for upload as they are taken.

WIRELESS COMMUNICATION

Connect to smartphones running the latest version of the FUJIFILM Camera Remote app. The smartphone can then be used to:

- Control the camera and take pictures remotely
- Receive pictures uploaded from the camera
- Browse the pictures on the camera and download selected pictures
- Upload location data to the camera




For downloads and other information, visit:



http://app.fujifilm-dsc.com/en/camera_remote/


PHOTOBOOK ASSIST

Create books from your favorite photos.

Creating a Photobook

- 1 Select **NEW BOOK** for  **PLAY BACK MENU > PHOTOBOOK ASSIST**.
- 2 Scroll through the images and press the focus stick (focus lever) up to select or deselect. Press **MENU/OK** to exit when the book is complete.
- 3 Highlight **COMPLETE PHOTOBOOK** and press **MENU/OK** (to select all photos for the book, choose **SELECT ALL**). The new book will be added to the list in the photobook assist menu.

-  • Neither photographs  or smaller nor movies can be selected for photobooks.
- The first picture selected becomes the cover image. Press the focus stick down to select the current image for the cover instead.

-  • Books can contain up to 300 pictures.
- Books that contain no photos are automatically deleted.

Photobooks

Photobooks can be copied to a computer using MyFinePix Studio software.

Viewing Photobooks

Highlight a book in the photobook assist menu and press **MENU/OK** to display the book, then press the focus stick (focus lever) left or right to scroll through the pictures.


Editing and Deleting Photobooks


Display the photobook and press **MENU/OK**. The following options will be displayed; select the desired option and follow the on-screen instructions.


- **EDIT:** Edit the book as described in “Creating a Photobook”.
- **ERASE:** Delete the book.

PRINT ORDER (DPOF)

Create a digital “print order” for DPOF-compatible printers.


- 1 Select **PLAY BACK MENU > PRINT ORDER (DPOF)**.
- 2 Select **WITH DATE**  to print the date of recording on pictures, **WITHOUT DATE** to print pictures without dates, or **RESET ALL** to remove all pictures from the print order before proceeding.
- 3 Display a picture you wish to include in or remove from the print order.
- 4 Press the focus stick (focus lever) up or down to choose the number of copies (up to 99).

 To remove a picture from the order, press the focus stick down until the number of copies is 0.





Total number of prints

Number of copies

 Repeat steps 3–4 to complete the print order.


- 5 The total number of prints is displayed in the monitor. Press **MENU/OK** to exit.

-  • The pictures in the current print order are indicated by a  icon during playback.
- Print orders can contain a maximum of 999 pictures.
- If a memory card is inserted containing a print order created by another camera, you will need to delete the order before creating as described above.

instax PRINTER PRINT

To print pictures to optional Fujifilm instax SHARE printers, first select **PLAY BACK MENU > instax PRINTER CONNECTION SETTING** and enter the instax SHARE printer name (SSID) and password, then follow the steps below.


- 1 Turn the printer on.
- 2 Select **PLAY BACK MENU > instax PRINTER PRINT**. The camera will connect to the printer.
- 3 Use the focus stick (focus lever) to display the picture you want to print, then press **MENU/OK**. The picture will be sent to the printer and printing will start.





- Pictures taken with other cameras cannot be printed.
- The area printed is smaller than the area visible in the LCD monitor.
- The displays may vary depending on the printer connected.

DISP ASPECT

Choose how High Definition (HD) devices display pictures with an aspect ratio of 4:3 (this option is available only when an HDMI cable is connected).



| | Option | |
|---------|---|---|
| | 16:9 | 4:3 |
| Display |  |  |



Select 16:9 to display the image so that it fills the screen with its top and bottom cropped out, 4:3 to display the entire image with black bands at either side.

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.


The Setup Menus


8



USER SETTING



Adjust basic camera settings.

To access basic camera settings, press **MENU/OK**, select the  (SET UP) tab, and choose **USER SETTING**.




FORMAT

To format a memory card:

- 1 Select  **USER SETTING** > **FORMAT** in the  (SET UP) tab.
- 2 Highlight the slot containing the card you wish to format and press **MENU/OK**.
- 3 A confirmation dialog will be displayed. To format the memory card, highlight **OK** and press **MENU/OK**.




To exit without formatting the memory card, select **CANCEL** or press **DISP/BACK**.



- All data—including protected pictures—will be deleted from the memory card. Be sure important files have been copied to a computer or other storage device.
- Do not open the battery-chamber cover during formatting.



The format menu can also be displayed by pressing the center of the rear command dial while pressing and holding the  button.

DATE/TIME

To set the camera clock:

- 1 Select **USER SETTING** > **DATE/TIME** in the (**SET UP**) tab.
- 2 Press the focus stick (focus lever) left or right to highlight the year, month, day, hour, or minute and press up or down to change. To change the order in which the year, month, and day are displayed, highlight the date format and press the focus stick up or down.
- 3 Press **MENU/OK** to set the clock.

TIME DIFFERENCE

Switch the camera clock instantly from your home time zone to the local time at your destination when traveling. To specify the difference between your local and home time zone:

- 1 Highlight **LOCAL** and press **MENU/OK**.
- 2 Use the focus stick (focus lever) to choose the time difference between local time and your home time zone. Press **MENU/OK** when settings are complete.

To set the camera clock to local time, highlight **LOCAL** and press **MENU/OK**. To set the clock to the time in your home time zone, select **HOME**.

| Options | |
|--------------|-------------|
| LOCAL | HOME |


If **LOCAL** is selected, will be displayed in yellow for about three seconds when the camera is turned on.

Choose a language.

MY MENU SETTING


Edit the items listed in the **MY** (MY MENU) tab, a personalized custom menu of frequently-used options.

- 1 Highlight **USER SETTING > MY MENU SETTING** in the **(SET UP)** tab and press **MENU/OK**.




To reorder items, select **RANK ITEMS**. To delete items, select **REMOVE ITEMS**.

- 2 Press the focus stick (focus lever) up or down to highlight **ADD ITEMS** and press **MENU/OK**. Options that can be added to “my menu” are highlighted in blue.



Items currently in “my menu” are indicated by check marks.

- 3 Choose a position for the item and press **MENU/OK**. The item will be added to “my menu”.





- 4 Press **MENU/OK** to return to the edit display.
- 5 Repeat Steps 3 and 4 until all the desired items have been added.

“My menu” can contain up to 16 items.

SENSOR CLEANING


Remove dust from the camera image sensor.

| Option | Description |
|--------------------------|--|
| OK | Clean the sensor immediately. |
| WHEN SWITCHED ON | Sensor cleaning will be performed when the camera is turned on. |
| WHEN SWITCHED OFF | Sensor cleaning will be performed when the camera turns off (sensor cleaning is not however performed if the camera turns off in playback mode). |

 Dust that cannot be removed using sensor cleaning can be removed manually ( 246).

BATTERY AGE

Check battery age. Age is expressed as a number between 0 and 4.



RESET

Reset shooting or setup menu options to default values.

- 1 Highlight the desired option and press **MENU/OK**.

| Option | Description |
|----------------------------|---|
| SHOOTING MENU RESET | Reset all shooting menu settings other than custom white balance and custom settings banks created using EDIT/SAVE CUSTOM SETTING to default values. |
| SET-UP RESET | Reset all setup menu settings other than DATE/TIME , TIME DIFFERENCE , and CONNECTION SETTING to default values. |


- 2 A confirmation dialog will be displayed; highlight **OK** and press **MENU/OK**.



SOUND SETTING

Make changes to camera sounds.

To access sound settings, press **MENU/OK**, select the **[SET UP]** tab, and choose **SOUND SET-UP**.



AF BEEP VOL.

Choose the volume of the beep that sounds when the camera focuses. The beep can be muted by selecting **OFF**.

Options

(high)

(medium)

(low)

OFF (mute)

SELF-TIMER BEEP VOL.

Choose the volume of the beep that sounds while the self-timer is active. The beep can be muted by selecting **OFF**.

Options

(high)

(medium)

(low)

OFF (mute)

OPERATION VOL.

Adjust the volume of the sounds produced when camera controls are operated. Choose **OFF** to disable control sounds.

Options


(high)





(medium)

(low)

OFF (mute)




SHUTTER VOLUME

Adjust the volume of the sounds produced by the electronic shutter. Choose  **OFF** to disable the shutter sound.

| Options | | | |
|--|--|---|---|
|  (high) |  (medium) |  (low) |  OFF (mute) |

SHUTTER SOUND

Choose the sound made by the electronic shutter.

| Options | | |
|--|--|--|
|  SOUND 1 |  SOUND 2 |  SOUND 3 |

PLAYBACK VOLUME

Adjust the volume for movie playback.


| Options | | | | | | | | | | | |
|---------|---|---|---|---|---|---|---|---|---|---|--|
| 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |



SCREEN SETTING

Make changes to display settings.

To access display settings, press **MENU/OK**, select the **SET UP** tab, and choose **SCREEN SET-UP**.



EVF BRIGHTNESS

Adjust the brightness of the display in the electronic viewfinder.

| Option | Description |
|---------------|--|
| AUTO | Automatic brightness adjustment. |
| MANUAL | Adjust brightness manually; choose from options between +5 and -7. |

EVF COLOR


Adjust the hue of the display in the electronic viewfinder.

| Options | | | | | | | | | | |
|---------|----|----|----|----|---|----|----|----|----|----|
| +5 | +4 | +3 | +2 | +1 | 0 | -1 | -2 | -3 | -4 | -5 |

EVF COLOR ADJUSTMENT

Adjust the color of the display in the electronic viewfinder.

- Adjust colors using the focus stick (focus lever).



- Press **MENU/OK**.

LCD BRIGHTNESS

Adjust monitor brightness.

| Options | | | | | | | | | | |
|---------|----|----|----|----|---|----|----|----|----|----|
| +5 | +4 | +3 | +2 | +1 | 0 | -1 | -2 | -3 | -4 | -5 |

LCD COLOR

Adjust monitor hue.

| Options | | | | | | | | | | |
|---------|----|----|----|----|---|----|----|----|----|----|
| +5 | +4 | +3 | +2 | +1 | 0 | -1 | -2 | -3 | -4 | -5 |

LCD COLOR ADJUSTMENT

Adjust the color of the display in the LCD monitor.

- 1 Adjust colors using the focus stick (focus lever).
- 2 Press **MENU/OK**.

IMAGE DISP.

Choose how long images are displayed after shooting.

| Option | Description |
|-------------------|--|
| CONTINUOUS | Pictures are displayed until the MENU/OK button is pressed or the shutter button is pressed halfway. To zoom in on the active focus point, press the center of the rear command dial; press again to cancel zoom. |
| 1.5 SEC | Pictures are displayed for the selected time or until the shutter button is pressed halfway. |
| 0.5 SEC | |
| OFF | Pictures are not displayed after shooting. |



- Colors may differ slightly from those in the final image.
- “Noise” mottling may be visible at high sensitivities.

AUTOROTATE DISPLAYS

Choose whether the indicators in the viewfinder and LCD monitor rotate to match camera orientation.

| Options | |
|-----------|------------|
| ON | OFF |

PREVIEW EXP./WB IN MANUAL MODE

Choose whether to enable exposure and/or white balance preview in manual exposure mode.

| Option | Description |
|------------------------|--|
| PREVIEW EXP./WB | Enable exposure and white balance preview. |
| PREVIEW WB | Preview white balance only. Choose this option in situations in which exposure and white balance are likely to change during shooting, as may be the case when you use a flash with an incandescent monitoring lamp. |
| OFF | Disable exposure and white balance preview. Choose this option when using a flash or on other occasions on which exposure may change when the picture is taken. |







NATURAL LIVE VIEW

Choose whether the effects of film simulation, white balance, and other settings are visible in the monitor.

| Option | Description |
|------------|--|
| ON | The effects of camera settings are not visible in the monitor, but shadows in low-contrast, back-lit scenes and other hard-to-see subjects more visible. Colors and tone will differ from those in the final picture. The display will however be adjusted to show the effects of monochrome and sepia settings. |
| OFF | The effects of film simulation, white balance, and other settings can be previewed in the monitor. |

FRAMING GUIDELINE

Choose a framing grid for shooting mode.

| Option | | | |
|---------|--|---|--|
| |  GRID 9 |  GRID 24 |  HD FRAMING |
| Display |  |  |  |
| | For “rule of thirds” composition. | A six-by-four grid. | Frame HD pictures in the crop shown by the lines at the top and bottom of the display. |



- Framing guides are not shown at default settings but can be displayed using **SCREEN SET-UP > DISP. CUSTOM SETTING** (168).
- HD framing can be customized using FUJIFILM Tether Shooting Plug-in PRO or Hyper-Utility Software HS-V5.

AUTOROTATE PB

Choose **ON** to automatically rotate “tall” (portrait-orientation) pictures during playback.

| Options | |
|-----------|------------|
| ON | OFF |

FOCUS SCALE UNITS

Choose the units used for the focus distance indicator.

| Options | |
|---------------|-------------|
| METERS | FEET |

DISP. CUSTOM SETTING

Choose the items shown in the standard indicator display.


- 1 In shooting mode, use the **DISP/BACK** button to display standard indicators.
- 2 Press **MENU/OK** and select **SCREEN SET-UP > DISP. CUSTOM SETTING** in the **(SET UP)** tab.
- 3 Highlight items and press **MENU/OK** to select or deselect.

| Item | Default | Item | Default |
|---------------------------|-------------------------------------|------------------------|-------------------------------------|
| FRAMING GUIDELINE | <input type="checkbox"/> | FLASH | <input checked="" type="checkbox"/> |
| ELECTRONIC LEVEL | <input type="checkbox"/> | CONTINUOUS MODE | <input checked="" type="checkbox"/> |
| FOCUS FRAME | <input checked="" type="checkbox"/> | DUAL IS MODE | <input checked="" type="checkbox"/> |
| AF DISTANCE INDICATOR | <input type="checkbox"/> | TOUCH SCREEN MODE | <input checked="" type="checkbox"/> |
| MF DISTANCE INDICATOR | <input checked="" type="checkbox"/> | WHITE BALANCE | <input checked="" type="checkbox"/> |
| HISTOGRAM | <input type="checkbox"/> | FILM SIMULATION | <input checked="" type="checkbox"/> |
| LIVE VIEW HIGHLIGHT ALERT | <input type="checkbox"/> | DYNAMIC RANGE | <input checked="" type="checkbox"/> |
| SHOOTING MODE | <input checked="" type="checkbox"/> | FRAMES REMAINING | <input checked="" type="checkbox"/> |
| APERTURE/S-SPEED/ISO | <input checked="" type="checkbox"/> | IMAGE SIZE/QUALITY | <input checked="" type="checkbox"/> |
| INFORMATION BACKGROUND | <input checked="" type="checkbox"/> | MOVIE MODE & REC. TIME | <input checked="" type="checkbox"/> |
| Expo. Comp. (Digit) | <input type="checkbox"/> | 35mm FORMAT MODE | <input checked="" type="checkbox"/> |
| Expo. Comp. (Scale) | <input checked="" type="checkbox"/> | IMAGE TRANSFER ORDER | <input checked="" type="checkbox"/> |
| FOCUS MODE | <input checked="" type="checkbox"/> | MIC LEVEL | <input checked="" type="checkbox"/> |
| PHOTOMETRY | <input checked="" type="checkbox"/> | BATTERY LEVEL | <input checked="" type="checkbox"/> |
| SHUTTER TYPE | <input checked="" type="checkbox"/> | FRAMING OUTLINE | <input type="checkbox"/> |


- 4 Press **DISP/BACK** to save changes.
- 5 Press **DISP/BACK** as needed to exit the menus and return to the shooting display.

LARGE INDICATORS MODE(EVF)

Select **ON** to display large indicators in the electronic viewfinder. The indicators displayed can be selected using **SCREEN SETTING > LARGE INDICATORS DISP. SETTING**.



OFF




ON

! Some icons are not displayed when **ON** is selected for **LARGE INDICATORS MODE(EVF)** (11).


📄 If **LARGE INDICATORS MODE** is assigned to a function button, the button can be used to toggle **LARGE INDICATORS MODE** on (**ON**) and off (**OFF**) (174, 198).

LARGE INDICATORS MODE(LCD)


Select **ON** to display large indicators in the LCD monitor. The indicators displayed can be selected using **SCREEN SETTING > LARGE INDICATORS DISP. SETTING**.




OFF




ON

 Some icons are not displayed when **ON** is selected for **LARGE INDICATORS MODE(LCD)** (13).

 If **LARGE INDICATORS MODE** is assigned to a function button, the button can be used to toggle **LARGE INDICATORS MODE** on (**ON**) and off (**OFF**) (174, 198).

LARGE INDICATORS DISP. SETTING


Choose the indicators displayed when **ON** is selected for **SCREEN SETTING > LARGE INDICATORS MODE(EVF)** or **LARGE INDICATORS MODE(LCD)**.




| Option | Description |
|-------------------------|--|
| ① Expo. DISP. | Choose the items listed at the bottom of the display. Selected items are indicated by check marks (✓); to deselect, highlight the check marks and press MENU/OK . |
| ② Scale | Select ON to display the exposure indicator. |
| ③ L1, L2, L3, L4 | Choose up to four large icons for display on the left side of the screen. |
| ④ R1, R2, R3, R4 | Choose up to four large icons for display on the right side of the screen. |

BUTTON/DIAL SETTING


Access options for camera controls.

To access control options, press **MENU/OK**, select the  (**SET UP**) tab, and choose **BUTTON/DIAL SETTING**.





FOCUS LEVER SETTING

Choose the functions performed by the focus stick (focus lever).


| Option | Description |
|---|---|
| LOCK (OFF) | The focus stick cannot be used during shooting. |
| PUSH  TO UNLOCK | Press the stick to view the focus-point display and tilt the stick to select a focus point. |
| ON | Tilt the stick to view the focus-point display and select a focus point. |


EDIT/SAVE QUICK MENU

Choose the items displayed in the quick menu.

- 1 Select  **BUTTON/DIAL SETTING > EDIT/SAVE QUICK MENU** in the  (**SET UP**) tab.
- 2 The current quick menu will be displayed; use the focus stick (focus lever) to highlight the item you wish to change and press **MENU/OK**.
- 3 Highlight any of the following options and press **MENU/OK** to assign it to the selected position.
 - IMAGE SIZE
 - IMAGE QUALITY
 - FILM SIMULATION*
 - GRAIN EFFECT*
 - COLOR CHROME EFFECT*
 - DYNAMIC RANGE*
 - WHITE BALANCE*
 - HIGHLIGHT TONE*
 - SHADOW TONE*
 - COLOR*
 - SHARPNESS*
 - NOISE REDUCTION*
 - SELECT CUSTOM SETTING*
 - AF MODE
 - FACE/EYE DETECTION SETTING
 - MF ASSIST
 - TOUCH SCREEN MODE
 - SELF-TIMER
 - PHOTOMETRY
 - SHUTTER TYPE
 - FLICKER REDUCTION
 - ISO*
 - FLASH FUNCTION SETTING
 - FLASH COMPENSATION
 - MOVIE MODE
 - MIC LEVEL ADJUSTMENT
 - EVF/LCD BRIGHTNESS
 - EVF/LCD COLOR
 - NONE



* Stored in custom settings bank.

-  Select **NONE** to assign no option to the selected position.
- When **SELECT CUSTOM SETTING** is selected, current settings are shown in the quick menu by the label **BASE**.

-  The quick menu can also be accessed in shooting mode by holding the **Q** button.

FUNCTION (Fn) SETTING

Choose the roles played by the function buttons.

- 1 Select  **BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING** in the  **(SET UP)** tab.
- 2 Highlight the desired control and press **MENU/OK**.
- 3 Highlight any of the following options and press **MENU/OK** to assign it to the selected control.
 - IMAGE SIZE
 - IMAGE QUALITY
 - RAW
 - FILM SIMULATION
 - GRAIN EFFECT
 - COLOR CHROME EFFECT
 - DYNAMIC RANGE
 - WHITE BALANCE
 - SELECT CUSTOM SETTING
 - FOCUS AREA
 - FOCUS CHECK
 - AF MODE
 - RAPID AF
 - FACE/EYE DETECTION SETTING
 - DRIVE BUTTON
 - SELF-TIMER
 - AE BKT SETTING
 - FOCUS BKT SETTING
 - PHOTOMETRY
 - SHUTTER TYPE
 - FLICKER REDUCTION
 - ISO
 - 35mm FORMAT MODE
 - WIRELESS COMMUNICATION
 - FLASH FUNCTION SETTING
 - TTL-LOCK
 - MODELING FLASH
 - MIC LEVEL ADJUSTMENT
 - PREVIEW DEPTH OF FIELD
 - PREVIEW EXP/WB IN MANUAL MODE
 - NATURAL LIVE VIEW
 - HISTOGRAM
 - ELECTRONIC LEVEL
 - LARGE INDICATORS MODE
 - FRONT COMMAND DIAL SWITCH
 - AE LOCK ONLY
 - AF LOCK ONLY
 - AE/AF LOCK
 - AF-ON
 - LOCK SETTING
 - AUTO IMAGE TRANSFER
 - SELECT PAIRING DESTINATION
 - Bluetooth ON/OFF
 - PLAYBACK
 - NONE (control disabled)



- **AE LOCK ONLY**, **AF LOCK ONLY**, **AE/AF LOCK**, and **AF-ON** cannot be assigned to the touch function buttons (**T-Fn1** through **T-Fn4**).
- Function button assignment options can also be accessed by holding the **DISP/BACK** button.

AF-ON

If **AF-ON** is selected, you can press the control instead of keeping the shutter button pressed halfway.

MODELING FLASH

If **MODELING FLASH** is selected when a compatible shoe-mounted flash unit is attached, you can press the control to test-fire the flash and check for shadows and the like (modeling flash).

TTL-LOCK

If **TTL-LOCK** is selected, you can press the control to lock flash output according to the option selected for **FLASH SETTING > TTL-LOCK MODE** (📖 125).

COMMAND DIAL SETTING

Choose the roles played by the command dials.

| Option | Description |
|-----------------------------|--|
| FRONT COMMAND DIAL 1 | Assign shutter speed (S.S. (PROGRAM SHIFT)) or aperture (APERTURE (PROGRAM SHIFT)) ¹ to FRONT COMMAND DIAL 1 . |
| FRONT COMMAND DIAL 2 | Assign shutter speed (S.S. (PROGRAM SHIFT)), aperture (APERTURE (PROGRAM SHIFT)) ¹ , exposure compensation (EXP. COMPENSATION) ² , sensitivity (ISO), or no role (NONE) to FRONT COMMAND DIAL 2 or FRONT COMMAND DIAL 3 . |
| FRONT COMMAND DIAL 3 | |
| REAR COMMAND DIAL | Assign shutter speed (S.S. (PROGRAM SHIFT)), aperture (APERTURE (PROGRAM SHIFT)) ¹ , exposure compensation (EXP. COMPENSATION) ² , sensitivity (ISO), or no role (NONE) to the rear command dial. |

1 Aperture ring rotated to **C**.

2 Exposure compensation dial rotated to **C**.



- **COMMAND DIAL SETTING** can also be accessed by pressing and holding the **Fn2** button.
- You can also press the **Fn2** button to cycle through settings in the order **FRONT COMMAND DIAL 1**, **FRONT COMMAND DIAL 2**, and **FRONT COMMAND DIAL 3**.
- The **Fn2** button can be assigned other roles using **■ BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING**. The role described above can also be assigned to other function buttons (📖 198).

SHUTTER AF


Choose whether the camera focuses when the shutter button is pressed halfway.

| Option | Description |
|-------------|---|
| AF-S | <ul style="list-style-type: none"> • ON: Focus locks when the shutter button is pressed halfway. • OFF: No focus operation is performed when the shutter button is pressed halfway. |
| AF-C | <ul style="list-style-type: none"> • ON: The camera focuses while the shutter button is pressed halfway. • OFF: No focus operation is performed when the shutter button is pressed halfway. |

SHUTTER AE

If **ON** is selected, exposure will lock while the shutter button is pressed halfway.

| Option | Description |
|----------------|--|
| AF-S/MF | <ul style="list-style-type: none"> • ON: Exposure locks when the shutter button is pressed halfway. • OFF: Exposure does not lock when the shutter button is pressed halfway. |
| AF-C | <ul style="list-style-type: none"> • ON: Exposure locks while the shutter button is pressed halfway. • OFF: Exposure does not lock when the shutter button is pressed halfway. |

 Select **OFF** to allow the camera to adjust exposure before each shot taken in burst mode.

SHOOT WITHOUT LENS

Choose **ON** to enable the shutter release when no lens is attached.

| Options | |
|-----------|------------|
| ON | OFF |


SHOOT WITHOUT CARD

Choose whether the shutter can be released without a memory card inserted in the camera.

| Option | Description |
|------------|---|
| ON | When no memory card is inserted, the shutter can be released to test camera function and the shooting and setup menus can be displayed. |
| OFF | The shutter is disabled if no memory card is inserted, preventing accidental loss of pictures taken without a memory card. |

FOCUS RING

Choose the direction in which the focus ring is rotated to increase the focus distance.

| Options | |
|---|---|
|  CW (clockwise) |  CCW (counterclockwise) |






















AE/AF-LOCK MODE

This option determines the behavior of the button to which exposure and/or focus lock is assigned.

| Option | Description |
|-----------------------------------|---|
| AE&AF ON WHEN PRESSING | Exposure and/or focus will lock while the button is pressed. |
| AE&AF ON/OFF SWITCH | Exposure and/or focus will lock when the button is pressed and remain locked until it is pressed again. |

TOUCH SCREEN SETTING

Enable or disable touch-screen controls.

| Option | Description | | | | | | | | |
|--|---|---|---|--|--|---|---|--|--|
| TOUCH SCREEN ON/OFF | <ul style="list-style-type: none"> • ON: Touch controls enabled; the LCD monitor functions as a touch screen. • OFF: Touch controls disabled; the LCD monitor cannot be used as a touch screen. | | | | | | | | |
| EVF TOUCH SCREEN AREA SETTINGS | <p>Select the area of the LCD monitor used for touch controls while the viewfinder is active.</p> <ul style="list-style-type: none"> • The area used for touch controls can be selected from: <table> <tr> <td>-  (all)</td><td>-  (left half)</td></tr> <tr> <td>-  (right half)</td><td>-  (top left quarter)</td></tr> <tr> <td>-  (top right quarter)</td><td>-  (bottom left quarter)</td></tr> <tr> <td>-  (bottom right quarter)</td><td></td></tr> </table> • Choose OFF to disable touch controls while the viewfinder is active. | -  (all) | -  (left half) | -  (right half) | -  (top left quarter) | -  (top right quarter) | -  (bottom left quarter) | -  (bottom right quarter) | |
| -  (all) | -  (left half) | | | | | | | | |
| -  (right half) | -  (top left quarter) | | | | | | | | |
| -  (top right quarter) | -  (bottom left quarter) | | | | | | | | |
| -  (bottom right quarter) | | | | | | | | | |

LOCK

Lock selected controls to prevent unintended operation.


| Option | Description |
|---------------------------|---|
| LOCK SETTING | <p>Choose from the following:</p> <ul style="list-style-type: none"> • UNLOCK: Reset lock options. • ALL FUNCTION: Lock all controls in the FUNCTION SELECTION list. • SELECTED FUNCTION: Lock only the controls selected in the FUNCTION SELECTION list. |
| FUNCTION SELECTION | <p>Choose the controls locked when SELECTED FUNCTION is chosen for LOCK SETTING.</p> |



POWER MANAGEMENT

Adjust power management settings.

To access power management settings, press **MENU/OK**, select the **⚙️ (SET UP)** tab, and choose **POWER MANAGEMENT**.



AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually.

| Options | | | | | |
|---------|-------|-------|--------|--------|-----|
| 5 MIN | 2 MIN | 1 MIN | 30 SEC | 15 SEC | OFF |

SHOOTING STAND BY MODE

Choose the delay before the camera enters shooting standby mode.

| Option | Description |
|--------|---|
| 5 MIN | The camera will suspend all functions and enter power-saving (standby) mode if no operations are performed for the selected period. |
| 2 MIN | |
| 1 MIN | |
| 30 SEC | |
| 15 SEC | |
| OFF | Shooting standby mode disabled. |

AUTO POWER SAVE

If **ON** is selected, the display frame rate will drop to save power if no operations are performed for a short period, but the normal frame rate can be restored by operating camera controls.


| Options | |
|---------|-----|
| ON | OFF |



SAVE DATA SETTING


Make changes to file management settings.

To access file management settings, press **MENU/OK**, select the **W (SET UP)** tab, and choose **SAVE DATA SET-UP**.



FRAME NO.

New pictures are stored in image files named using a four-digit file number assigned by adding one to the last file number used. The file number is displayed during playback as shown. **FRAME NO.** controls whether file numbering is reset to 0001 when a new memory card is inserted or the current memory card is formatted.



| Option | Description |
|-------------------|--|
| CONTINUOUS | Numbering continues from the last file number used or the first available file number, whichever is higher. Choose this option to reduce the number of pictures with duplicate file names. |
| RENEW | Numbering is reset to 0001 after formatting or when a new memory card is inserted. |



- If the frame number reaches 999-9999, the shutter release will be disabled. Format the memory card after transferring to a computer any pictures you wish to keep.
- Selecting **W USER SETTING > RESET** sets **FRAME NO.** to **CONTINUOUS** but does not reset the file number.
- Frame numbers for pictures taken with other cameras may differ.

SAVE ORG IMAGE


Choose **ON** to save unprocessed copies of pictures taken using **RED EYE REMOVAL**.

| Options | |
|-----------|------------|
| ON | OFF |

EDIT FILE NAME

Change the file name prefix. sRGB images use a four-letter prefix (default "DSCF"), Adobe RGB images a three-letter prefix ("DSF") preceded by an underscore.

| Option | Default prefix | Sample file name |
|-----------------|----------------|------------------|
| sRGB | DSCF | ABCD0001 |
| AdobeRGB | _DSF | _ABC0001 |

 File name prefixes can be edited using touch controls.

CARD SLOT SETTING (STILL IMAGE)

Choose the role played by the card in the second slot.

| Option | Description |
|-------------------|--|
| SEQUENTIAL | The card in the second slot is used only when the card in the first slot is full. |
| BACKUP | Each picture is recorded twice, once to each card. |
| RAW / JPEG | RAW pictures will be saved to the card in the first slot and JPEG pictures to the card in the second slot. |

SWITCH SLOT (SEQUENTIAL)

Choose the card that is recorded to first when **SEQUENTIAL** is selected for **CARD SLOT SETTING (STILL IMAGE)**. The camera switches between memory card Slots 1 and 2 each time this option is selected.

MOVIE FILE DESTINATION

Choose the slot used to store movies.

| Options | |
|---------|--------|
| SLOT 1 | SLOT 2 |

SELECT FOLDER

Create folders and choose the folder used to store subsequent pictures.

| Option | Description |
|----------------------|---|
| SELECT FOLDER | To choose the folder in which subsequent pictures will be stored, press the focus stick (focus lever) up or down to highlight an existing folder and press MENU/OK . |
| CREATE FOLDER | Enter a five-character folder name to create a new folder in which to store subsequent pictures. The new folder will be created with the next picture you take and subsequent pictures will be stored in that folder. |

COPYRIGHT INFO

Copyright information, in the form of Exif tags, can be added to new images as they are taken. Changes to copyright information are reflected only in images taken after the changes are made.

| Option | Description |
|------------------------------|--|
| DISP COPYRIGHT INFO | View the current copyright information. |
| ENTER AUTHOR'S INFO | Enter the creator's name. |
| ENTER COPYRIGHT INFO | Enter the name of the copyright holder. |
| DELETE COPYRIGHT INFO | Delete the current copyright information. This change applies only to images taken after this option is selected; copyright information recorded with existing images is not affected. |




Copyright information can be edited using touch controls.



CONNECTION SETTING

Adjust settings for connection to other devices.

To access connection settings, press **MENU/OK**, select the **⚙️ (SET UP)** tab, and choose **CONNECTION SETTING**.



For more information on wireless connections, visit:
<http://fujifilm-dsc.com/wifi/>

Bluetooth SETTINGS

Adjust Bluetooth settings.

| Option | Description |
|-----------------------------------|---|
| PAIRING REGISTRATION | To pair the camera with a smartphone or tablet, select this option, then launch FUJIFILM Camera Remote on the smart device and tap PAIRING REGISTRATION . |
| SELECT PAIRING DESTINATION | Choose a connection from a list of devices with which the camera has been paired using PAIRING REGISTRATION . Select NO CONNECTION to exit without connecting. |
| DELETE PAIRING REG. | Delete pairing information for selected devices. Choose the device in the device list. The selected device will also be removed from the devices listed in SELECT PAIRING DESTINATION . |
| Bluetooth ON/OFF | <ul style="list-style-type: none"> • ON: The camera automatically establishes a Bluetooth connection with paired devices when turned on. • OFF: The camera does not connect via Bluetooth. |
| AUTO IMAGE TRANSFER | <ul style="list-style-type: none"> • ON: Mark photos for upload as they are taken. Mark JPEG photos for upload as they are taken. • OFF: Photos are not marked for upload as they are taken. |
| SMARTPHONE SYNC. SETTING | <p>Choose whether to synchronize the camera to the time and/or location provided by a paired smartphone.</p> <ul style="list-style-type: none"> • LOCATION&TIME: Synchronize the time and location. • LOCATION: Synchronize the location. • TIME: Synchronize the time. • OFF: Synchronization off. |



- Install the latest version of the FUJIFILM Camera Remote app on your smartphone or tablet before pairing the device with your camera or uploading images.
- When **ON** is selected for both **Bluetooth ON/OFF** and **AUTO IMAGE TRANSFER** or images are currently selected for upload using the **IMAGE TRANSFER ORDER** option in the  (playback) menu, upload to paired devices will begin shortly after you exit to playback or turn the camera off. **IMAGE TRANSFER ORDER** can also be used to select pictures for upload when **AUTO IMAGE TRANSFER** is off.

NETWORK SETTING

Adjust settings for connection to wireless networks.


| Option | Description |
|--------------------------------------|---|
| WIRELESS ACCESS POINT SETTING | <ul style="list-style-type: none">• SIMPLE SETUP: Connect to an access point using simple settings.• MANUAL SETUP: Manually adjust settings for connection to a wireless network. Choose the network from a list (SELECT FROM NETWORK LIST) or enter the name manually (ENTER SSID). |
| WIRELESS IP ADDRESS SETTING | <ul style="list-style-type: none">• AUTO: The IP address is assigned automatically.• MANUAL: Assign an IP address manually. Manually choose the IP address (IP ADDRESS), network mask (NETMASK), and gateway address (GATEWAY ADDRESS). |

instax PRINTER CONNECTION SETTING

Adjust settings for connection to optional Fujifilm instax SHARE printers.


The Printer Name (SSID) and Password

The printer name (SSID) can be found on the bottom of the printer; the default password is "1111". If you have already chosen a different password to print from a smartphone, enter that password instead.



PC CONNECTION MODE

Adjust settings for connection to a computer.

| Option | Description |
|---------------------------------------|---|
| USB CARD READER | Connecting the camera to a computer via USB automatically enables data transfer mode, allowing data to be copied to the computer. The camera functions normally when not connected. |
| USB TETHER SHOOTING AUTO | Connecting the camera to a computer via USB automatically enables tethered shooting mode. You can also use FUJIFILM X Acquire to save and load camera settings, allowing you to reconfigure the camera in an instant or share settings with other cameras of the same type. The camera functions normally when not connected. |
| USB TETHER SHOOTING FIXED | The camera functions in tethered shooting mode even when not connected to a computer. At default settings, pictures are not saved to the memory card, but pictures taken while the camera is not connected will be transferred to the computer when it is connected. |
| WIRELESS TETHER SHOOTING FIXED | Choose this option for wireless remote photography. Select a network using  CONNECTION SETTING > NETWORK SETTING . |

| Option | Description |
|--|---|
| USB RAW CONV./ BACKUP RESTORE | <p>Connecting the camera to a computer via USB automatically enables USB RAW conversion/backup restore mode. The camera functions normally when not connected.</p> <ul style="list-style-type: none"> • USB RAW CONV. (requires FUJIFILM X RAW STUDIO): Use the camera's image processing engine to rapidly convert RAW files to high-quality JPEG images. • BACKUP RESTORE (requires FUJIFILM X Acquire): Save and load camera settings. Reconfigure the camera in an instant or share settings with other cameras of the same type. |








POWER MANAGEMENT > AUTO POWER OFF settings also apply during tethered shooting. Select **OFF** to prevent the camera turning off automatically.



Tethered shooting is available with software such as Hyper-Utility Software HS-V5 (available separately) or FUJIFILM X Acquire (available for free download from the Fujifilm website) or when the FUJIFILM Tether Shooting Plug-in PRO or Tether Shooting Plug-in (both available separately) is used with Adobe® Photoshop® Lightroom® Classic CC.

GENERAL SETTINGS

Adjust settings for connection to wireless networks.

| Option | Description |
|---|---|
| NAME | Choose a name (NAME) to identify the camera on the wireless network (the camera is assigned a unique name by default). |
| RESIZE IMAGE FOR SMARTPHONE  | Choose whether to resize images for upload to smartphones. Resizing applies only to the copy uploaded to the smartphone; the original is not affected. <ul style="list-style-type: none"> • ON: Larger images are resized to  for upload. This setting is recommended. • OFF: Images are uploaded at their original size. |
| GEOTAGGING | Choose whether location data downloaded from a smartphone are embedded in pictures as they are taken. |
| LOCATION INFO | Display the location data last downloaded from a smartphone. |
|  BUTTON SETTING | Choose the role played by function buttons assigned the WIRELESS COMMUNICATION function. <ul style="list-style-type: none"> •  PAIRING/TRANSFER ORDER: The buttons can be used for pairing and selecting images for transfer. •  WIRELESS COMMUNICATION: The buttons can be used for wireless connections. |

INFORMATION

View the camera's MAC and Bluetooth address.

RESET WIRELESS SETTING

Restore wireless settings to their default values.

[illegible]



9

Shortcuts

Shortcut Options

Customize camera controls to suit your style or situation.

Frequently-used options can be added to the **Q** menu or a custom “my” menu or assigned to an **Fn** (function) button for direct access:


| Shortcut Option | Description |  |
|-----------------------------|--|---|
| The Q menu | The Q menu is displayed by pressing the Q button. Use the Q menu to view or change the options selected for frequently-used menu items. | 193 |
| “My menu” | Add frequently-used options to this custom menu, which can be viewed by pressing MENU/OK and selecting the  (“MY MENU”) tab. | 200 |
| The function buttons | Use the function buttons for direct access to selected features. | 196 |

The Q (Quick Menu) Button

Press **Q** for quick access to selected options.

The Quick Menu Display

At default settings, the quick menu contains the following items:



- | | |
|-------------------------|--------------------------|
| ① SELECT CUSTOM SETTING | ⑨ HIGHLIGHT TONE |
| ② ISO | ⑩ SHADOW TONE |
| ③ DYNAMIC RANGE | ⑪ COLOR |
| ④ WHITE BALANCE | ⑫ SHARPNESS |
| ⑤ NOISE REDUCTION | ⑬ SELF-TIMER |
| ⑥ IMAGE SIZE | ⑭ AF MODE |
| ⑦ IMAGE QUALITY | ⑮ FLASH FUNCTION SETTING |
| ⑧ FILM SIMULATION | ⑯ EVF/LCD BRIGHTNESS |

The quick menu shows the options currently selected for items ②–⑯, which can be changed as described on page 195.


SELECT CUSTOM SETTING

The **Q** **IMAGE QUALITY SETTING** > **SELECT CUSTOM SETTING** item (item ①) shows the current custom settings bank:

- **BASE**: No custom settings bank selected.
- **C 1–C7**: Select a bank to view the settings saved using the **Q** **IMAGE QUALITY SETTING** > **EDIT/SAVE CUSTOM SETTING** option.
- **BASE** – **BASE** **C 1–C7**: The current custom settings bank.



Viewing and Changing Settings

- 1 Press **Q** to display the quick menu during shooting.




- 2 Use the focus stick (focus lever) to highlight items and rotate the rear command dial to change.

- Changes are not saved to the current settings bank.
- Settings that differ from those in the current settings bank (**C1–C7**) are shown in red.



- 3 Press **Q** to exit when settings are complete.


 The quick menu can also be edited using touch controls.

Editing the Quick Menu

To choose the items displayed in the quick menu:

- 1 Press and hold the **Q** button during shooting.

- 2 The current quick menu will be displayed; use the focus stick (focus lever) to highlight the item you wish to change and press **MENU/OK**.



- 3 Highlight any of the following options and press **MENU/OK** to assign it to the selected position.

- IMAGE SIZE
- IMAGE QUALITY
- FILM SIMULATION*
- GRAIN EFFECT*
- COLOR CHROME EFFECT*
- DYNAMIC RANGE*
- WHITE BALANCE*
- HIGHLIGHT TONE*
- SHADOW TONE*
- COLOR*
- SHARPNESS*
- NOISE REDUCTION*
- SELECT CUSTOM SETTING*
- AF MODE
- FACE/EYE DETECTION SETTING
- MF ASSIST
- TOUCH SCREEN MODE
- SELF-TIMER
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION
- ISO*
- FLASH FUNCTION SETTING
- FLASH COMPENSATION
- MOVIE MODE
- MIC LEVEL ADJUSTMENT
- EVF/LCD BRIGHTNESS
- EVF/LCD COLOR
- NONE

* Stored in custom settings bank.



- Select **NONE** to assign no option to the selected position.
- When **SELECT CUSTOM SETTING** is selected, current settings are shown in the quick menu by the label **BASE**.



The quick menu can also be edited using **■ BUTTON/DIAL SETTING > EDIT/SAVE QUICK MENU**.

The Fn (Function) Buttons


Assign a role to the function buttons for quick access to the selected feature.



The functions assigned to **T-Fn1** through **T-Fn4** can be accessed by flicking the monitor.


The default assignments are:

Fn1 button




Sensitivity

Fn2 button




Front command dial switch

Fn3 button




Exposure lock

Fn4 button




Focus lock

Fn5 button




AF mode

T-Fn1 (flick up)




Histogram

T-Fn2 (flick left)




Film simulation

T-Fn3 (flick right)




White balance

T-Fn4 (flick down)




Electronic level

Drive button



Drive button

Center of rear command dial




Focus check

Assigning Roles to the Function Buttons

To assign roles to the buttons:

- 1 Press and hold the **DISP/BACK** button until a control selection menu is displayed.
- 2 Highlight a control and press **MENU/OK**.
- 3 Highlight the desired role and press **MENU/OK** to assign it to the selected control. Choose from:
 - IMAGE SIZE
 - IMAGE QUALITY
 - RAW
 - FILM SIMULATION
 - GRAIN EFFECT
 - COLOR CHROME EFFECT
 - DYNAMIC RANGE
 - WHITE BALANCE
 - SELECT CUSTOM SETTING
 - FOCUS AREA
 - FOCUS CHECK
 - AF MODE
 - RAPID AF
 - FACE/EYE DETECTION SETTING
 - DRIVE BUTTON
 - SELF-TIMER
 - AE BKT SETTING
 - FOCUS BKT SETTING
 - PHOTOMETRY
 - SHUTTER TYPE
 - FLICKER REDUCTION
 - ISO
 - 35mm FORMAT MODE
 - WIRELESS COMMUNICATION
 - FLASH FUNCTION SETTING
 - TTL-LOCK
 - MODELING FLASH
 - MIC LEVEL ADJUSTMENT
 - PREVIEW DEPTH OF FIELD
 - PREVIEW EXP/WB IN MANUAL MODE
 - NATURAL LIVE VIEW
 - HISTOGRAM
 - ELECTRONIC LEVEL
 - LARGE INDICATORS MODE
 - FRONT COMMAND DIAL SWITCH
 - AE LOCK ONLY
 - AF LOCK ONLY
 - AE/AF LOCK
 - AF-ON
 - LOCK SETTING
 - AUTO IMAGE TRANSFER
 - SELECT PAIRING DESTINATION
 - Bluetooth ON/OFF
 - PLAYBACK
 - NONE (control disabled)



- **AE LOCK ONLY**, **AF LOCK ONLY**, **AE/AF LOCK**, and **AF-ON** cannot be assigned to the touch function buttons (**T-Fn1** through **T-Fn4**).
- Button assignments can also be selected using **FUNCTION/DIAL SETTING > FUNCTION (Fn) SETTING**.

AF-ON

If **AF-ON** is selected, you can press the control instead of keeping the shutter button pressed halfway.

MODELING FLASH

If **MODELING FLASH** is selected when a compatible shoe-mounted flash unit is attached, you can press the control to test-fire the flash and check for shadows and the like (modeling flash).


TTL-LOCK

If **TTL-LOCK** is selected, you can press the control to lock flash output according to the option selected for **FLASH SETTING > TTL-LOCK MODE** (125).

MY MENU

Access a personalized menu of frequently-used options.

To display “my menu”, press **MENU/OK** in the shooting display and select the **MY** (MY MENU) tab.




The **MY** tab is only available if options have been assigned to **MY MENU**.

MY MENU SETTING


To choose the items listed in the **MY** (MY MENU) tab:

- 1 Highlight **USER SETTING > MY MENU SETTING** in the **(SET UP)** tab and press **MENU/OK**.




To reorder items, select **RANK ITEMS**. To delete items, select **REMOVE ITEMS**.

- 2 Press the focus stick (focus lever) up or down to highlight **ADD ITEMS** and press **MENU/OK**. Options that can be added to “my menu” are highlighted in blue.



Items currently in “my menu” are indicated by check marks.

- 3 Choose a position for the item and press **MENU/OK**. The item will be added to “my menu”.



- 4 Press **MENU/OK** to return to the edit display.
- 5 Repeat Steps 3 and 4 until all the desired items have been added.



“My menu” can contain up to 16 items.

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.


10

Peripherals and Optional Accessories

Lenses

The camera can be used with lenses for the FUJIFILM G-mount.

Lens Parts



① Lens hood

② Mounting marks

③ Focus ring

④ Aperture ring lock release


⑤ Mounting marks (focal length)

⑥ Aperture ring

⑦ Lens signal contacts

⑧ Front lens cap

⑨ Rear lens cap


 A GF63mmF2.8 R WR lens is used here for illustrative purposes.

Lens Care

- Use a blower to remove dust, then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of Fujifilm lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied.
- Replace the front and rear caps when the lens is not in use.

Removing Lens Caps


Remove lens caps as shown.



 Lens caps may differ from those shown.


Attaching Lens Hoods




When attached, lens hoods reduce glare and protect the front lens element.




Aperture ring

Rotate the lens aperture ring to choose the aperture (f-number).



| Setting | Description |
|---|--|
| C () | Set aperture to the value chosen with the camera command dial. |
| A () | Set aperture to the value chosen automatically by the camera. |
| Other values () | Set aperture to the selected value. |

 To select **C** or **A**, or to select another value after selecting **C** or **A**, press the aperture ring lock release while rotating the aperture ring.

External Flash Units

Flash units can be mounted on the hot shoe or connected via the sync terminal.

Use optional external flash units for flash photography. Some units support high-speed sync (FP) and can be used at shutter speeds faster than the flash sync speed, while others can function as master flash units controlling remote units via optical wireless flash control.




You may be unable to test-fire the flash in some circumstances, for example when a setup menu is displayed on the camera.


Red-Eye Removal

Red-eye removal is available when an option other than **OFF** is selected for **FLASH SETTING > RED EYE REMOVAL** and a “FACE ON” option is selected for **AF/MF SETTING > FACE/EYE DETECTION SETTING**. Red-eye removal minimizes “red-eye” caused when light from the flash is reflected from the subject’s retinas.


Flash Settings

To adjust settings for a flash unit mounted on the hot shoe or connected via the sync terminal:


- 1 Connect the unit to the camera.
- 2 In shooting mode, select **FLASH FUNCTION SETTING** in the  (**FLASH SETTING**) menu tab. The options available vary with the flash unit.



| Menu | Description | |
|-------------------------|--|-----|
| SYNC TERMINAL | Displayed when no compatible flash unit is connected or if a unit is connected via the sync terminal or uses only the X-contact on the hot shoe. | 209 |
| SHOE MOUNT FLASH | Displayed when an optional flash unit is mounted on the hot shoe and turned on. | 210 |
| MASTER (OPTICAL) | Displayed if an optional flash unit functioning as a master flash for Fujifilm optical wireless remote flash control is connected and turned on. | 213 |

 **SYNC TERMINAL** will be also displayed if an incompatible flash unit or no flash unit is connected.


- 3 Highlight items using the focus stick (focus lever) and rotate the rear command dial to change the highlighted setting.



- 4 Press **DISP/BACK** to put the changes into effect.

SYNC TERMINAL


The following options are available when no compatible flash unit is connected or if a unit is connected via the sync terminal or uses only the X-contact on the hot shoe.



| Setting | Description |
|----------------------|--|
| ① Flash control mode | <p>Choose from the following options:</p> <ul style="list-style-type: none"> • M: A trigger signal is transmitted via the hot shoe X contacts when a picture is taken. Choose a shutter speed slower than the sync speed; even slower speeds may be required if the unit uses long flashes or has a slow response time. • OFF (OFF): The trigger signal is disabled. |
| ② Sync | <p>Choose whether the flash is timed to fire immediately after the shutter opens ($\frac{1}{2}$ FRONT / 1ST CURTAIN) or immediately before it closes ($\frac{1}{2}$ REAR / 2ND CURTAIN). 1ST CURTAIN is recommended in most circumstances.</p> |


The Sync Terminal

Use the sync terminal to connect flash units that require a sync cable.









SHOE MOUNT FLASH

The following options are available when an optional shoe-mounted flash unit is attached and turned on.



| Setting | Description |
|----------------------|---|
| ① Flash control mode | <p>The flash control mode selected with the flash unit. This can in some cases be adjusted from the camera; the options available vary with the flash.</p> <ul style="list-style-type: none"> • TTL: TTL mode. Adjust flash compensation (②). • M: The flash fires at the selected output regardless of subject brightness or camera settings. Output in some cases can be adjusted from the camera (②). • MULTI: Repeating flash. Compatible shoe-mounted flash units will fire multiple times with each shot. • OFF (OFF): The flash does not fire. Some flash units can be turned off from the camera. |


| Setting | Description |
|-----------------------------|--|
| ② Flash compensation/output | <p>The options available vary with flash control mode.</p> <ul style="list-style-type: none"> • TTL: Adjust flash compensation (the full value may not be applied if the limits of the flash control system are exceeded). In the cases of the EF-X20, EF-20, and EF-42, the selected value is added to the value selected with the flash unit. • M/MULTI: Adjust flash output (compatible units only). Choose from values expressed as fractions of full power, from $\frac{1}{4}$ (mode M) or $\frac{1}{4}$ (MULTI) down to $\frac{1}{512}$ in increments equivalent to $\frac{1}{3}$ EV. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results. |
| ③ Flash mode (TTL) | <p>Choose a flash mode for TTL flash control. The options available vary with the shooting mode (P, S, A, or M) selected.</p> <ul style="list-style-type: none"> • FLASH AUTO: The flash fires only as required; flash level is adjusted according to subject brightness. A  icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken. • STANDARD: The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released. • SLOW SYNC.: Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released. |
| ④ Sync | <p>Control flash timing.</p> <ul style="list-style-type: none"> • FRONT (1ST CURTAIN): The flash fires immediately after the shutter opens (generally the best choice). • REAR (2ND CURTAIN): The flash fires immediately before the shutter closes. • AUTO FP(HSS): High-speed sync (compatible units only). The camera automatically engages front-curtain high-speed sync at shutter speeds faster than the flash sync speed. Equivalent to 1ST CURTAIN when MULTI is selected for flash control mode. |

| Setting | Description |
|-----------------------|--|
| ⑤ Zoom | The angle of illumination (flash coverage) for units that support flash zoom. Some units allow the adjustment to be made from the camera. If AUTO is selected, zoom will automatically be adjusted to match coverage to lens focal length. |
| ⑥ Lighting | If the unit supports this feature, choose from: <ul style="list-style-type: none"> •  (FLASH POWER PRIORITY): Gain range by slightly reducing coverage. •  (STANDARD): Match coverage to picture angle. •  (EVEN COVERAGE PRIORITY): Slightly increase coverage for more even lighting. |
| ⑦ LED light | Choose how the built-in LED light functions during still photography (compatible units only): as a catchlight ( / CATCHLIGHT), as an AF-assist illuminator (AF/AF ASSIST), or as both a catchlight and an AF-assist illuminator ( / AF ASSIST+CATCHLIGHT). Choose OFF to disable the LED during photography. |
| ⑦ Number of flashes * | Choose the number of times the flash fires each time the shutter is released in MULTI mode. |
| ⑧ Frequency * | Choose the frequency at which the flash fires in MULTI mode. |


* Full value may not be applied if limits of flash control system are exceeded.

MASTER(OPTICAL)








The options will be displayed if the unit is currently functioning as master flash for Fujifilm optical wireless remote flash control.



The master and remote units can be placed in up to three groups (A, B, and C) and flash mode and flash level adjusted separately for each group. Four channels are available for communication between the units; separate channels can be used for different flash systems or to prevent interference when multiple systems are operating in close proximity.



| Setting | Description |
|---------------------------------------|---|
| ① Flash control mode (group A) | Choose flash control modes for groups A, B, and C. TTL% is available for groups A and B only. <ul style="list-style-type: none"> • TTL: The units in the group fire in TTL mode. Flash compensation can be adjusted separately for each group. • TTL%: If TTL% is selected for either group A or B, you can specify the output of the selected group as a percentage of the other and adjust overall flash compensation for both groups. |
| ② Flash control mode (group B) | <ul style="list-style-type: none"> • M: In mode M, the units in the group fire at the selected output (expressed as a fraction of full power) regardless of subject brightness or camera settings. • MULTI: Choosing MULTI for any group sets all the units in all groups to repeating flash mode. All units will fire multiple times with each shot. • OFF (OFF): If OFF is selected, the units in the group will not fire. |
| ③ Flash control mode (group C) | |
| ④ Flash compensation/output (group A) | Adjust flash level for the selected group according to option selected for flash control mode. Note that the full value may not be applied if the limits of the flash control system are exceeded. |
| ⑤ Flash compensation/output (group B) | <ul style="list-style-type: none"> • TTL: Adjust flash compensation. • M/MULTI: Adjust flash output. • TTL%: Choose the balance between groups A and B and adjust overall flash compensation. |
| ⑥ Flash compensation/output (group C) | |

| Setting | Description |
|--------------------|--|
| ⑦ Flash mode (TTL) | <p>Choose a flash mode for TTL flash control. The options available vary with the shooting mode (P, S, A, or M) selected.</p> <ul style="list-style-type: none"> •  (FLASH AUTO): The flash fires only as required; flash level is adjusted according to subject brightness. A  icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken. •  (STANDARD): The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released. •  (SLOW SYNC.): Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released. |
| ⑧ Sync | <p>Control flash timing.</p> <ul style="list-style-type: none"> •  (1ST CURTAIN): The flash fires immediately after the shutter opens (generally the best choice). •  (2ND CURTAIN): The flash fires immediately before the shutter closes. •  (AUTO FP(HSS)): High-speed sync (compatible units only). The camera automatically engages front-curtain high-speed sync at shutter speeds faster than the flash sync speed. Equivalent to 1ST CURTAIN when MULTI is selected for flash control mode. |
| ⑨ Zoom | <p>The angle of illumination (flash coverage) for units that support flash zoom. Some units allow the adjustment to be made from the camera. If AUTO is selected, zoom will automatically be adjusted to match coverage to lens focal length.</p> |

| Setting | Description |
|---------------------|---|
| ⑩ Lighting | <p>If the unit supports this feature, choose from:</p> <ul style="list-style-type: none"> ➡ (FLASH POWER PRIORITY): Gain range by slightly reducing coverage. ➡ (STANDARD): Match coverage to picture angle. ➡ (EVEN COVERAGE PRIORITY): Slightly increase coverage for more even lighting. |
| ⑪ Master | <p>Assign the master flash to group A (Gr A), B (Gr B), or C (Gr C). If OFF is selected, output from the master flash will be held to a level that does not affect the final picture. Available only if the unit is mounted on the camera hot shoe as a master flash for Fujifilm optical wireless remote flash control in TTL, TTL%, or M mode.</p> |
| ⑪ Number of flashes | <p>Choose the number of times the flash fires each time the shutter is released in MULTI mode.</p> |
| ⑫ Channel | <p>Choose the channel used by the master flash for communication with the remote flash units. Separate channels can be used for different flash systems or to prevent interference when multiple systems are operating in close proximity.</p> |
| ⑫ Frequency | <p>Choose the frequency at which the flash fires in MULTI mode.</p> |

11

Connections


HDMI Output

Camera shooting and playback displays can be output to HDMI devices.

Connecting to HDMI Devices

Connect the camera to TVs or other HDMI devices using a third-party HDMI cable.

- 1 Turn the camera off.
- 2 Connect the cable as shown below.



- 3 Configure the device for HDMI input as described in the documentation supplied with the device.
- 4 Turn the camera on. The contents of the camera display will be shown on the HDMI device. The camera display turns off in playback mode (📖 219).




- Making sure the connectors are fully inserted.
- The USB cable cannot be used while an HDMI cable is connected.
- Use an HDMI cable no more than 1.5 m (4.9 ft.) long.

Shooting

Shoot photos and record movies while viewing the scene through the camera lens or saving footage to the HDMI device.

Playback

To start playback, press the camera  button. The camera monitor turns off and pictures and movies are output to the HDMI device. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.



Some televisions may briefly display a black screen when movie playback begins.

Wireless Connections

(Bluetooth®, Wireless LAN/Wi-Fi)

Access wireless networks and connect to computers, smartphones, or tablets. For more information, visit:

<http://fujifilm-dsc.com/wifi/>

Smartphones and Tablets: FUJIFILM Camera Remote

Connect to the camera via Bluetooth or wireless LAN.



To establish a wireless connection to the camera, you will need to install the latest version of the FUJIFILM Camera Remote app on your smartphone or tablet.

FUJIFILM Camera Remote

Once a connection has been established, you can use FUJIFILM Camera Remote to:

- Control the camera and take pictures remotely
- Receive pictures uploaded from the camera
- Browse the pictures on the camera and download selected pictures
- Upload location data to the camera
- Release the camera shutter
- Update camera firmware

For downloads and other information, visit:

http://app.fujifilm-dsc.com/en/camera_remote/

SmartPhones and Tablets: Bluetooth® Pairing

Use **CONNECTION SETTING > Bluetooth SETTINGS > PAIRING REGISTRATION** to pair the camera with smartphones or tablets. Pairing offers a simple method for downloading photos from the camera.



- Photos are downloaded via a wireless connection.
- Once pairing is complete, you will be able to synchronize the camera clock and location data with the smartphone or tablet (185).
- You can choose a connection from up to 7 paired smartphones or tablets.


Smartphones and Tablets: Wireless LAN

Use the **WIRELESS COMMUNICATION** options in **SHOOTING SETTING** or the playback menu to connect to a smartphone or tablet via a Wireless LAN.



Tethered Shooting: FUJIFILM X Acquire/FUJIFILM Tether Shooting Plug-in/FUJIFILM Tether Shooting Plug-in PRO/Hyper-Utility Software HS-V5

- Before proceeding, select **WIRELESS TETHER SHOOTING FIXED** for **CONNECTION SETTING > PC CONNECTION MODE** in the camera menus.
- FUJIFILM X Acquire, the FUJIFILM Tether Shooting Plug-in, FUJIFILM Tether Shooting Plug-in PRO, and Hyper-Utility Software HS-V5 can be used for tethered shooting.



- For more information, visit the following website:
<http://app.fujifilm-dsc.com/en/#tether>
- For more information on FUJIFILM X Acquire, the FUJIFILM Tether Shooting Plug-in, FUJIFILM Tether Shooting Plug-in PRO, and Hyper-Utility Software HS-V5, see "Software from Fujifilm" (📖 234).


Connecting to Computers via USB

Connect the camera to a computer to download pictures or take pictures remotely.



Before downloading pictures or taking pictures remotely, connect the camera to a computer and check that it functions normally.

- 1 Turn the computer on.
- 2 Adjust settings according to whether you will be using the camera for tethered shooting (📖 226), copying pictures to a computer (📖 227), save RAW pictures in other formats (📖 228), or Saving and Loading Camera Settings (📖 228).
- 3 Turn the camera off.
- 4 Connect a USB cable.



USB connector (Type-C)



The USB cable must be no more than 1.5 m (4.9 ft.) long and be suitable for data transfer.

5 Turn the camera on.

6 Copy pictures to your computer.


- **Tethered shooting:** During tethered shooting, you can copy pictures using tethered shooting software such as the FUJIFILM Tether Shooting Plug-in PRO.
- **Image transfer:** Use MyFinePix Studio or applications provided with your operating system.
- **RAW conversion:** Process RAW images using FUJIFILM X RAW STUDIO. The power of the camera's image processing engine is used for rapid processing.
- **Saving and loading camera settings:** Use FUJIFILM X Acquire to save or load camera settings. Save your preferred settings to a file in a single operation and copy them to multiple cameras.



- Turn the camera off before disconnecting the USB cable.
- When connecting USB cables, be sure the connectors are fully inserted in the correct orientation. Connect the camera directly to the computer; do not use a USB hub or keyboard.
- Loss of power during transfer could result in loss of data or damage to the memory card. Insert a fresh or fully-charged battery before connecting the camera.
- If a memory card containing a large number of images is inserted, there may be a delay before the software starts and you may be unable to import or save images. Use a memory card reader to transfer pictures.
- Make sure that the indicator lamp is off or lit green before turning the camera off.
- Do not disconnect the USB cable while transfer is in progress. Failure to observe this precaution could result in loss of data or damage to the memory card.
- Disconnect the camera before inserting or removing memory cards.
- In some cases, it may not be possible to access pictures saved to a network server using the software in the same way as on a stand-alone computer.
- Do not immediately remove the camera from the system or disconnect the USB cable once the message stating that copying is in progress clears from the computer display. If the number of images copied is very large, data transfer may continue after the message has ceased to be displayed.
- The user bears all applicable fees charged by the phone company or Internet service provider when using services that require an Internet connection.

Tethered Shooting: FUJIFILM X Acquire/FUJIFILM Tether Shooting Plug-in/FUJIFILM Tether Shooting Plug-in PRO/Hyper-Utility Software HS-V5


- Before proceeding, select **USB TETHER SHOOTING AUTO** for **CONNECTION SETTING > PC CONNECTION MODE** in the camera menus.
- FUJIFILM X Acquire, the FUJIFILM Tether Shooting Plug-in, FUJIFILM Tether Shooting Plug-in PRO, and Hyper-Utility Software HS-V5 can be used for tethered shooting.



- Choose **USB TETHER SHOOTING FIXED** if the camera will be used solely for tethered shooting. Note that if the USB cable is disconnected, the camera will continue to function in tethered mode and pictures will not be saved to the camera memory card.
- For more information, visit the following website:
<http://app.fujifilm-dsc.com/en/#tether>
- For more information on FUJIFILM X Acquire, the FUJIFILM Tether Shooting Plug-in, FUJIFILM Tether Shooting Plug-in PRO, and Hyper-Utility Software HS-V5, see “Software from Fujifilm” (📖 234).

Copying Pictures to a Computer

- Before copying pictures to a computer, select **USB CARD READER** for **CONNECTION SETTING > PC CONNECTION MODE**.
- The software that can be used to copy pictures varies with your computer operating system.



Mac OS X/macOS

Pictures can be copied to your computer using Image Capture (supplied with your computer) or other software.

Windows


Use MyFinePix Studio to copy pictures to your computer, where they can be stored, viewed, organized, and printed.



For more information on MyFinePix Studio, see “Software from Fujifilm” (p. 234).

Copying RAW Images in Other Formats: FUJIFILM X RAW STUDIO


- Before proceeding, select **USB RAW CONV./BACKUP RESTORE** for **CONNECTION SETTING > PC CONNECTION MODE** in the camera menus.
- FUJIFILM X RAW STUDIO can be used to save copies of RAW images in other formats.



 For more information on FUJIFILM X RAW STUDIO, see “Software from Fujifilm” (📖 234).

Saving and Loading Camera Settings (FUJIFILM X Acquire)

- Before proceeding, select **USB RAW CONV./BACKUP RESTORE** for **CONNECTION SETTING > PC CONNECTION MODE** in the camera menus.
- FUJIFILM X Acquire can be used to save and load camera settings.



 For more information on FUJIFILM X Acquire, see “Software from Fujifilm” (📖 234).

instax SHARE Printers


Print pictures from your digital camera to instax SHARE printers.

Establishing a Connection


Select **CONNECTION SETTING** > **instax PRINTER CONNECTION SETTING** and enter the instax SHARE printer name (SSID) and password.


The Printer Name (SSID) and Password

The printer name (SSID) can be found on the bottom of the printer; the default password is "1111". If you have already chosen a different password to print from a smartphone, enter that password instead.




Printing Pictures

- 1 Turn the printer on.
- 2 Select  **PLAY BACK MENU > instax PRINTER PRINT**. The camera will connect to the printer.



- 3 Use the focus stick (focus lever) to display the picture you want to print, then press **MENU/OK**.



-  • Pictures taken with other cameras cannot be printed.
- The area printed is smaller than the area visible in the LCD monitor.
- The displays may vary depending on the printer connected.

- 4 The picture will be sent to the printer and printing will start.

12

Technical Notes

Accessories from Fujifilm

The following optional accessories are available from Fujifilm. For the latest information on the accessories available in your region, check with your local Fujifilm representative or visit http://www.fujifilm.com/products/digital_cameras/index.html.

Rechargeable Li-ion batteries

NP-T125: Additional high-capacity NP-T125 rechargeable batteries can be purchased as required.

Battery chargers

BC-T125: Replacement battery chargers can be purchased as required.

AC power adapters

AC-15V: Use this 100–240 V, 50/60 Hz AC power adapter for extended shooting and playback, when copying pictures to a computer. It can also be used to charge the battery without removing it from the camera.

FUJINON lenses

GF-series lenses: Interchangeable lenses for use exclusively with the FUJIFILM G-mount.

Mount adapters

H MOUNT ADAPTER G: This mount adapter allows the camera to be used with SUPER EBC FUJINON accessories for the GX645AF, giving you the use of one additional teleconverter and nine different lenses.

Macro extension tubes

MCEX-18G WR/MCEX-45G WR: Mount this adapter between the lens and the camera body for macro photography with large reproduction ratios.

View camera adapters

VIEW CAMERA ADAPTER G: This adapter is for use with lenses for older FUJINON large-format cameras, including lenses in the CM FUJINON series.

Shoe-mounted flash units

EF-X500: This clip-on flash unit has a Guide Number of 50/164 (ISO 100, m/ft.) and supports FP (high-speed sync), allowing it to be used at shutter speeds that exceed the flash sync speed. Powered by four AA batteries or an optional EF-BP1 battery pack, it supports manual and TTL flash control and auto power zoom in the range 24–105 mm (35 mm format equivalent) and features Fujifilm optical wireless flash control, allowing it to be used as a master or remote flash unit for remote wireless flash photography. The flash head can be rotated 90° up, 10° down, 135° left, or 180° right for bounce lighting.

EF-42: This clip-on flash unit (powered by four AA batteries) has a Guide Number of 42/137 (ISO 100, m/ft.) and supports manual and TTL flash control and auto power zoom in the range 24–105 mm (35 mm format equivalent). The flash head can be rotated 90° up, 180° left, or 120° right for bounce lighting.

EF-X20: This clip-on flash unit has a Guide Number of 20/65 (ISO 100, m/ft.). Powered by two AAA batteries, this light, compact unit features a dial for adjusting TTL flash compensation or manual flash output.

EF-20: This clip-on flash unit (powered by two AA batteries) has a Guide Number of 20/65 (ISO 100, m/ft.) and supports TTL flash control (manual flash control is not supported). The flash head can be rotated upwards 90° for bounce lighting.

Remote releases

RR-100: Use to reduce camera shake or keep the shutter open during a time exposure.

Stereo microphones

MIC-ST1: An external microphone for movie recording.

Body caps

BCP-002: Cover the camera lens mount when no lens is attached.

instax SHARE printers

SP-1/SP-2/SP-3: Connect via wireless LAN to print pictures on instax film.

Software from Fujifilm

The camera can be used with the following Fujifilm software.

FUJIFILM Camera Remote

Establish a wireless connection between your camera and a smartphone or tablet (📖 220).

http://app.fujifilm-dsc.com/en/camera_remote/

MyFinePix Studio

Manage, view, print, and edit the many images downloaded from your digital camera (📖 227).

<http://fujifilm-dsc.com/mfs/>

Once download is complete, double-click the downloaded file ("MFPS_Setup.EXE") and follow the on-screen instructions to complete installation.

RAW FILE CONVERTER EX

View RAW pictures on your computer and convert them into other formats.

<http://fujifilm-dsc.com/rfc/>

FUJIFILM X RAW STUDIO

When the camera is connected to a computer via USB, FUJIFILM X RAW STUDIO can use the camera's unique image processing engine to rapidly convert RAW files to create high-quality images in other formats.

<http://fujifilm-x.com/x-stories/fujifilm-x-raw-studio-features-users-guide/>

FUJIFILM X Acquire

This application for Windows and macOS lets you connect to the camera via USB or Wi-Fi and automatically download photos to a specified folder as they are taken.

<http://fujifilm-x.com/x-stories/fujifilm-x-acquire-features-users-guide/>

FUJIFILM Tether Shooting Plug-ins for Lightroom

Plug-ins for Adobe® Photoshop® Lightroom® Classic CC.

- *FUJIFILM Tether Shooting Plug-in PRO*

<http://fujifilm-x.com/x-stories/fujifilm-tether-plug-in-pro-features/>

- *FUJIFILM Tether Shooting Plug-in*

http://www.fujifilm.com/products/digital_cameras/accessories/others/#soft

Hyper-Utility Software HS-V5

This computer application lets you connect to the camera via USB or Wi-Fi, control the camera remotely, and save pictures taken with the camera directly to the computer.

http://www.fujifilm.com/products/digital_cameras/accessories/others/#soft

For Your Safety

IMPORTANT SAFETY INSTRUCTIONS

- **Read Instructions:** All the safety and operating instructions should be read before the appliance is operated.
- **Retain Instructions:** The safety and operating instructions should be retained for future reference.
- **Heed Warnings:** All warnings on the appliance and in the operating instructions should be adhered to.
- **Follow Instructions:** All operating and use instructions should be followed.

Installation

Power Sources: This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For video products intended to operate from battery power, or other sources, refer to the operating instructions.

Grounding or Polarization: This video product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

Alternate Warnings: This video product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

Overloading: Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

Ventilation: Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the video product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface.

This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. This video product should never be placed near or over a radiator or heat register.

Attachments: Do not use attachments not recommended by the video product manufacturer as they may cause hazards.

Water and Moisture: Do not use this video product near water—for example, near a bath tub, wash bowl, kitchen sink, or laundry pool, in a wet basement, or near a swimming pool, and the like.

Power-Cord Protection: Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

Accessories: Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.


An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



Antennas

Outdoor Antenna Grounding: If an outside antenna or cable system is connected to the video product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code, ANSI/NFPA No. 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE



Power Lines: An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

Use

Cleaning: Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Object and Liquid Entry: Never push objects of any kind into this video product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product.

Lightning: For added protection for this video product receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

Service

Servicing: Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service: Unplug this video product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or plug is damaged
- If liquid has been spilled, or objects have fallen into the video product.
- If the video product has been exposed to rain or water.
- If the video product has been dropped or the cabinet has been damaged.

If the video product does not operate normally follow the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.

When the video product exhibits a distinct change in performance — this indicates a need for service.

Replacement Parts: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

Safety Check: Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.



Be sure to read these notes before use

Safety Notes




- Make sure that you use your camera correctly. Read these safety notes and your *Owner's Manual* carefully before use.
- After reading these safety notes, store them in a safe place.

About the Icons




The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.

| | |
|---|--|
|  | WARNING This icon indicates that death or serious injury can result if the information is ignored. |
|  | CAUTION This icon indicates that personal injury or material damage can result if the information is ignored. |

The icons shown below are used to indicate the nature of the instructions which are to be observed.

| | |
|---|---|
|  | Triangular icons tell you that this information requires attention ("Important"). |
|  | Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited"). |
|  | Filled circles with an exclamation mark indicate an action that must be performed ("Required"). |

The symbols on the product (including the accessories) represent the following:

| | |
|---|---|
|  | AC |
|  | DC |
|  | Class II equipment (The construction of the product is double-insulated.) |

⚠ WARNING

If a problem arises, turn the camera off, remove the battery, and disconnect and unplug the AC power adapter.















Continued use of the camera when it is emitting smoke, is emitting any unusual odor, or is in any other abnormal state can cause a fire or electric shock. Contact your Fujifilm dealer.















Do not allow water or foreign objects to enter the camera. If water or foreign objects get inside the camera, turn the camera off, remove the battery, and disconnect and unplug the AC power adapter. Continued use of the camera can cause a fire or electric shock. Contact your Fujifilm dealer.













Do not use the camera in the bathroom or shower. This can cause a fire or electric shock.



|  WARNING | |
|--|--|
|  | Never attempt to change or take apart the camera (never open the case). Failure to observe this precaution can cause fire or electric shock. |
|  | Should the case break open as the result of a fall or other accident, do not touch the exposed parts. Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation. |
|  | Do not change, heat or unduly twist or pull the connection cord and do not place heavy objects on the connection cord. These actions could damage the cord and cause a fire or electric shock. If the cord is damaged, contact your Fujifilm dealer. |
|  | Do not place the camera on an unstable surface. This can cause the camera to fall or tip over and cause injury. |
|  | Never attempt to take pictures while in motion. Do not use the camera while walking or driving. This can result in you falling down or being involved in a traffic accident. |
|  | Do not touch any metal parts of the camera during a thunderstorm. This can cause an electric shock due to induced current from the lightning discharge. |
|  | Do not use the battery except as specified. Load the battery as shown by the indicator. |
|  | Do not disassemble, modify, or heat batteries. Do not drop, strike, or throw batteries or otherwise subject them to strong impacts. Do not use batteries that show signs of leaking, deformation, discoloration, or other abnormalities. Use only designated chargers to recharge rechargeable batteries and do not attempt to recharge non-rechargeable Li-ion or alkaline batteries. Do not short batteries or store them with metallic objects. Failure to observe these precautions could result in the batteries overheating, igniting, rupturing, or leaking, causing fire, burns, or other injury. |
|  | Use only batteries or AC power adapters specified for use with this camera. Do not use voltages other than the power supply voltage shown. The use of other power sources can cause a fire. |
|  | If the battery leaks and fluid gets in contact with your eyes, skin or clothing, flush the affected area with clean water and seek medical attention or call an emergency number right away. |
|  | Do not use the charger to charge batteries other than those specified here. The supplied charger is for use only with batteries of the type supplied with the camera. Using the charger to charge conventional batteries or other types of rechargeable batteries can cause the battery to leak, overheat or burst. |


|  WARNING | |
|--|---|
|  | Using a flash too close to a person's eyes may cause visual impairment. Take particular care when photographing infants and young children. |
|  | Do not remain in prolonged contact with hot surfaces. Failure to observe this precaution could result in low-temperature burns, particularly at high ambient temperatures or with users who suffer from poor circulation or reduced sensation, in which case use of a tripod or similar precautions are recommended. |
|  | Do not leave one part of the body in contact with the product for prolonged periods while the product is on. Failure to observe this precaution could result in low-temperature burns, particularly during prolonged use, at high ambient temperatures, or with users who suffer from poor circulation or reduced sensation, in which case use of a tripod or similar precautions are recommended. |
|  | Do not use in the presence of flammable objects, explosive gases, or dust. |
|  | When carrying the battery, install it in a digital camera or keep it in the hard case. When storing the battery, keep it in the hard case. When discarding, cover the battery terminals with insulation tape. Contact with other metallic objects or batteries could cause the battery to ignite or burst. |
|  | Keep memory cards, hot shoes, and other small parts out of the reach of small children. Children may swallow small parts; keep out of reach of children. Should a child swallow a small part, seek medical attention or call emergency. |
|  | Keep out of reach of small children. Among the elements that could cause injury are the strap, which could become entangled about a child's neck, causing strangulation, and the flash, which could cause visual impairment. |
|  | Follow the directions of airline and hospital personnel. This product generates radio-frequency emissions that could interfere with navigational or medical equipment. |
|  CAUTION | |
|  | Do not use this camera in locations affected by oil fumes, steam, humidity or dust. This can cause a fire or electric shock. |
|  | Do not leave this camera in places subject to extremely high temperatures. Do not leave the camera in locations such as a sealed vehicle or in direct sunlight. This can cause a fire. |
|  | Do not place heavy objects on the camera. This can cause the heavy object to tip over or fall and cause injury. |
|  | Do not move the camera while the AC power adapter is still connected. Do not pull on the connection cord to disconnect the AC power adapter. This can damage the power cord or cables and cause a fire or electric shock. |

|  CAUTION | |
|--|---|
|  | <u>Do not cover or wrap the camera or the AC power adapter in a cloth or blanket.</u> This can cause heat to build up and distort the casing or cause a fire. |
|  | <u>Do not use the plug if it is damaged or if it does not fit securely into the outlet.</u> Failure to observe this precaution could result in fire or electric shock. |
|  | <u>When you are cleaning the camera or you do not plan to use the camera for an extended period, remove the battery and disconnect and unplug the AC power adapter.</u> Failure to do so can cause a fire or electric shock. |
|  | <u>When charging ends, unplug the charger from the power socket.</u> Leaving the charger plugged into the power socket can cause a fire. |

|  CAUTION | |
|--|--|
|  | <u>When a memory card is removed, the card could come out of the slot too quickly. Use your finger to hold it and gently release the card.</u> Injury could result to those struck by the ejected card. |
|  | <u>Request regular internal testing and cleaning for your camera.</u> Build-up of dust in your camera can cause a fire or electric shock. Contact your Fujifilm dealer to request internal cleaning every two years. Please note that this service is not free of charge. |
|  | <u>Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.</u> |
|  | <u>Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.</u> |

The Battery and Power Supply

Note: Check the type of battery used in your camera and read the appropriate sections.

 **WARNING:** Battery shall not be exposed to excessive heat such as sunshine, fire or the like.

The following describes the proper use of batteries and how to prolong their life. Incorrect use can shorten battery life or cause leakage, overheating, fire, or explosion.

Li-ion Batteries

Read this section if your camera uses a rechargeable Li-ion battery.

The battery is not charged at shipment. Charge the battery before use. Keep the battery in its case when not in use.

■ Notes on the Battery

The battery gradually loses its charge when not in use. Charge the battery one or two days before use.

Battery life can be extended by turning the camera off when not in use.

Battery capacity decreases at low temperatures; a depleted battery may not function when cold. Keep a fully charged spare battery in a warm place and exchange as necessary, or keep the battery in your pocket or other warm place and insert it in the camera only when shooting. Do not place the battery in direct contact with hand warmers or other heating devices.

■ Charging the Battery

Charge the battery in the supplied battery charger. Charging times will increase at ambient temperatures below +10°C (+50°F) or above +35°C (+95°F). Do not attempt to charge the battery at temperatures above +40°C (+104°F); at temperatures below +5°C (+41°F), the battery will not charge.

Do not attempt to recharge a fully charged battery. The battery does not however need to be fully discharged before charging.

The battery may be warm to the touch immediately after charging or use. This is normal.

■ Battery Life

At normal temperatures, the battery can be recharged about 300 times. A noticeable decrease in the length of time the battery will hold a charge indicates that it has reached the end of its service life and should be replaced.

■ Storage

Performance may be impaired if the battery is left unused for extended periods when fully charged. Run the battery flat before storing it.

If the camera will not be used for an extended period, remove the battery and store it in a dry place with an ambient temperature of from +15°C to +25°C (+59°F to +77°F). Do not store in locations exposed to extremes of temperature.

■ Cautions: Handling the Battery

- Do not transport or store with metal objects such as necklaces or hairpins.
- Do not expose to flame or heat.
- Do not disassemble or modify.
- Use with designated chargers only.
- Dispose of used batteries promptly.
- Do not drop or subject to strong physical shocks.
- Do not expose to water.
- Keep the terminals clean.
- The battery and camera body may become warm to the touch after extended use. This is normal.

■ Caution: Disposal

Dispose of used batteries in accord with local regulations. Attention should be drawn to the environmental aspects of battery disposal. Use the apparatus under moderate climate.

AC Power Adapters

Use only Fujifilm AC power adapters designated for use with this camera. Other adapters could damage the camera.

- The AC power adapter is for indoor use only.
- Be sure the DC plug is securely connected to the camera.
- Turn the camera off before disconnecting the adapter. Disconnect the adapter by the plug, not the cable.
- Do not use with other devices.

- Do not disassemble.
- Do not expose to high heat and humidity.
- Do not subject to strong physical shocks.
- The adapter may hum or become hot to the touch during use. This is normal.
- If the adapter causes radio interference, reorient or relocate the receiving antenna.

Using the Camera

- Do not aim the camera at extremely bright light sources, such as the sun in a cloudless sky. Failure to observe this precaution could damage the camera image sensor.
- Strong sunlight focused through the viewfinder may damage the panel of electronic viewfinder (EVF). Do not aim the electronic viewfinder at the sun.

Take Test Shots

Before taking photographs on important occasions (such as at weddings or before taking the camera on a trip), take a test shot and view the results to ensure that the camera is functioning normally. FUJIFILM Corporation cannot accept liability for damages or lost profits incurred as a result of product malfunction.

Notes on Copyright

Unless intended solely for personal use, images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner. Note that some restrictions apply to the photographing of stage performances, entertainments, and exhibits, even when intended purely for personal use. Users are also asked to note that the transfer of memory cards containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

Handling

To ensure that images are recorded correctly, do not subject the camera to impact or physical shocks while images are being recorded.

Liquid Crystal

In the event that the display is damaged, care should be taken to avoid contact with liquid crystal. Take the urgent action indicated should any of the following situations arise:

- **If liquid crystal comes in contact with your skin**, clean the area with a cloth and then wash thoroughly with soap and running water.
- **If liquid crystal enters your eyes**, flush the affected eye with clean water for at least 15 minutes and then seek medical assistance.
- **If liquid crystal is swallowed**, rinse your mouth thoroughly with water. Drink large quantities of water and induce vomiting, then seek medical assistance.

Although the display is manufactured using extremely high-precision technology, it may contain pixels that are always lit or that do not light. This is not a malfunction, and images recorded with the product are unaffected.

Trademark Information

Digital Split Image is a trademark or registered trademark of FUJIFILM Corporation. Digital Micro Prism is a trademark or registered trademark of FUJIFILM Corporation. xD-Picture Card and  are trademarks of FUJIFILM Corporation. The typefaces included herein are solely developed by DynaComware Taiwan Inc. Mac, OS X, and macOS are trademarks of Apple Inc. in the U.S.A. and other countries. Windows is a registered trademark of Microsoft Corporation in the U.S.A. and other countries. Adobe, the Adobe logo, Photoshop, and Lightroom are trademarks or registered trademarks of Adobe Systems Incorporated in the U.S.A. and other countries. Wi-Fi® and Wi-Fi Protected Setup® are registered trademarks of the Wi-Fi Alliance. The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc., and any use of such marks by Fujifilm is under license. The SDHC and SDXC logos are trademarks of SD-3C, LLC. The HDMI logo is a trademark or registered trademark of HDMI Licensing LLC. All other trade names mentioned in this manual are the trademarks or registered trademarks of their respective owners.

Electrical Interference

This camera may interfere with hospital or aviation equipment. Consult with hospital or airline staff before using the camera in a hospital or on an aircraft.

Color Television Systems

NTSC (National Television System Committee) is a color television telecasting specification adopted mainly in the U.S.A., Canada, and Japan. PAL (Phase Alternation by Line) is a color television system adopted mainly in European countries and China.

Exif Print (Exif Version 2.3)

Exif Print is a newly revised digital camera file format in which information stored with photographs is used for optimal color reproduction during printing.

IMPORTANT NOTICE: Read Before Using the Software

Direct or indirect export, in whole or in part, of licensed software without the permission of the applicable governing bodies is prohibited.

NOTICES

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

Please read the "Safety Notes" and make sure you understand them before using the camera.

Perchlorate Material—special handling may apply. See:

<http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

For Customers in the U.S.A.

**Tested To Comply With FCC Standards
FOR HOME OR OFFICE USE**



Contains IC : 10293A-WMBNBM26A

Contains FCC ID : COF-WMBNBM26A

FCC Statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement: This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

Notes on the Grant: To comply with Part 15 of the FCC Rules, this product must be used with a Fujifilm-specified ferrite-core A/V cable, USB cable, and DC supply cord.



A lithium ion battery that is recyclable powers the product you have purchased. Please call 1-800-8-BATTERY for information on how to recycle this battery.

For Customers in Canada

CAN ICES-3 (B)/NMB-3(B)

CAUTION: This Class B digital apparatus complies with Canadian ICES-003.

Industry Canada statement: This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter, except tested built-in radios. The County Code Selection feature is disabled for products marketed in the US/ Canada.

Radiation Exposure Statement: The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power Wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research. GFX 50R has been tested and found to comply with IC radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the IC radio frequency (RF) Exposure rules.

Disposal of Electrical and Electronic Equipment in Private Households

In the European Union, Norway, Iceland and

Liechtenstein: This symbol on the product, or in the manual and in the warranty, and/or on its packaging indicates that this product shall not be treated as household waste. Instead it should be taken to an applicable collection point for the recycling of electrical and electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

This symbol on the batteries or accumulators indicates that those batteries shall not be treated as household waste.

If your equipment contains easy removable batteries or accumulators please dispose these separately according to your local requirements.

The recycling of materials will help to conserve natural resources. For more detailed information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

In Countries Outside the European Union, Norway, Iceland and

Liechtenstein: If you wish to discard this product, including the batteries or accumulators, please contact your local authorities and ask for the correct way of disposal.

In Japan: This symbol on the batteries indicates that they are to be disposed of separately.



Li-ion

Wireless Network and Bluetooth Devices: Cautions

This product complies with the following EU Directives:

- RoHS Directive 2011/65/EU
- RE Directive 2014/53/EU

Hereby, FUJIFILM Corporation declares that the radio equipment type FF180004 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: http://www.fujifilm.com/products/digital_cameras/gfx/fujifilm_gfx_50r/pdf/index/fujifilm_gfx_50r_cod.pdf

This compliance is indicated by the following conformity marking placed on the product:



This marking is valid for non-Telecom products and EU harmonized Telecom products (e.g. Bluetooth®).

IMPORTANT: Read the following notices before using the camera's built-in wireless transmitter.

- ① This product, which contains encryption function developed in the United States, is controlled by the United States Export Administration Regulations and may not be exported or re-exported to any country to which the United States embargoes goods.

- **Use only a wireless network or Bluetooth device.** Fujifilm does not accept liability for damages resulting from unauthorized use. Do not use in applications requiring a high degree of reliability, for example in medical devices or other systems that may directly or indirectly impact human life. When using the device in computer and other systems that demand a greater degree of reliability than offered by wireless network or Bluetooth devices, be sure to take all necessary precautions to ensure safety and prevent malfunction.
- **Use only in the country in which the device was purchased.** This device conforms to regulations governing wireless network and Bluetooth devices in the country in which it was purchased. Observe all location regulations when using the device. Fujifilm does not accept liability for problems arising from use in other jurisdictions.
- **Do not use the device in locations subject to magnetic fields, static electricity, or radio interference.** Do not use the transmitter in the vicinity of microwave ovens or in other locations subject to magnetic fields, static electricity, or radio interference that may prevent reception of wireless signals. Mutual interference may occur when the transmitter is used in the vicinity of other wireless devices operating in the 2.4 GHz band.
- **The wireless transmitter operates in the 2.4 GHz band using DSSS, OFDM and GFSK modulation.**

- **Security.** Wireless network and Bluetooth devices transmit data via radio and consequently their use requires greater attention to security than applies in the case of wired networks.

- Do not connect to unknown networks or networks to which you do not have access rights, even if they are displayed on your device, as such access may be considered unauthorized. Connect only to networks to which you have access rights.
- Be aware that wireless transmissions may be vulnerable to interception by third parties.

- **The following may be punishable by law:**

- Disassembly or modification of this device
- Removal of device certification labels

- **This device operates on the same frequency as commercial, educational, and medical devices and wireless transmitters.** It also operates on the same frequency as licensed transmitters and special unlicensed low-voltage transmitters used in RFID tracking systems for assembly lines and in other similar applications.

- **To prevent interference with the above devices, observe the following precautions.** Confirm that the RFID transmitter is not in operation before using this device. Should you observe that the device causes interference in licensed transmitters used for RFID tracking, immediately stop using the affected frequency or move the device to another location. If you notice that this device causes interference in low-voltage RFID tracing systems, contact a Fujifilm representative.

- **Do not use this device on board an aircraft.** Note that Bluetooth may remain on even when the camera is off. Bluetooth can be disabled by selecting **OFF** for **CONNECTION SETTING > Bluetooth SETTINGS > Bluetooth ON/OFF**.

Be sure to read these notes before using the lens

Safety Notes

- Make sure that you use the lens correctly. Read these safety notes and the camera *Owner's Manual* carefully before use.
- After reading these safety notes, store them in a safe place.

About the Icons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.



WARNING This icon indicates that death or serious injury can result if the information is ignored.



CAUTION This icon indicates that personal injury or material damage can result if the information is ignored.

The icons shown below are used to indicate the nature of the instructions which are to be observed.



Triangular icons tell you that this information requires attention ("Important").



Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").



Filled circles with an exclamation mark indicate an action that must be performed ("Required").



WARNING



Do not immerse in or expose to water. Failure to observe this precaution can cause a fire or electric shock.



Do not disassemble (do not open the case). Failure to observe this precaution can cause fire, electric shock, or injury due to product malfunction.



Should the case break open as the result of a fall or other accident, do not touch the exposed parts. Failure to observe this precaution could result in electric shock or in injury from touching the damaged parts. Remove the battery immediately, taking care to avoid injury or electric shock, and take the product to the point of purchase for consultation.



Do not place on unstable surfaces. The product may fall, causing injury.



Do not view the sun through the lens or camera viewfinder. Failure to observe this precaution can cause permanent visual impairment.



CAUTION



Do not use or store in locations that are exposed to steam, or smoke or are very humid or extremely dusty. Failure to observe this precaution can cause fire or electric shock.



Do not leave in direct sunlight or in locations subject to very high temperatures, such as in a closed vehicle on a sunny day. Failure to observe this precaution can cause fire.



Keep out of the reach of small children. This product could cause injury in the hands of a child.



Do not handle with wet hands. Failure to observe this precaution can cause electric shock.



Keep the sun out of the frame when shooting backlit subjects. Sunlight focused into the camera when the sun is in or close to the frame can cause fire or burns.



When the product is not in use, replace the lens caps and store out of direct sunlight. Sunlight focused by the lens can cause fire or burns.




Do not carry the camera or lens while they are attached to a tripod. The product can fall or strike other objects, causing injury.

Product Care

To ensure continued enjoyment of the product, observe the following precautions.

Camera body: Use a soft, dry cloth to clean the camera body after each use. Do not use alcohol, thinner, or other volatile chemicals, which could discolor or deform the leather on the camera body. Any liquid on the camera should be removed immediately with a soft, dry cloth. Use a blower to remove dust from the monitor, taking care to avoid scratches, and then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of Fujifilm lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied. To prevent dust entering the camera, replace the body cap when no lens is in place.

Image sensor: Multiple photographs marred by spots or blotches in identical locations may indicate the presence of dust on the image sensor. Clean the sensor using  **USER SETTING > SENSOR CLEANING**.

Cleaning the Image Sensor

Dust that cannot be removed using **USER SETTING > SENSOR CLEANING** can be removed manually as described below.

! Note that there will be a charge to repair or replace the image sensor if it is damaged during cleaning.

- 1 Use a blower (not a brush) to remove dust from the sensor.

! Do not use a brush or blower brush. Failure to observe this precaution could damage the sensor.




- 2 Check whether the dust has been successfully removed. Repeat Steps 1 and 2 as necessary.
- 3 Replace the body cap or lens.


Firmware Updates

Updates to product firmware may result in changes not described in the manual. For more information, visit: http://www.fujifilm.com/support/digital_cameras/software

Checking the Firmware Version

 The camera will only display the firmware version if a memory card is inserted.


- 1 Turn the camera off and check that a memory card is inserted.
- 2 Turn the camera on while pressing the **DISP/BACK** button. The current firmware version will be displayed; check the firmware version.
- 3 Turn the camera off.

 To view the firmware version or update firmware for optional accessories such as interchangeable lenses, shoe-mounted flash units, and mount adapters, mount the accessories on the camera.

Troubleshooting



Consult the table below should you encounter problems using your camera. If you don't find the solution here, contact your local Fujifilm distributor.

Power and Battery

| Problem | Solution |
|--------------------------------|--|
| The camera does not turn on. | <ul style="list-style-type: none">• The battery is exhausted: Charge the battery or insert a fully-charged spare battery (📖 29).• The battery is inserted incorrectly: Reinsert in the correct orientation (📖 32).• The battery-chamber cover is not latched: Latch the battery-chamber cover (📖 32). |
| The monitor does not turn on. | The monitor may not turn on if the camera is turned off and then on again very quickly. Keep the shutter button pressed halfway until the monitor activates. |
| The battery runs down quickly. | <ul style="list-style-type: none">• The battery is cold: Warm the battery by placing it in a pocket or other warm place and reinsert it in the camera immediately before taking a picture.• There is dirt on the battery terminals: Clean the terminals with a soft, dry cloth.• ON is selected for  AF/MF SETTING > PRE-AF: Turn PRE-AF off (📖 103).• The battery has been charged many times: The battery has reached the end of its charging life. Purchase a new battery (📖 159). |
| The camera turns off suddenly. | The battery is exhausted: Charge the battery or insert a fully-charged spare battery (📖 29). |

| Problem | Solution |
|---|--|
| Charging does not start. | <ul style="list-style-type: none"> • Insert the battery (📖 32). • Reinsert the battery in the correct orientation (📖 32). • Make sure that the charger is correctly plugged in (📖 29). • Ensure that the plug adapter is correctly connected to the charger (📖 29). |
| Charging is slow. | Charge the battery at room temperature. |
| The charging lamp blinks, but the battery does not charge. | <ul style="list-style-type: none"> • There is dirt on the battery terminals: Clean the terminals with a soft, dry cloth (📖 32). • The battery has been charged many times: The battery has reached the end of its charging life. Purchase a new battery. If the battery still fails to charge, contact your Fujifilm dealer (📖 232). |

Menus and Displays

| Problem | Solution |
|-----------------------------------|--|
| Display is not in English. | Select ENGLISH for  USER SETTING >  言語/LANG. (📖 41, 158). |

Shooting

| Problem | Solution |
|---|---|
| No picture is taken when the shutter button is pressed. | <ul style="list-style-type: none"> • The memory card is full: Insert a new memory card or delete pictures (📖 34, 138). • The memory card is not formatted: Format the memory card in the camera (📖 156). • There is dirt on the memory card contacts: Clean the contacts with a soft, dry cloth. • The memory card is damaged: Insert a new memory card (📖 34). • The battery is exhausted: Charge the battery or insert a fully-charged spare battery (📖 29). • The camera has turned off automatically: Turn the camera on (📖 37). • You are using a third-party mount adapter: Select ON for SHOOT WITHOUT LENS (📖 177). |
| Mottling ("noise") appears in the monitor or viewfinder when the shutter button is pressed halfway. | Gain is increased to aid composition when the subject is poorly lit and aperture is stopped down, which may result in noticeable mottling when images are previewed in the displays. Images taken with the camera are unaffected. |
| The camera does not focus. | The subject is not suited to autofocus: Use focus lock or manual focus (📖 81). |


| Problem | Solution |
|-----------------------------------|---|
| No face is detected. | <ul style="list-style-type: none"> • The subject's face is obscured by sunglasses, a hat, long hair, or other objects: Remove the obstructions (📖 104). • The subject's face occupies only a small area of the frame: Change the composition so that the subject's face occupies a larger area of the frame (📖 104). • The subject's face is turned away from the camera: Ask the subject to face the camera (📖 104). • The camera is tilted: Keep the camera level. • The subject's face is poorly lit: Shoot in bright light. |
| Wrong subject is selected. | <p>The selected subject is closer to the center of the frame than the main subject. Disable face detection, select single-point AF, and use focus-area selection to position the focus area over your subject (📖 67, 69).</p> |
| The flash does not fire. | <ul style="list-style-type: none"> • The flash is disabled: Adjust settings (📖 124). • The battery is exhausted: Charge the battery or insert a fully-charged spare battery (📖 29). • The camera is in bracketing or continuous mode: Select single frame mode (📖 6). |

| Problem | Solution |
|---|---|
| The flash does not fully light the subject. | <ul style="list-style-type: none"> • The subject is not in range of the flash: Position the subject in range of the flash. • The flash window is obstructed: Hold the camera correctly. • Shutter speed is faster than the sync speed: Choose a slower shutter speed (📖 58, 62, 262). |
| Pictures are blurred. | <ul style="list-style-type: none"> • The lens is dirty: Clean the lens. • The lens is blocked: Keep objects away from the lens (📖 45). • !AF is displayed during shooting and the focus frame is displayed in red: Check focus before shooting (📖 46). |
| Pictures are mottled. | <ul style="list-style-type: none"> • Shutter speed is slow and the ambient temperature is high: This is normal and does not indicate a malfunction. Use pixel mapping (📖 98). • The camera has been used continuously at high temperatures: Turn the camera off and wait for it to cool down (📖 37, 259). • A temperature warning is displayed: Turn the camera off and wait for it to cool down (📖 37, 259). |

Playback

| Problem | Solution |
|---|---|
| Pictures are grainy. | The pictures were taken with a different make or model of camera. |
| Playback zoom is unavailable. | The pictures were created using RESIZE or with a different make or model of camera. |
| No sound in movie playback. | <ul style="list-style-type: none"> • Playback volume is too low: Adjust playback volume (🔊 161). • The microphone was obstructed: Hold the camera correctly during recording. • The speaker is obstructed: Hold the camera correctly during playback. |
| Selected pictures are not deleted. | Some of the pictures selected for deletion are protected. |
| Pictures remain after ERASE > ALL FRAMES is selected. | Remove protection using the device with which it was originally applied (🔒 142). |
| File numbering is unexpectedly reset. | The battery-chamber cover was opened while the camera was on. Turn the camera off before opening the battery-chamber cover (🔋 182). |

Connections

| Problem | Solution |
|--|--|
| The monitor is blank. | The camera is connected to a TV: Pictures will be displayed on the TV instead of in the camera monitor (📖 218). |
| Both the TV and camera monitor are blank. | The display mode selected with the VIEW MODE button is EVF ONLY +  : Put your eye to the viewfinder. Use the VIEW MODE button to choose another display mode (📖 14). |
| No picture or sound on TV. | <ul style="list-style-type: none"> • The camera is not properly connected: Connect the camera properly (📖 218). • Input on the television is set to “TV”: Set input to “HDMI” (📖 218). • The volume on the TV is too low: Use the controls on the television to adjust the volume (📖 218). |
| The computer does not recognize the camera. | Be sure the camera and computer are correctly connected (📖 223). |
| Cannot transfer RAW or JPEG files to computer. | Use MyFinePix Studio to transfer pictures (Windows only; 📖 223). |

Wireless Transfer

For additional information on troubleshooting wireless connections, visit:

<http://digital-cameras.support.fujifilm.com/app?pid=x>




| Problem | Solution |
|---|--|
| Cannot connect to smartphone. The camera is slow to connect or upload pictures to the smartphone. Upload fails or is interrupted. | <ul style="list-style-type: none"> • The smartphone is too far away: Move the devices closer (📖 220). • Nearby devices are causing radio interference: Move the camera and smartphone away from microwave ovens or cordless phones (📖 220). |
| Cannot upload images. | <ul style="list-style-type: none"> • The smartphone is connected to another device: The smartphone and camera can connect to only one device at a time. End the connection and try again (📖 220). • There are several smartphones in the vicinity: Try connecting again. The presence of multiple smartphones can make connection difficult (📖 220). • The image was created on another device: The camera may not be able to upload images created on other devices. • The image is a movie: Although you can select movies for upload when viewing the contents of camera memory on your smartphone, upload will take some time. Movies intended for display on a smartphone or tablet should be recorded at a frame size of 1280 × 720 (HD) or smaller. For information on viewing the pictures on the camera, visit: http://app.fujifilm-dsc.com/en/camera_remote/ |
| Smartphone will not display pictures. | Select ON for GENERAL SETTINGS > RESIZE IMAGE FOR SMARTPHONE (📖 189). Selecting OFF increases upload times for larger images; in addition, some phones may not display images over a certain size (📖 189). |



Miscellaneous







| Problem | Solution |
|--|--|
| The camera is unresponsive. | <ul style="list-style-type: none"> • Temporary camera malfunction: Remove and reinsert the battery (📖 32). • The battery is exhausted: Charge the battery or insert a fully-charged spare battery (📖 29). • The camera is connected to a wireless LAN: End the connection. |
| The camera does not function as expected. | Remove and reinsert the battery (📖 32). If the problem persists, contact your Fujifilm dealer. |
| No sound. | Adjust the volume (📖 160). |
| Pressing the Q button does not display the quick menu. | TTL-LOCK is active: End TTL-LOCK (📖 125). |

Warning Messages and Displays

The following warnings appear in the display.



| Warning | Description |
|---|---|
|  (red) | Low battery. Charge the battery or insert a fully-charged spare battery. |
|  (blinks red) | Battery exhausted. Charge the battery or insert a fully-charged spare battery. |
| !AF (displayed in red with red focus frame) | The camera cannot focus. Use focus lock to focus on another subject at the same distance, then recompose the picture. |
| Aperture or shutter speed displayed in red | The subject is too bright or too dark and the picture will be over- or under-exposed. Use the flash for additional lighting when taking photographs of poorly-lit subject. |
| FOCUS ERROR LENS CONTROL ERROR TURN OFF THE CAMERA AND TURN ON AGAIN | Camera malfunction. Turn the camera off and then on again. If the message persists, contact a Fujifilm dealer. |
| NO CARD | The shutter can only be released when a memory card is inserted. Insert a memory card. |
| CARD NOT INITIALIZED | <ul style="list-style-type: none"> • The memory card is not formatted or the memory card has been formatted in a computer or other device: Format the memory card using  USER SETTING > FORMAT. • The memory card contacts require cleaning: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card. If the message persists, replace the card. • Camera malfunction: Contact a Fujifilm dealer. |
| LENS ERROR | Turn the camera off, remove the lens, and clean the mounting surfaces, then replace the lens and turn the camera on. If the problem persists, contact a Fujifilm dealer. |

| Warning | Description |
|---|---|
| CARD ERROR | <ul style="list-style-type: none"> • The memory card is not formatted for use in the camera: Format the card. • The memory card contacts require cleaning or the memory card is damaged: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card. If the message persists, replace the card. • Incompatible memory card: Use a compatible card. • Camera malfunction: Contact a Fujifilm dealer. |
| PROTECTED CARD | The memory card is locked. Unlock the card. |
| BUSY | The memory card is incorrectly formatted. Use the camera to format the card. |
|  MEMORY FULL | The memory card is full and pictures cannot be recorded. Delete pictures or insert a memory card with more free space. |
| WRITE ERROR | <ul style="list-style-type: none"> • Memory card error or connection error: Reinsert the card or turn the camera off and then on again. If the message persists, contact a Fujifilm dealer. • Not enough memory remaining to record additional pictures: Delete pictures or insert a memory card with more free space. • The memory card is not formatted: Format the memory card. |
| FRAME NO. FULL | The camera has run out of frame numbers (current frame number is 999-9999). Insert a formatted memory card and select RENEW for  SAVE DATA SET-UP > FRAME NO.. Take a picture to reset frame numbering to 100-0001, then select CONTINUOUS for FRAME NO.. |


| Warning | Description |
|---|--|
| READ ERROR | <ul style="list-style-type: none"> • The file is corrupt or was not created with the camera: The file cannot be viewed. • The memory card contacts require cleaning: Clean the contacts with a soft, dry cloth. If the message is repeated, format the card. If the message persists, replace the card. • Camera malfunction: Contact a Fujifilm dealer. |
| PROTECTED FRAME | An attempt was made to delete or rotate to a protected picture. Remove protection and try again. |
| CAN NOT CROP | The picture is damaged or was not created with the camera. |
| DPOF FILE ERROR | Print orders can contain no more than 999 pictures. Copy any additional pictures you wish to print to another memory card and create a second print order. |
| CAN NOT SET DPOF | The picture cannot be printed using DPOF. |
|  CAN NOT SET DPOF | Movies cannot be printed using DPOF. |
| CAN NOT ROTATE | The selected picture cannot be rotated. |
|  CAN NOT ROTATE | Movies cannot be rotated. |
|  CANNOT EXECUTE | Red-eye removal cannot be applied to movies. |
|  CANNOT EXECUTE | Red-eye removal cannot be applied to pictures created with other devices. |
|  (yellow) | Turn the camera off and wait for it to cool. Mottling may increase in pictures taken when this warning is displayed. |
|  (red) | Turn the camera off and wait for it to cool. While this warning is displayed, movie recording may not be available, mottling may increase, and performance, including frame advance rate and display quality, may drop. |

Memory Card Capacity

The following table shows the recording time or number of pictures available at different image sizes. All figures are approximate; file size varies with the scene recorded, producing wide variations in the number of files that can be stored. The number of exposures or length remaining may not diminish at an even rate.

| | | Capacity | | | 8 GB | | | 16 GB | | |
|---|---------------------------------------|----------|--|--|------------|------|--------|-------------|------|--------|
| | | | | | SUPER FINE | FINE | NORMAL | SUPER FINE | FINE | NORMAL |
|  | 4:3 | | | | 254 | 381 | 607 | 524 | 785 | 1253 |
| | RAW (UNCOMPRESSED) | | | | 66 | | | 137 | | |
| | RAW (LOSSLESS COMPRESSED) | | | | 127 | | | 265 | | |
| | Full HD 1080/29.97P, 25P, 24P, 23.98P | | | | 26 minutes | | | 54 minutes | | |
|  | HD 720/29.97P, 25P, 24P, 23.98P | | | | 51 minutes | | | 105 minutes | | |





* Use a UHS speed class 1 card or better. Individual movies cannot exceed 30 minutes in length.

 Although movie recording will continue without interruption when the file size reaches 4 GB, subsequent footage will be recorded to a separate file which must be viewed separately.

Specifications

| System | |
|-----------------------|--|
| Model | FUJIFILM GFX 50R |
| Product Number | FF180004 |
| Effective pixels | Approx. 51.4 million |
| Image sensor | 43.8 mm × 32.9 mm Bayer array with primary color filter |
| Storage media | Fujifilm-recommended SD/SDHC/SDXC memory cards |
| Memory card slots | Two SD memory card slots (UHS-II compliant) |
| File system | Compliant with Design Rule for Camera File System (DCF2.0), Exif 2.3, and Digital Print Order Format (DPOF) |
| File format | <ul style="list-style-type: none"> • Still pictures: Exif 2.3 JPEG (compressed); RAW (original RAF format, uncompressed or compressed using a lossless algorithm; special purpose software required); RAW+JPEG available; TIFF (RGB) • Movies: MPEG-4 AVC/H.264 standard with stereo sound (MOV) • Audio (voice memos): Stereo sound (WAV) |
| Image size | L 4:3 (8256 × 6192) |
| | L 3:2 (8256 × 5504) |
| | L 16:9 (8256 × 4640) |
| | L 1:1 (6192 × 6192) |
| | L 65:24 (8256 × 3048) |
| | L 5:4 (7744 × 6192) |
| | L 7:6 (7232 × 6192) |
| | RAW (8256 × 6192) |
| | S 4:3 (4000 × 3000) |
| | S 3:2 (4000 × 2664) |
| | S 16:9 (4000 × 2248) |
| | S 1:1 (2992 × 2992) |
| | S 65:24 (4000 × 1480) |
| | S 5:4 (3744 × 3000) |
| | S 7:6 (3504 × 3000) |
| | TIFF (8256 × 6192) |
| Lens mount | FUJIFILM G mount |
| Sensitivity | <ul style="list-style-type: none"> • Still pictures: Standard output sensitivity equivalent to ISO 100–12800 in increments of 1/3 EV; AUTO; extended output sensitivity equivalent to ISO 50, 25600, 51200, or 102400 • Movies: Standard output sensitivity equivalent to ISO 200–6400 in increments of 1/3 EV; AUTO |
| Metering | 256-segment through-the-lens (TTL) metering; MULTI, SPOT, AVERAGE, CENTER WEIGHTED |
| Exposure control | Programmed AE (with program shift); shutter-priority AE; aperture-priority AE; manual exposure |
| Exposure compensation | <ul style="list-style-type: none"> • Still pictures: –5 EV–+5 EV in increments of 1/3 EV • Movies: –2 EV–+2 EV in increments of 1/3 EV |









System

| | |
|---------------|---|
| Shutter speed | <ul style="list-style-type: none"> • MECHANICAL SHUTTER, E-FRONT CURTAIN SHUTTER <ul style="list-style-type: none"> - Mode P: 4 s to $\frac{1}{4000}$ s - Other modes: 60 min. to $\frac{1}{4000}$ s - Time: 60 min. to $\frac{1}{4000}$ s - Bulb: Max. 60 min. • ELECTRONIC SHUTTER, MECHANICAL + ELECTRONIC, E-FRONT + ELECTRONIC <ul style="list-style-type: none"> - Mode P: 4 s to $\frac{1}{16000}$ s - Other modes: 60 min. to $\frac{1}{16000}$ s - Time: 60 min. to $\frac{1}{16000}$ s - Bulb: Max. 60 min. |
| Continuous | <ul style="list-style-type: none"> • Available frame advance rates (JPEG): 3.0 fps • Approximate maximum number of shots per burst: 25 <p> The frame rate varies with shooting conditions and the number of images recorded. In addition, the frame rate and number of frames per burst may vary depending on the type of memory card used.</p> |
| Focus | <ul style="list-style-type: none"> • Mode: Single or continuous AF; manual focus with focus ring • Autofocus system: TTL contrast-detect • Focus-area selection: SINGLE POINT, ZONE, WIDE/TRACKING |
| White balance | Auto, Custom 1, Custom 2, Custom 3, color temperature selection, direct sunlight, shade, daylight fluorescent, warm white fluorescent, cool white fluorescent, incandescent, underwater |
| Self-timer | Off, 2 sec., 10 sec. |
| Flash mode | <ul style="list-style-type: none"> • MODE: TTL MODE (FLASH AUTO, STANDARD, SLOW SYNC.), MANUAL, MULTI, OFF • SYNC. MODE: 1ST CURTAIN, 2ND CURTAIN, AUTO FP (high-speed sync) • RED EYE REMOVAL:  FLASH+REMOVAL,  FLASH,  REMOVAL, OFF |
| Hot shoe | Accessory shoe with TTL contacts; supports sync speeds as fast as $\frac{1}{125}$ s |
| Sync contact | X contact; supports sync speeds as fast as $\frac{1}{125}$ s |
| Sync terminal | Provided |

System

| | |
|-------------------|--|
| Viewfinder | 0.5-in., 3690k-dot OLED viewfinder; magnification 0.77× with 50 mm lens (35 mm format equivalent) at infinity and diopter set to -1.0 m^{-1} ; diagonal angle of view approximately 38° (horizontal angle of view approximately 30°) <ul style="list-style-type: none"> • Diopter adjustment: -4 to $+2 \text{ m}^{-1}$ • Eyepoint: Approximately 23 mm |
|-------------------|--|

| | |
|--------------------|---|
| LCD monitor | 3.2-in/8.1 cm, 2360k-dot color LCD touch screen with 2-way tilt |
|--------------------|---|

| | | |
|--------------------------------------|--|---|
| Movies (with stereo sound) |  1080/29.97P |  720/29.97P |
| |  1080/25P |  720/25P |
| |  1080/24P |  720/24P |
| |  1080/23.98P |  720/23.98P |

Input/output terminals

| | |
|--|-----------------------------------|
| Digital input/output | USB connector (Type-C) USB3.1Gen1 |
| HDMI output | HDMI Micro connector (type D) |
| Microphone/Remote release connector | ø2.5 mm 3-pole mini jack |
| DC IN | Provided |

Power supply/other

Power supply

- NP-T125 rechargeable battery (supplied with camera)
- AC-15V AC adapter (available separately)


Battery life

- **Battery type:** NP-T125
- **Lens:** GF63mmF2.8 R WR
- **Flash:** Disabled
- **Shooting mode:** Mode P

Number of shots

| AUTO POWER SAVE | LCD | EVF |
|-----------------|-------------|-------------|
| ON | Approx. 400 | Approx. 400 |
| OFF | Approx. 340 | Approx. 340 |

Total length of footage that can be recorded on a single charge

| Mode | Actual Battery life of movie capture | Continuance Battery life of movie capture |
|---|--------------------------------------|---|
|  | Approx. 70 minutes | Approx. 145 minutes |

CIPA standard. Measured using battery supplied with camera and SD memory card.

Note: Battery endurance varies with battery charge level and the figures given above are not guaranteed. Battery endurance will decline at low temperatures.

Camera size

(W × H × D) 160.7 mm × 96.5 mm × 66.4 mm (46.0 mm excluding projections, measured at thinnest part)/6.33 in. × 3.80 in. × 2.62 in. (1.81 in.)

Camera weight

Approx. 690 g/24.3 oz., excluding battery, accessories, and memory card

Shooting weight

Approx. 775 g/27.3 oz., including battery and memory card

Operating conditions

- **Temperature:** -10 °C to +40 °C/+14 °F to +104 °F (+5 °C to +40 °C/+41 °F to +104 °F when battery is charging)
- **Humidity:** 10% to 80% (no condensation)

Wireless transmitter**Wireless LAN**

| | |
|------------------|---|
| Standards | IEEE 802.11b/g/n (standard wireless protocol) |
|------------------|---|

| | |
|---|-----------------------------------|
| Operating frequency (center frequency) | 2,412 MHz–2,462 MHz (11 channels) |
|---|-----------------------------------|

| | |
|-------------------------|----------------|
| Access protocols | Infrastructure |
|-------------------------|----------------|

Bluetooth®

| | |
|------------------|--|
| Standards | Bluetooth version 4.0 (Bluetooth Low Energy) |
|------------------|--|

| | |
|---|---------------------|
| Operating frequency (center frequency) | 2,402 MHz–2,480 MHz |
|---|---------------------|

NP-T125 rechargeable battery

| | |
|------------------------|--------|
| Nominal voltage | 10.8 V |
|------------------------|--------|

| | |
|-------------------------|----------|
| Nominal capacity | 1250 mAh |
|-------------------------|----------|

| | |
|------------------------------|------------------------------------|
| Operating temperature | –10 °C to +40 °C/+14 °F to +104 °F |
|------------------------------|------------------------------------|

| | |
|-------------------------------|---|
| Dimensions (W × H × D) | 36.0 mm × 54.4 mm × 26.0 mm/1.4 in. × 2.1 in. × 1.0 in. |
|-------------------------------|---|

| | |
|---------------|----------------------|
| Weight | Approx. 81 g/2.9 oz. |
|---------------|----------------------|

BC-T125 battery charger

| | |
|--------------------|--------------------------|
| Rated input | 100V – 240V AC, 50/60 Hz |
|--------------------|--------------------------|

| | |
|-----------------------|------------|
| Input capacity | 23 – 31 VA |
|-----------------------|------------|

| | |
|---------------------|------------------|
| Rated output | 12.6V DC, 800 mA |
|---------------------|------------------|

| | |
|----------------------------|--------------------------------|
| Supported batteries | NP-T125 rechargeable batteries |
|----------------------------|--------------------------------|

| | |
|----------------------|-------------------------------------|
| Charging time | Approx. 140 minutes (+25 °C/+77 °F) |
|----------------------|-------------------------------------|

| | |
|------------------------------|-----------------------------------|
| Operating temperature | +5 °C to +40 °C/+41 °F to +104 °F |
|------------------------------|-----------------------------------|

| | |
|-------------------------------|--|
| Dimensions (W × H × D) | 71.4 mm × 97.0 mm × 34.2 mm/2.8 in. × 3.8 in. × 1.4 in., excluding projections |
|-------------------------------|--|

| | |
|---------------|-----------------------|
| Weight | Approx. 120 g/4.2 oz. |
|---------------|-----------------------|



Weight and dimensions vary with the country or region of sale.



Specifications and performance are subject to change without notice. Fujifilm will not be held liable for any errors this manual may contain. The appearance of the product may differ from that described in this manual.

[illegible]

[illegible]

FUJIFILM

FUJIFILM Corporation

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN

http://www.fujifilm.com/products/digital_cameras/index.html

